

PARTS CATALOGUE

SIERRA-U DXL-90U



CONTENTS


PARTS ITEM:

- 01 CYLINDERHEAD
- 02 CRANKSHAFTPISTON
- 03 FAN COVERAIR SHROUD
- 04 AIR CLEANERREED VALVECARBURETOR
- 05 CRANK CASECOVEROIL PUMP
- 06 TRANSMISSION
- 07 KICK SHAFT ASSY.STARTER CLUTCH ASSY.
- 08 DRIVEN PULLEY (CVT)
- 09 ENGINE BRACKET ENG ATV
- 10 GENERATORSTART MOTOR
- 11 PREARRANGE
- 12 PREARRANGE
- 13 MUFFLER
- 14 FRAME
- 15 SWING ARM
- 16 FENDER
- 17 SEAT
- 18 FUEL TANKOIL TANK
- 19 SUSPENSION
- 20 FRONT WHEEL
- 21 REAR WHEEL
- 22 FRONT BRAKE
- 23 REAR BRAKE
- 24 HANDLE BAR
- 25 BUMPERFOOTREST
- 26 CHAINREAR WHEEL AXLE
- 27 STEERING

- 28 ELECTRICAL EQUIPMENT
- 29 FRONT&REAR PACK ASSY
- 30 PACKING CASEEXTERNAL
- 40 CYLINDER+PISTON TOP END KIT
- 41 MAINTENANCE KIT 1 (MJ # 85)
- 42 MAINTENANCE KIT 2 (MJ # 85)


N & sign meaning: not available to sale

1. CYLINDER, HEAD




ITEM	AVAIL	PART NO.	NAME	QTY
01			CYLINDERHEAD	
01-1		A2200-B00-0000	HEAD CYLINDER	1
01-2		A2251-B00-0000	GASKET CYLINDER HEAD	1
01-3		I8000-B00-0000	SPARK PLUG	1
01-4		A2100-B00-0000	CYLINDER	1
01-5		A2191-B00-0000	GASKET CYLINDER	1
01-6		I0031-07124-0H	STUD BOLT (A)	4
01-7		I4050-07070-0H	NUT FLANGE	4

2. CRANKSHAFT, PISTON




ITEM	AVAIL	PART NO.	NAME	QTY
02			CRANKSHAFTPISTON	
02-1		A3000-B00-0001	CRANKSHAFT COMP	1
02-1-1		I4401-13050	WOODRUFF KEY	1
02-2		I6100-62044-10	BEARING, BALL, RADIAL	2
02-3		I1202-B00-0000	OIL SEAL	1
02-4		I1201-B00-0000	OIL SEAL	1
02-5		B8117-B00-0000	BOSS	1
02-6		A3101-B00-0000	PISTON	1
02-7		A3111-B00-0000	PIN PISTON (12×40)	1
02-8		A3011-B00-0000	PISTON RING SET (50)	1
02-9		I4601-12000	CLIP, PISTON PIN	2
02-10		I1100-1215165	BEARING, NEEDLE	1
02-11		I4510-19000	CIRCLIP EX	2
02-12		A5131-B00-0000	GEAR PUMP DRIVE	1
02-13		I4303-03118	KNOCK PIN	1

3. FAN COVER, SHROUD



ITEM	AVAIL	PART NO.	NAME	QTY
03			FAN COVERAIR SHROUD	
03-1		A9620-B00-0001	AIR SHROUD, CYLINDER	1
03-2		A1207-B00-0000	GROMMET	2
03-3		A961A-B00-0000	COVER FAN COMP	1
03-3-1		A9610-B00-0000	COVER COMP FAN	1
03-3-1-1		A9617-B00-0000	SEAL SHROUD 1	1
03-3-1-2		A9618-B00-0000	SEAL SHROUD 2	1
03-3-2		A9616-B00-0000	CAP FAN COVER	1
03-3-3		I3903-416B0	TRUSS	1
03-3-4		I4104-05316	WASHER	1
03-4		I3891-06020-0C	SCREW WASHER	2
03-5		I3901-240C0	SCREW TAPPING	1
03-6		A9510-B00-0000	FAN	1
03-7		I4608-64431	O-RING	1
03-8		I3893-06016-0H	SCREW WASHER	3
03-9		H0153-B00-0000	DEFLECTOR	1
03-10		A7910-9FA0-0000	CABLE ASSY THROT	1


4. AIR CLEANER, REED VALVE, CARBURETOR



ITEM	AVAIL	PART NO.	NAME	QTY
04			AIR CLEANER REED VALVE CARBURETOR	
04-1		A6201-B00-0000	GASKET VALVE SEAT	1
04-2		A410A-B00-0000	REED VALVE ASSY	1
04-3		A720A-B00-7000	AIR CLEANER ASSY	1
04-3-1		A7257-B00-7000	DUCT	1
04-3-2		A7230-B00-0000	CASE AIR/C	1
04-3-3		A7232-B00-0000	CAP	1
04-3-4		I5002-12312	TUBE CLIP	1
04-3-5		A7234-B00-0000	TUBE DRAIN	1
04-3-6		A7205-B00-0000	WEB AIR/C	1
04-3-7		A7214-B00-0000	SEAL	1
04-3-8		A7233-B00-0000	PLATE FIXING CONNECTING TUBE	1
04-3-9		I3903-312B0	TRUSS	5
04-3-10		A7231-B00-0000	COVER AIR/C	1
04-3-11		A7253-B00-0000	JOIN PIPE AIR CLEANER	1
04-3-12		I5002-43022	TUBE CLIP	1
04-3-13		I3901-425C0	SCREW TAPPING	3
04-4		A711A-B00-0000	PIPE INLET ASSY	1
04-4-1		A7110-B00-0000	PIPE COMP INLET	1
04-4-2		A7256-B00-0000	BAND CONNECTING TUBE	1
04-5		A610A-B00-0001	CARBURETOR ASSY. (MJ #85)	1
04-5-1		A6111-B00-0000	BOLT WASHER	1
04-5-2		A6109-B00-0000	BOLT WASHER	1
04-5-3		A6102-B00-0000	CARBURETOR COVER	1
04-5-4		A6112-B00-0000	NUT HEX	1
04-5-5		A6103-B00-0000	CARBURETOR COVER WASHER	1
04-5-6		KAC31810	THROTTLE VALVE SPRING	1
04-5-7		KAC30310	V CLIP	1
04-5-8		KAC30220	JET NEEDLE ASSY. (#3CR1)	1
04-5-8-1	N	KAC30222	E CLIP	1
04-5-8-2	N	KAC30221	JET NEEDLE (#3CR1)	1
04-5-9		KAC30110	THROTTLE VALVE (#3.0)	1
04-5-10		A6105-B00-0000	AIR FLOW ADJUSTING SCREW	1
04-5-11		KAC30840	THROTTLE ADJUSTING SCREW	1
04-5-12		KAC30510	SLOW JET (*20)	1
04-5-13		KAC30610	NEEDLE JET (*426 E-1)	1
04-5-14		KAC30410	MAIN JET # 85	1
04-5-15		A6104-B00-0000	CARBURETOR BODY	1

04-5-16		A6118-B00-0000	O-RING	1
04-5-17	N	A6119-B00-0000	NEEDLE VALVE SEAT	1
04-5-18	N	KAC31120	NEEDLE VALVE ASSY.	1
04-5-18-1	N	KAC31121	NEEDLE VALVE	1
04-5-18-2	N	KAC31122	FLOAT CLIP	1
04-5-19		A6120-B00-0000	PLATE FIXING	1
04-5-20		A6115-B00-0000	BOLT	1
04-5-21		KAC30910	CHAMBER O-RING	1
04-5-22		KAC31210	FLOAT ASSY	1
04-5-23		A6108-B00-0000	CARBURETOR CHAMBER	1
04-5-24		KAC31410	DRAIN SCREW	1
04-5-25		A6117-B00-0000	BOLT WASHER	4
04-5-26		A6106-B00-0000	RUBBER TUBE	1
04-5-27		A6153-B00-0000	MANUAL CHOKE VALVE	1
04-5-28		A6152-B00-0000	SPRING	1
04-5-29		A6113-B00-0000	O-RING	1
04-5-30		KAC31910	AUTO-BY STARTER	1
04-5-31		A6114-B00-0000	BOLT WASHER	2
04-6		A6022-5EC9-0000	RESTRICTOR CARBURETOR	1
04-7		A6101-B02-0000	CRAB RUBBER CAP	1
04-8		I6706-06020-0C	SCREW WASHER	2
04-9		I6001-06020-0H	FLANGE BOLT, HEX.	4


5. CRANK CASE, COVER ,OIL PUMP



ITEM	AVAIL	PART NO.	NAME	QTY
05			CRANK CASECOVEROIL PUMP	
05-1		A1000-B00-0000	R L CRANK CASE COMP	1
05-1-1	N	A1200-B00-8900	CRANK CASE (L)	1
05-1-2	N	A1100-B00-9900	CRANK CASE RIGHT	1
05-2		A1208-B00-0000	BUSH	1
05-3		A1105-B00-0000	CAP RUBBER R	1
05-4		A1220-B00-0000	BREATHER COMP	1
05-4-1	N	A1206-B00-0000	BREATHER JOINT	1
05-4-2	N	A1221-B00-0000	HOSE, BREATHER	1
05-4-3		I5002-06008	TUBE CLIP	1
05-5		A137A-B00-0000	BOLT,FLANGE(M6×23.5)	2
05-6		A1361-B00-0000	PLATE	1
05-7		I4301-12160	KNOCK PIN	2
05-8		I3500-06035-0A	SCREW PAN	10
05-9		A1205-B00-0000	RUBBER CAP LEFT	1
05-10		B1300-B00-0000	COVER, MISSION	1
05-11		B1395-B00-0000	GASKET, MISSION COVER	1
05-12		A1395-B00-0000	GASKET L COVER	1
05-13		I4301-10140	KNOCK PIN	4
05-14		I3500-06020-0A	SCREW PAN	3
05-15		A1341-B00-0000	COVER CRANK CASE L	1
05-16		A1342-B00-0000	SHAFT	1
05-17		I3500-06025-0A	SCREW PAN	8
05-18		I3500-06065-0A	SCREW PAN	1
05-19		A5651-B00-0000	PLUG, OIL	1
05-20		I4608-13825	O-RING	1
05-21		I5701-08016-0H	BOLT FLANGE	1
05-22		I4104-08015	WASHER	1
05-23		A1121-B00-0000	HOLDER	1
05-24		I3500-06012-0A	SCREW, PAN	1
05-25		A1393-B00-0000	GASKET R CRANK CASE	1
05-26		I4050-06060-0H	FLANGE NUT, HEX.	3
05-27		A1362-B00-0000	ELEMENT	1
05-28		A1363-B00-0000	GUIDE, ELEMENT	1
05-29		I4520-42000	CIRCLIP IN	1
05-30		A510A-B00-7000	OIL PUMP ASSY	1
05-31		I3500-05014-0A	SCREW PAN HEAD	2
05-32		A135A-B00-0000	COVER, CRANKCASE ASSY(L)	1
05-32-1		A1351-B00-0000	COVER, CRANKCASE (L)	1


05-32-2		A1352-B00-0000	DAMPER ENGINE MOUT 1	1
05-32-3		A1354-B00-0000	DAMPER ENGINE MOUT 3	1
05-32-4		A1353-B00-0000	DAMPER ENGINE MOUT 2	1
05-32-5		A1356-B00-0000	DAMPER ENGINE MOUT 5	1
05-32-6		A1355-B00-0000	DAMPER ENGINE MOUT 4	1

6.TRANSMISSION




ITEM	AVAIL	PART NO.	NAME	QTY
06			TRANSMISSION	
06-1		B3420-B00-0000	COUNTER SHAFT COMP	1
06-2		I6100-62013-10	BEARING, BALL, RADIAL	1
06-3		I4104-12310	WASHER	1
06-4		I700W-12027	SPOKE NIPPLE WASHER	1
06-5		B3430-B00-9000	FINAL SHAFT COMP	1
06-6		I1130-253316	BEARING, NEEDLE	1
06-7		I6150-60040-10	BEARING, BALL, RADIAL	1
06-8		I1204-B00-0000	OIL SEAL	1
06-9		I4520-42000	CIRCLIP IN	1
06-10		I4530-32000	CIRCLIP	1
06-11		I4104-20210	WASHER	1
06-12		I4510-20000	CIRCLIP EX	1
06-13		B3801-B00-9000	DRIVE CHAIN SPROCKET	1
06-14		B3811-A00-0000	PLATE FIXING	1
06-15		I2201-06010-0H	BOLT, HEX.	2

7.KICK SHAFT ASSY., STARTER CLUTCH ASSY.



ITEM	AVAIL	PART NO.	NAME	QTY
07			KICK SHAFT ASSY.STARTER CLUTCH ASSY.	
07-1		B8110-B00-0000	GEAR COMP STARTING CLUTCH	1
07-2		I1100-555913	BRARING, NEEDLE	1
07-3		B8115-B00-0000	BOSS GEAR	1
07-4		I4104-55506	WASHER	1
07-5		B8120-B00-0000	OUTER COMP ST CLUTCH	1
07-6		B8100-B00-0000	GEAR COMP STARTER REDUCTION	1
07-6-1		B8101-B00-0000	GEAR STARTER REDUCTION	1
07-6-2		I1130-081210	BEARING, NEEDLE	1
07-7		B823A-B00-0000	GEAR ASSY STARTER IDLE	1
07-7-1		B8223-B00-0000	SPG KICK DRIVEN GEAR	1
07-7-2		B8230-B00-0000	GEAR COMP KICK DRIVEN	1
07-8		B8300-B00-8000	KICK CRANK ASSY.	1
07-9		B8102-B00-0000	SHAFT START REDUCTION	1
07-10		I4104-08218	WASHER	2
07-11		B8105-B00-0000	PLATE START REDUCTION	1
07-12		I3892-06014-0H	SCREW, PAN	2
07-13		B8250-B00-9000	SPINDLE COMP KICK START	1
07-14		B8281-B00-0000	SPRING KICK RETURN	1
07-15		B8254-B00-0000	BOSS KICK SPINDLE	1
07-16		I4104-15010	WASHER	1
07-17		I4510-15000	CIRCLIP EX	1
07-18		A1000-5EA0-0000	RUBBER CAP KICK SHAFT	1


8.DRIVEN PULLEY(CVT)



ITEM	AVAIL	PART NO.	NAME	QTY
08			DRIVEN PULLEY (CVT)	
08-1		B3411-B00-0000	SHAFT DRIVE	1
08-2		I4104-06512A	WASHER	1
08-3		I3500-06010-0A	SCREW, PAN	1
08-4		I4510-17000	CIRCLIP EX	1
08-5		I6100-60030	BEARING, BALL, RADIAL	1
08-6		I1203-B00-0000	OIL SEAL	1
08-7		B301A-B00-0000	PLATE SUB ASSY DRIVE	1
08-7-1		I1211-B00-0000	OIL SEAL	2
08-7-1		I1211-B00-0000	OIL SEAL	2
08-7-2		I4608-36719	O-RING	2
08-7-2		I4608-36719	O-RING	2
08-7-3		B3237-B00-0000	COLLAR SEAL	1
08-7-3		B3237-B00-0000	COLLAR SEAL	1
08-7-4		B3233-B02-0000	SPG DRIVEN FACE	1
08-7-4		B3233-B00-0000	SPG DRIVEN FACE	1
08-7-5		B2300-B00-0000	PLATE COMP DRIVE	1
08-7-5		B2300-B00-0000	PLATE COMP DRIVE	1
08-7-6		I4002-281A0	NUT HEX	1
08-7-6		I4002-281A0	NUT HEX	1
08-7-7		B2101-B00-0000	OUTER CLUTCH	1
08-7-7		B2101-B00-0000	OUTER CLUTCH	1
08-7-8		B3210-B00-0000	FACE COMP DRIVEN	1
08-7-8		B3210-B00-0000	FACE COMP DRIVEN	1
08-7-9		B3220-B00-0000	FACE COMP MOVABLE DRIVE	1
08-7-9		B3225-B00-0000	PIN GUIDE	2
08-7-10		B3225-B00-0000	PIN GUIDE	2
08-7-10		B3220-B00-0000	FACE COMP MOVABLE DRIVE	1
08-8		I4050-10080-0H	NUT FLANGE	1
08-9		I6130-60380-10	BEARING, BALL, RADIAL	1
08-10		I4608-64531	O-RING	1
08-11		B211A-B00-0000	FACE ASSY MOVABLE DRIVE	1
08-11-1		B2121-B00-0000	ROLLER COMP WEIGHT	6
08-11-2		B2110-B00-0000	FACE COMP MOVABLE DRIVE	1
08-11-3		B2132-B00-0000	PIECE SLIDE	3
08-11-4		B2131-B00-0000	PLATE RAMP	1
08-12		B2105-B00-0000	BOSS DRIVE FACE	1
08-13		B3100-B00-0000	BELT DRIVE	1
08-14		B2102-B00-0000	FACE DRIVE	1


08-15		B8211-B00-0000	CLUTCH, ONEWAY	1
08-16		I700W-10126	SPOKE NIPPLE WASHER	1
08-17		I4001-100C0	NUT HEX	1
08-18		B2103-B00-0000	WASHER DRIVE FACE	1

9.ENGINE BRACKET



ITEM	AVAIL	PART NO.	NAME	QTY
09			ENGINE BRACKET ENG ATV	
09-1		AB000-B00-8003	ENGINE ATV	1
09-2		A1261-B00-9000	PIN, PIVOT	1
09-3		I0309-0800H	HEX. NUT, SAFETY	1
09-4		A1241-B00-9000	ENGINE BRACKET	1
09-5		I5702-12038-0H	BOLT FLANGE	1
09-6		I4001-121H0	NUT HEX	1
09-7		I4104-12210	WASHER	1

10.GENERATOR, START MOTOR



ITEM	AVAIL	PART NO.	NAME	QTY
10			GENERATORSTART MOTOR	
10-1		C1120-B00-0000	STATOR COMP	1
10-1-1	N	C1121-B00-0000	STATOR	1
10-1-2	N	I1205-B00-0000	OIL SEAL	1
10-2		C1110-B00-0000	FLYWHEEL COMP.	1
10-3		I4104-12522	WASHER	1
10-4		I4050-12110-0H	FLANGE NUT, HEX.	1
10-5		I3500-06016-0A	SCREW, PAN	2
10-6		C1200-B00-0000	MOTOR START COMP	1
10-6-1		C1220-B00-0000	CARBON BRUSH COMP	1
10-6-1-1	N	C1221-B00-0000	POSITIVE CARBON BRUSH	1
10-6-1-2	N	C1222-B00-0000	NEGATIVE CARBON BRUSH	1
10-7		I6001-06020-0H	FLANGE BOLT, HEX.	2


No picture.

ITEM	AVAIL	PART NO.	NAME	QTY
11			PREARRANGE	

No picture.


ITEM	AVAIL	PART NO.	NAME	QTY
12			PREARRANGE	

13. MUFFLER




ITEM	AVAIL	PART NO.	NAME	QTY
13			MUFFLER	
13-1		A830A-9FA0-0000	EXHAUST PIPE ASSY.	1
13-2		A8291-5AA0-0000	GASKET (34×25.4×4)	1
13-3		I0149-06810	BOLT ,FLANGE	2
13-4		I0149-08036-01	BOLT,FLANGE	2

14. FRAME




ITEM	AVAIL	PART NO.	NAME	QTY
14			FRAME	
14-1		E0100-9FA0-0000	FRAME COMP.	1
14-2		E0350-9FA0-0000	ENGINE SUSPENSION ASSY.	1
14-3		E2202-9FA0-0000	BUSH	2
14-4		E0111-9FA0-0000	WASHER	2
14-5		E0351-9FA0-0000	ENGINE SET BOLT(M14×230)	1
14-6		I5611-14200	HEX. FLANGE NUT, SAFETY	1
14-7		E0353-9FA0-0000	RUBBER, ENGINE SUSPENSION	2
14-8		I0149-10030	BOLT,FLANGE	2
14-9	N	E0101-5EA0-0000	FRAME NUMBER PLATE	1
14-10		H750A-5BA1-0000	NAIL, PULL	2
14-11		E0105-9FA0-0000	BRACKET, SEAT	1
14-12		I0149-06016	FLANGE BOLT, HEX.	4
14-13		E0110-9FA0-0000	SUPPORT BAR, TAIL LIGHT	1
14-14		I0149-06010	BOLT,FLANGE	2
14-15		E0112-9FA0-0000	WASHER	2
14-16		I0119-06802	BOLT, HEX.	2
14-17		E0113-9FA0-0000	RUBBER, SEAT	1

15. SWINGARM



ITEM	AVAIL	PART NO.	NAME	QTY
15			SWING ARM	
15-1		E0200-9FA0-0000	ARM, SUSPENSION, L.H.	1
15-2		E0210-9FA0-0000	ARM, SUSPENSION, R.H.	1
15-3		E0201-9FA0-0000	BUSH, ARM SUSPENSION	4
15-4		I0149-10080	FLANGE BOLT, HEX.	2
15-5		I5611-10200	HEX. FLANGE NUT, SAFETY	3
15-6		E220A-9FA0-0010	SWING ARM SUB ASSY.	1
15-6-1		E2202-9FA0-0000	BUSH	2
15-7		E0351-9FA0-0000	ENGINE SET BOLT(M14×230)	1
15-8		I5611-14200	HEX. FLANGE NUT, SAFETY	1
15-9		I0149-10085	BOLT,FLANGE	1
15-10		I0149-10060	BOLT,FLANGE	1
15-11		I0149-10030	BOLT,FLANGE	1
15-12		E0111-9FA0-0000	WASHER	2
15-13		E0112-9FA0-0000	WASHER	2
15-14		I3003-14028	WASHER(14.5×28.5×3t)	2


16 FENDER



ITEM	AVAIL	PART NO.	NAME	QTY
16			FENDER	
16-1		F4300-9FA0-0700	FRONT FENDER(SILVER)	1
16-1		F4300-9FA0-0100	FRONT FENDER(YELLOW)	1
16-1		F4300-9FA0-1500	FRONT FENDER(GREEN)	1
16-2		H3500-9FA0-0100	REAR FENDER(YELLOW)	1
16-2		H3500-9FA0-1500	REAR FENDER(GREEN)	1
16-2		H3500-9FA0-0700	REAR FENDER(SILVER)	1
16-3		F4301-9FA0-0800	FRONT CENTRAL COVER (BLACK)	1
16-3		F4301-9FA0-0200	FRONT CENTRAL COVER(RED)	1
16-3		F4301-9FA0-0900	FRONT CENTRAL COVER (BROWN)	1
16-4		H3520-9FA0-1000	FOOTREST, PLACTIC PART, RIGHT	1
16-5		H3620-9FA0-1000	FOOTREST, PLACTIC PART, LEFT	1
16-6		E3205-9FA0-0200	COVER, HANDLE BAR(RED)#1795C	1
16-6		E3205-9FA0-0800	COVER, HANDLE BAR(BLACK)	1
16-6		E3205-9FA0-0900	COVER, HANDLE BAR(BROWN)	1
16-7		E0117-9EA0-0000	SCREW, TRUSS	11
16-8		I5611-06200-0G	HEX. FLANGE NUT, SAFETY	11
16-9		F4312-9FA0-0000	NUT, PLACTIC	4
16-10		I0109-5BA1-0000	BOLT FLANGE	4
16-11		I7507-08020	BOLT, HEXAGON HEAD(M8×20)	4
16-12		I5611-08200	HEX. FLANGE NUT, SAFETY	2
16-13		I0050-06010	BOLT, SOCKET	1
16-14		H7101-9FA0-9000	STICKER,WARNING PASSENGER	1
16-15		H7102-9FA0-9000	STICKER,WARNING (Y12)	1
16-16		H7107-5EB0-0000	EMBLEM, E-TON LOGO(SILVER)	1
16-17		I8310-06025	SCREW(M6×25)	4
16-18		F4315-9FA0-0000	ISOLATE FOAM	1
16-19		F4309-5EA0-0000	STICKER, MFD.	1
16-20		H7110-9FA0-0900	STICKER,CENTRAL COVER (SIERRA)(BROWN)	1
16-20		H7110-9FA0-0700	STICKER,CENTRAL COVER (SIERRA)(SILVER)	1
16-20		H7110-9FA0-0200	STICKER,CENTRAL COVER (SIERRA)(RED)	1
16-21		H7108-5EB0-0000	STICKER, E-TON	1
16-22		H7102-5EA1-0000	STICKER,CE	1


16-23		H7103-9FA0-0000	STICKER, EMBLEM,DXL-90(LIFT)	1
16-24		H7104-9FA0-0000	STICKER,DXL-90(RIGHT)	1
16-25		H7101-5EA1-0000	STICKER WARNING,CE	1

17. SEAT



ITEM	AVAIL	PART NO.	NAME	QTY
17			SEAT	
17-1		G7200-9FA0-0200	SEAT ASSY. (RED)	1
17-1		G7200-9FA0-0800	SEAT ASSY. (BLACK)	1
17-1		G7200-9FA0-0900	SEAT ASSY. (BROWN)	1
17-1-1		G7201-9FA0-0000	SEAT FIXER ASSY.	1
17-1-1-1		G7221-9FA0-0000	SEAT FIXER	2
17-1-1-2		G7226-9FA0-0000	LEVEL ASSY.	1
17-1-1-3		G7227-9FA0-0000	LEVEL SPRING	1
17-1-1-4		G7230-9FA0-0000	E CLIP	1
17-1-1-5		G7231-9FA0-0000	SELF-TAPPING SCREW(M4×16)	4
17-1-1-6		G7232-9FA0-0000	PLUG RUBBER	6


18. FUEL TANK, OIL TANK




ITEM	AVAIL	PART NO.	NAME	QTY
18			FUEL TANKOIL TANK	
18-1		A7500-9FA0-0000	FUEL TANK ASSY.	1
18-2		A7520-5EA0-0000	MANUAL FUEL CUP	1
18-3		A7501-9FA0-0000	FUEL TUBE	1
18-3-1		A7516-5EA0-0000	CLIP(A)	1
18-3-2		A7517-5EA0-0000	CLIP(B)	1
18-4		I8506-05016	SCREW PAN	2
18-5		A7510-9FA0-1000	FUEL FILTER ASSY.	1
18-5-1		A7519-FIA0-1000	FUEL FILTER	1
18-5-2		A7516-5EA0-0000	CLIP(A)	4
18-5-3		A7514-9FA0-0000	FUEL TUBE (A)	1
18-5-4		A7515-9FA0-0000	FUEL TUBE (B)	1
18-6		A7622-9FA0-0000	RUBBER PAD, FUEL TANK CAP	1
18-7		A762A-9FA0-0000	FUEL TANK CAP ASSY.	1
18-7-1		A7620-9FA0-0000	FUEL TANK CAP	1
18-7-1		A7620-9FA0-0000	FUEL TANK CAP	1
18-7-2		A7621-9FA0-0000	TUBE, RUBBER	1
18-7-2		A7621-9FA0-0000	TUBE, RUBBER	1
18-8		I7507-06225	BOLT, HEX.	2
18-9		E5100-9FA0-0000	OIL TANK ASSY.	1
18-10		E5105-9FA0-0000	OIL TANK CAP ASSY.	1
18-11		E5108-9FA0-0000	RUBBER PAD	1
18-12		I0119-06821	BOLT, HEX.	4
18-13		A7502-9FA0-0000	SPARE TUBE	1
18-13-1		A7516-5EA0-0000	CLIP(A)	1
18-13-2		A7517-5EA0-0000	CLIP(B)	1

19. SUSPENSION

ITEM	AVAIL	PART NO.	NAME	QTY
19			SUSPENSION	
19-1		E1105-9FA0-0000	SUSPENSION, FRONT	2
19-2		E2400-9FA0-0000	SUSPENSION, REAR	1
19-3		I0102-10040B	FLANGE BOLT, HEX.	6
19-4		I9900-25019	PIN, SPLIT	6




20. FRONT WHEEL




ITEM	AVAIL	PART NO.	NAME	QTY
20			FRONT WHEEL	
20-1		D471A-9FA0-0000	FRONT WHEEL ASSY.,LEFT	1
20-1-1		D4710-5EB0-0000	WHEEL TIRE(19×7-8)	1
20-1-2		D4602-5EB0-0000	WHEEL RIM	0
20-2		D471B-9FA0-0000	FRONT WHEEL ASSY.,RIGHT	1
20-2-1		D4710-5EB0-0000	WHEEL TIRE(19×7-8)	1
20-2-2		D4602-5EB0-0000	WHEEL RIM	0
20-3		D4610-9FA0-0000	BRAKE DRUM, FRONT	2
20-3-1		D4612-9FA0-0000	BOLT,STUD	8
20-4		I6100-6202Z	OUTER BEARING(15×35×11)	2
20-5		I6100-6203Z	INNER BEARING(17×40×12)	2
20-6		D4624-9FA0-0000	OUTER OIL SEAL(20×35×7)	2
20-7		D4623-9FA0-0000	INNER OIL SEAL(22×40×7)	2
20-8		D4621-9FA0-0000	OUTER SPACER (15.5×20×8)	2
20-9		D4620-9FA0-0000	INNER SPACER(17×24×8)	2
20-10		D4611-9FA0-0000	GASKET, ANTIDUST	2
20-11		D4611-9EA0-0000	FLANGE NUT, HEX.	8
20-12		I9905-14200	WASHER	2
20-13		I5500-14100	CASTLE NUT	2
20-14		I9900-30032	COTTER PIN(1/8"×11/4")	2
20-15		D4609-9FA0-0000	RUBBER CAP	2

21. REAR WHEEL




ITEM	AVAIL	PART NO.	NAME	QTY
21			REAR WHEEL	
21-1		D471A-9EA0-0000	REAR WHELL ASSY.,LEFT	1
21-1-1		D4710-5EB0-0000	WHEEL TIRE(19×7-8)	1
21-1-2	N	D4601-5EB0-0000	WHEEL RIM	1
21-2		D471B-9EA0-0000	WHEEL TIRE ASSY(RIGHT)	1
21-2-1		D4710-5EB0-0000	WHEEL TIRE(19×7-8)	1
21-2-2	N	D4601-5EB0-0000	WHEEL RIM	1
21-3		D2705-9EA0-1000	SHAFT CONNECTER WITH BOLTS	2
21-4		D4611-9EA0-0000	FLANGE NUT, HEX.	8
21-5		D2309-5EA0-0000	WASHER	2
21-6		I9905-14200	WASHER	2
21-7		I5500-14100	CASTLE NUT	2
21-8		I9900-30032	COTTER PIN(1/8"×11/4")	2
21-9		D4609-5EA0-0001	RUBBER CAP	2

22. FRONT BRAKE




ITEM	AVAIL	PART NO.	NAME	QTY
22			FRONT BRAKE	
22-1		D5351-9FA0-0000	FRONT BRAKE PANEL COMP., LEFT	1
22-2		D5352-9FA0-0000	FRONT BRAKE PANEL COMP., RIGHT	1
22-3		I0050-06010	BOLT, SOCKET	6
22-4		D5120-9FA0-0000	FRONT BRAKE SHOE COMP. (80)	2
22-5		D5141-FIA0-0000	FRONT BRAKE ARM CAM	2
22-6		D5149-5EA0-0000	FELT SEAL	2
22-7		D5410-9FA0-0000	FRONT BRAKE ARM, LEFT	1
22-8		D5411-9FA0-0000	FRONT BRAKE ARM,RIGHT	1
22-9		I0020-05024	BOLT HEX.	2
22-10		E5450-9FA0-0000	CABLE, FRONT BRAKE	2
22-10-1		E5452-9FA0-0000	NUT,ADJUSTING	2

23 REAR BRAKE




ITEM	AVAIL	PART NO.	NAME	QTY
23			REAR BRAKE	
23-1		D2310-5EA0-0000	BEARING SEAT ASSY., REAR WHEEL AXLE	1
23-2		D2311-5EA0-0000	SPACER	1
23-3		I6100-6006ZZ	BEARING, BALL RADIAL	2
23-4		D2315-9EA0-0000	OIL SEAL(38×55×10)	1
23-5		D2314-5EA0-0000	OIL SEAL(14×20×4)	2
23-6		D3141-5EA0-0000	BRAKE ARM CAM, REAR	1
23-7		D3410-5EA0-0000	BRAKE ARM, REAR	1
23-8		D3120-5EA0-0000	REAR BRAKE SHOE COMP.(130)	1
23-9		D3145-5EA0-0000	REAR BRAKE INDICATOR	1
23-10		D3419-5EA0-0000	REAR RETURN SPRING	1
23-11		I0020-06030	BOLT	1
23-12		I0141-12025-01	FLANGE BOLT, HEX.	4
23-13		D2313-9EA0-0000	OIL SEAL	1
23-14		D3615-FIA0-0000	DRUM COVER, REAR	1
23-15		D2315-FIA0-0000	OIL SEAL	1
23-16		I8557-06012	SCREW WASHER	6
23-17		D0114-9EA0-0000	SPACER	1
23-18		D3610-9FA0-1000	REAR BRAKE DRUM	1
23-19		D3611-5EA0-0000	GASKET, REAR DRUM COVER	1
23-20		D2316-5EA0-0000	DRAIN PIPE ASSY.	1
23-21		D2319-5EA0-0000	PLUG, PURGE HOLE	1
23-22		E3450-9FA0-0000	CABLE, REAR BRAKE	1
23-22-1		E3453-5EA0-0000	CIRCULAR CYLINDER	1
23-22-2		E3454-9FA0-0000	NUT,ADJUSTING	1
23-23		I0149-08030	FLANGE BOLT, HEX.	1
23-24		I5611-08200	HEX. FLANGE NUT, SAFETY	1

24 HANDLER BAR




ITEM	AVAIL	PART NO.	NAME	QTY
24			HANDLE BAR	
24-1		E3100-9FA0-0000	HANDLE BAR ASSY.	1
24-2		E3180-9FA0-0010	LEVER ASSY., (RIGHT)	1
24-2-1		E3181-9FA0-0000	LEVEL,RIGHT	1
24-2-2		E319A-5EA0-0000	LEVEL ACCELERATE	1
24-3		E3170-5EB0-0010	LEVEL ASSY., LEFT	1
24-3-1		E3171-5EB0-0000	LEVEL,LEFT	1
24-3-2		E3174-5EA0-0000	BARKE SWITH ASSY.	1
24-4		E3166-5EA0-0000	GRIP	2
24-5		E3112-5EA0-0000	BOTTOM,HANDLE BAR CLAMP	2
24-6		E3110-5EA0-0000	CAP,HANDEL BAR CLAMP(L)	1
24-7		E3111-5EA0-0000	CAP,HANDEL BAR CLAMP(R)	1
24-8		I0050-06025	BOLT, SOCKET	4
24-9		I5611-10200	HEX. FLANGE NUT, SAFETY	2

25. BUMPER, FOOTRESR




ITEM	AVAIL	PART NO.	NAME	QTY
25			BUMPERFOOTREST	
25-1		E0700-9FA0-0000	FOOTREST BAR,LEFT ASSY	1
25-2		E0706-9FA0-0000	FOOTREST BAR,RIGHT ASSY	1
25-3		C510C-FIA0-0000	RUBBER PAD	8
25-4		I0149-10020	BOLT,FLANGE	8
25-5		I8310-06020-01	SCREW, OVAL	8
25-6		I0149-08016	FLANGE BOLT, HEX.	4
25-7		E0410-9FA0-0000	REAR BAR ASSY.	1
25-8		E0707-9FA0-0000	PLUG, FOOTREST PLATE	4

26. CHAIN, REAR WHEEL AXLE




ITEM	AVAIL	PART NO.	NAME	QTY
26			CHAINREAR WHEEL AXLE	
26-1		D0100-9FA0-0000	DRIVE CHAIN ASSY. (#520,48)	1
26-1-1		D0104-9EA0-0000	DRIVE CHAIN LINK(#520)	1
26-2		D0101-9FA0-0000	PROTECT COVER	1
26-3		D2301-9EA0-0000	REAR AXLE	1
26-4		D0110-9EA0-0000	DRIVE CHAIN ASSY.(28T)	1
26-4-1		D0111-9EA0-0000	SPROCKET HOLDER, REAR	1
26-4-1		D0111-9EA0-0000	SPROCKET HOLDER, REAR	1
26-4-2		D1111-9EA0-0000	GEAR(28T)	1
26-4-2		D1111-9EA0-0000	GEAR(28T)	1
26-4-3		D2706-9EA0-0000	BOLT	4
26-4-3		D2706-9EA0-0000	BOLT	4
26-4-4		I5611-10200	HEX. FLANGE NUT, SAFETY	4
26-4-4		I5611-10200	HEX. FLANGE NUT, SAFETY	4
26-5		D2302-9EA0-0000	NUT, HEX.	2
26-6		D0120-FIA0-0001	CHAIN ADJUSTER COMP.	1
26-7		I0149-08016	FLANGE BOLT, HEX.	6
26-8		D0510-9FA0-0000	DRIVE CHAIN COVER	1

27 STEERING




ITEM	AVAIL	PART NO.	NAME	QTY
27			STEERING	
27-1		E3200-9FA0-0000	SHAFT ASSY., STEERING	1
27-2		I3102-5AC0-0000	OIL SEAL	1
27-3		I4510-32000	C CLIP EX 32	1
27-4		I6100-6002ZZ	BEARING (6002ZZ)	1
27-5		D4620-5EA0-0000	COLLAR	1
27-6		E3201-5EA0-0000	OIL SEAL	1
27-7		I5611-14200	HEX. FLANGE NUT, SAFETY	1
27-8		I9900-25019	PIN, SPLIT	7
27-9		E0258-9FA0-0000	STEERING TIE-ROD ASSY., LEFT	1
27-9-1		E0251-9FA0-0000	BOLT,STUD	1
27-9-2		E0255-FIA0-0000	UNIVERSAL JOINT(L)	1
27-9-3		E0256-FIA0-0000	UNIVERSAL JOINT(R)	1
27-9-4		E0252-5EA0-0000	NUT (R)	1
27-9-5		E0253-5EA0-0000	NUT (L)	1
27-10		E0259-9FA0-0000	STEERING TIE-ROD ASSY., RIGHT	1
27-10-1		E0251-9FA0-0000	BOLT,STUD	1
27-10-2		E0255-FIA0-0000	UNIVERSAL JOINT(L)	1
27-10-3		E0256-FIA0-0000	UNIVERSAL JOINT(R)	1
27-10-4		E0252-5EA0-0000	NUT (R)	1
27-10-5		E0253-5EA0-0000	NUT (L)	1
27-11		E0205-9FA0-0000	KNUCKLE, LEFT ASSY	1
27-11-1		D5142-9FA0-0000	SLEEVE,FRONT BRAKE ARM CAM	2
27-11-2		D5144-9FA0-0000	FRONT BRAKE DRUM	2
27-11-3		E0206-9FA0-0000	OIL LINER(17)	4
27-12		E0215-9FA0-0000	KNUCKLE, RIGHT ASSY	1
27-13		E0211-9FA0-0000	SLEEVE	2
27-14		E0203-9FA0-0000	CAP	4
27-15		I5701-10105-0A	FLANGE BOLT, HEX.	2
27-16		I5611-10200	HEX. FLANGE NUT, SAFETY	6
27-17		I6600-06000	GREASE VALVE	2
27-18		E0209-5EA0-9000	CAP, GREASE VALVE	2
27-19		E3225-5EA0-0000	PU LINER	1
27-20		E3202-9FA0-0000	HOLDER, STEERING COLUMN	2
27-21		E3203-9FA0-0000	FIX PLATE, STEERING SHAFT	1
27-22		I0020-08055	BOLT(M8×55)	2

28 ELECTRICAL PARTS




ITEM	AVAIL	PART NO.	NAME	QTY
28			ELECTRICAL EQUIPMENT	
28-1		C2100-9FA0-0000	MAIN WIRE ASSY.	1
28-1-1		C2010-5EA0-0000	FUSE(7A)	1
28-2		C1500-9FA0-0000	BATTERY	1
28-3		C1501-9FA0-0000	FOAM STICK, BATTERY	2
28-4		C1502-9FA0-0000	RUBBER CLAMP, BATTERY(89L)	1
28-5		C5010-9FA0-0000	MAIN SWITCH	1
28-5-1		C5013-9FA0-0000	MATERIAL KEY (RIGHT CUT)	1
28-5-1		C5013-9FA0-0000	MATERIAL KEY (RIGHT CUT)	1
28-5-2		C5018-9FA0-0000	MATERIAL KEY (LEFT CUT)	1
28-6		C5200-9FA0-0000	LEVER HOLDER ASSY., LEFT	1
28-7		I8556-06020	SCREW, PAN HEAD	2
28-8		C5031-9FA0-0000	TAIL LIGHT, LEFT	1
28-8-1		C5004-9FA0-0000	BULB(8w)	1
28-9		C5032-9FA0-0000	TAIL LIGHT, RIGHT	1
28-9-1		C5004-9FA0-0000	BULB(8w)	1
28-10		I7707-04016	TAPPING SCREW, TRUSS	4
28-11		H3936-5AA0-0000	WIRE CLAMP	1
28-12		C8110-5BA0-E000	HORN	1
28-13		I8506-05016	SCREW PAN	2
28-14		I8556-06012	SCREW PAN	2
28-15		C0510-B00-0000	IGNITION COIL ASSY.	1
28-16		C0410-B00-7000	C.D.I. UNIT ASSY.	1
28-17		C1600-B00-0000	RECTIFIER COMP REGULATE	1
28-18		C5400-B00-0000	RESISTOR ASSY	1
28-19		C5850-B00-0000	STARTER RELY ASSY.	1
28-21		C5030-FIB0-0001	HAED LIGHT	2
28-21-1		C5003-FIB0-0000	BULB,HEADLIGHT(12v 20w)	2
28-22		I5800-08300	NUT, HEX.	2
28-23		I9901-08100	WASHER, SPRING	2
28-24		C5033-9FB0-0000	HEAD CAMP MAIN WIRE	1

29.FRONT&REAR PACK ASSY.



ITEM	AVAIL	PART NO.	NAME	QTY
29			FRONT&REAR PACK ASSY	
29-1		E041A-9FB0-0000	REAR RACK ASSY	1
29-1-1		E0411-9FB0-0000	REAR RACK	1
29-1-2		F4001-9FB0-0000	REAR CARRIER COVER	1
29-1-2-1		H7113-9FB0-0000	CARRIER COVER,STICKER	1
29-1-2-2		H7117-FIB0-0000	REAR REFLECTOR,STICKER	2
29-1-3		I0149-06823	SCREW	6
29-2		E041B-9FB0-0000	FRONT RACK ASSY.	1
29-2-1		E0400-9FB0-0000	BUMPER FRONT ASSY.	1
29-2-2		E0413-9FB0-0000	FRONT CARRIER	1
29-2-3		F3000-9FB0-0000	FRONT BUMPER COVER	1
29-2-4		F4000-9FB0-0000	FRONT CARRIER COVER	1
29-2-4-1		H7113-9FB0-0000	CARRIER COVER,STICKER	1
29-2-4-2		H7116-FIB0-0000	FRONT REFLECTOR,STICKER	2
29-2-5		I0149-06823	SCREW	10
29-2-6		I0149-08016	FLANGE BOLT, HEX.	4
29-3		I0149-08016	FLANGE BOLT, HEX.	2
29-4		I0149-08040	BOLT,FLANGE	5
29-5		I5611-08200	HEX. FLANGE NUT, SAFETY	5
29-6		E0402-9FA0-0000	COLLAR,BUMPER	5
29-7		H9510-9FB0-0000	PACKING CASE	1

30.PACKING CASE,EXTERNAL



ITEM	AVAIL	PART NO.	NAME	QTY
30			PACKING CASEEXTERNAL	
30-1		H9500-9FA0-0000	PACKING CASE,EXTERNAL	1
30-2	N	H9900-9FA0-0000	OWNER'S MANUAL	1
30-7		H9020-9FA0-0000	TOOL SET	1
30-8		H9021-9FA0-0000	WIRE CLAMP	1
30-9		H9010-5EA0-0000	TOOL BOX	1
30-10		I0149-06016	FLANGE BOLT, HEX.	2
30-11		I4071-06080	NUT, FLANGE CHECK(M6)	2
30-12		H9022-5EA0-0000	PRESSURE METER	1

No picture.

ITEM	AVAIL	PART NO.	NAME	QTY
40			CYLINDER+PISTON TOP END KIT	
40-1		A21AA-B00-0000	CYLINDER+PISTON TOP END KIT	1
40-1-1		A2100-B00-0000	CYLINDER	1
40-1-1		A2100-B00-0000	CYLINDER	1
40-1-2		A2191-B00-0000	GASKET CYLINDER	1
40-1-2		A2191-B00-0000	GASKET CYLINDER	1
40-1-3		A2251-B00-0000	GASKET CYLINDER HEAD	1
40-1-3		A2251-B00-0000	GASKET CYLINDER HEAD	1
40-1-4		A3011-B00-0000	PISTON RING SET (50)	1
40-1-4		A3011-B00-0000	PISTON RING SET (50)	1
40-1-5		A3101-B00-0000	PISTON	1
40-1-5		A3101-B00-0000	PISTON	1
40-1-6		A3111-B00-0000	PIN PISTON (12×40)	1
40-1-6		A3111-B00-0000	PIN PISTON (12×40)	1
40-1-7		I4601-12000	CLIP, PISTON PIN	2
40-1-7		I4601-12000	CLIP, PISTON PIN	2
40-1-8		I1100-1215165	BEARING, NEEDLE	1
40-1-8		I1100-1215165	BEARING, NEEDLE	1
40-1-9		A8291-5AA0-0000	GASKET (34×25.4×4)	1
40-1-9		A8291-5AA0-0000	GASKET (34×25.4×4)	1

No picture.

ITEM	AVAIL	PART NO.	NAME	QTY
41			MAINTENANCE KIT 1 (MJ # 85)	
41-01		A6100-B00-A001	MAINTENANCE KIT 1 (MJ # 85)	1
41-01-1		KAC30310	V CLIP	1
41-01-01		KAC30310	V CLIP	1
41-01-2		KAC30220	JET NEEDLE ASSY. (#3CR1)	1
41-01-02		KAC30220	JET NEEDLE ASSY. (#3CR1)	1
41-01-3		KAC30110	THROTTLE VALVE (#3.0)	1
41-01-03		KAC30110	THROTTLE VALVE (#3.0)	1
41-01-4		A6105-B00-0000	AIR FLOW ADJUSTING SCREW	1
41-01-04		A6105-B00-0000	AIR FLOW ADJUSTING SCREW	1
41-01-5		KAC30840	THROTTLE ADJUSTING SCREW	1
41-01-05		KAC30840	THROTTLE ADJUSTING SCREW	1
41-01-6		KAC30510	SLOW JET (*20)	1
41-01-06		KAC30510	SLOW JET (*20)	1
41-01-7		KAC30610	NEEDLE JET (*426 E-1)	1
41-01-07		KAC30610	NEEDLE JET (*426 E-1)	1
41-01-8		KAC30410	MAIN JET # 85	1
41-01-08		KAC30410	MAIN JET # 85	1
41-01-9		A6118-B00-0000	O-RING	1
41-01-09		A6118-B00-0000	O-RING	1
41-01-10		A6119-B00-0000	NEEDLE VALVE SEAT	1
41-01-10	N	A6119-B00-0000	NEEDLE VALVE SEAT	1
41-01-11		KAC31120	NEEDLE VALVE ASSY.	1
41-01-11	N	KAC31120	NEEDLE VALVE ASSY.	1
41-01-12		KAC30910	CHAMBER O-RING	1
41-01-12		KAC30910	CHAMBER O-RING	1

No picture.

ITEM	AVAIL	PART NO.	NAME	QTY
42			MAINTENANCE KIT 2 (MJ # 85)	
42-01		A6100-B00-A002	MAINTENANCE KIT 2 (MJ # 85)	1
42-01-1		KAC30310	V CLIP	1
42-01-01		KAC30310	V CLIP	1
42-01-2		KAC30220	JET NEEDLE ASSY. (#3CR1)	1
42-01-02		KAC30220	JET NEEDLE ASSY. (#3CR1)	1
42-01-3		KAC30110	THROTTLE VALVE (#3.0)	1
42-01-03		KAC30110	THROTTLE VALVE (#3.0)	1
42-01-4		A6105-B00-0000	AIR FLOW ADJUSTING SCREW	1
42-01-04		A6105-B00-0000	AIR FLOW ADJUSTING SCREW	1
42-01-5		KAC30840	THROTTLE ADJUSTING SCREW	1
42-01-05		KAC30840	THROTTLE ADJUSTING SCREW	1
42-01-6		KAC30510	SLOW JET (*20)	1
42-01-06		KAC30510	SLOW JET (*20)	1
42-01-7		KAC30610	NEEDLE JET (*426 E-1)	1
42-01-07		KAC30610	NEEDLE JET (*426 E-1)	1
42-01-8		KAC30410	MAIN JET # 85	1
42-01-08		KAC30410	MAIN JET # 85	1
42-01-9		A6118-B00-0000	O-RING	1
42-01-09		A6118-B00-0000	O-RING	1
42-01-10		A6119-B00-0000	NEEDLE VALVE SEAT	1
42-01-10	N	A6119-B00-0000	NEEDLE VALVE SEAT	1
42-01-11		KAC31120	NEEDLE VALVE ASSY.	1
42-01-11	N	KAC31120	NEEDLE VALVE ASSY.	1
42-01-12		KAC30910	CHAMBER O-RING	1
42-01-12		KAC30910	CHAMBER O-RING	1
42-01-13		KAC31210	FLOAT ASSY	1
42-01-13		KAC31210	FLOAT ASSY	1
42-01-14		KAC31410	DRAIN SCREW	1
42-01-14		KAC31410	DRAIN SCREW	1