

PARTS CATALOGUE

VECTOR ST 250 VXL-250 ST



CONTENTS


PARTS ITEM:

- 01 HEAD COVER
- 02 CYLINDER HEAD COMP
- 03 CYLINDER ASSY.
- 04 L COVER ASSY.
- 05 L CRANK CASE
- 06 R CRANK CASE
- 07 R CASE COVER
- 08 MOVABLE DRIVE FACE
- 09 CRANK SHAFT
- 10 AC GEN FLYWHEEL
- 11 BALANCE SHAFT
- 12 MISSION CASE
- 13 OIL PUMP ASSY.
- 14 CYL. HEAD SIDE COVER ASSY.
- 15 DRIVEN PULLEY SET
- 16 A.I.C.V. ASSY.
- 17 CARBURETOR ASSY
- 18 GEAR SHAFT LEVER, SAFETY SWITCH
- 19 AIR CLEANER
- 20 CABLE
- 21 WATER COOLER
- 22 ENGINE
- 23 MUFFLER
- 24 FRAME
- 25 FENDER
- 26 SWING ARM
- 27 SEAT

- 28 FUEL TANK
- 29 SUSPENSION
- 30 FRONT WHEEL
- 31 REAR WHEEL
- 32 FRONT BRAKE SYSTEM
- 33 REAR BRAKE SYSTEM
- 34 HANDLE BAR
- 35 BUMPER, FOOTREST
- 36 REAR WHEEL AXLE
- 37 STEERING
- 38 ELECTRICAL EQUIPMENT
- 39 PACKING CASE,EXTERNAL
- 40 ACCESSORIES
- 41 SERVICE KITS,BRAKE CALLIPER
- 42 TOOL


N & sign meaning: not available to sale

1. HEAD COVER




ITEM	AVAIL	PART NO.	NAME	QTY
01			HEAD COVER	
01-1		A2391-HMA-0000	HEAD COVER PACKING	1
01-2		A2301-HMA-0000	CYLINDER HEAD COVER	1
01-3		A230A-HMA-0000	CYL. HEAD COVER ASSY.	1
01-4		A8610-HKA-0000	REED VALVE COMP	1
01-5		I0002-HMA-0000	HEAD COVER BOLT	4
01-6		I6001-06016-00	FLANGE BOLT SH 6X16	2

2. CYLINDER HEAD COMP




ITEM	AVAIL	PART NO.	NAME	QTY
02			CYLINDER HEAD COMP	
02-1		A2200-RB1-0000	CYLINDER HEAD COMP	1
02-2		A2209-H6B-9000	VALVE STEM SEAL	4
02-3		A4100-RB1-0000	CAM SHAFT COMP	1
02-4	N	A4431-RFA-0000	IN. VALVE ROCKER ARM	1
02-5		A443A-RFA-0000	IN. VALVE ROCKER ARM ASSY.	1
02-6	N	A4441-RFA-0000	EX. VALVE ROCKER ARM	1
02-7		A444A-RFA-0000	EX. VALVE ROCKER ARM ASSY.	1
02-8		A4451-HMA-0000	ROCKER ARM SHAFT	2
02-9		A4457-HMA-0000	CAM SHAFT SETTING PLATE	1
02-10		A4711-HMA-0000	IN. VALVE	2
02-11		A4721-HMA-0000	EX. VALVE	2
02-12		A4751-HMA-0000	VALVE OUTER SPG.	4
02-13		A4761-HMA-0000	VALVE INNER SPG.	4
02-14		A4771-M8Q-0000	VALVE SPRING RETAINER	4
02-15		A4777-KN7-6700	VALVE SPRING SEAT	4
02-16		A4781-M9Q-0000	VALVE COTTER	8
02-17		C7750-PC1-0000	THERMO UNIT ASSY	1
02-18		A8647-RB1-0000	AIR PIPE COMP	1
02-19		A8654-N14-0000	AIR PIPE GASKET	2
02-20		A9300-HMA-0000	THERMOSTAT ASSY.	1
02-21		A9315-KJ9-0000	THERMOSTAT COVER COMP	1
02-22		I0012-HLK-0000	TAPPET ADJUSTING SCREW	4
02-23		I0206-HLK-0000	TAPPET ADJUSTING SCREW NUT	4
02-24		I0442-HMA-0000	SEALING WASHER 10.5MM	4
02-25		I4050-10080	FLANGE NUT 10MM	4
02-26		I6001-06014-08	FLANGE BOLT 6*14	1
02-27		I6001-06016-00	FLANGE BOLT SH 6X16	6
02-28		I6001-06090-00	FLANGE SH BOLT 6*90	2
02-29		I8000-RB1-0000	SPARK PLUG (CR8E)	1

3. CYLINDER ASSY.




ITEM	AVAIL	PART NO.	NAME	QTY
03			CYLINDER ASSY.	
03-1		A2100-HMA-0000	CYLINDER COMP	1
03-2		A210A-HMA-0000	CYLINDER ASSY.	1
03-3		A2191-HMA-0000	CYLINDER GASKET	1
03-4		A4510-HMA-0000	CAM CHAIN TENSIONER	1
03-5		A4520-H6T-0000	TENSIONER LIFTER ASSY.	1
03-6		A4522-H6T-0000	ADJUSTER BOLT	1
03-7		A4523-M9Q-0000	TENSIONER LIFTER GASKET	1
03-8		A4524-H6T-0000	O-RING	1
03-9		A4525-H6T-0000	ADJUSTER SPRING	1
03-10		A4531-KJ9-0000	CAM CHAIN TENSIONER PIVOT	1
03-11		A4610-HMA-0000	CAM CHAIN GUIDE	1
03-12		I0001-M9Q-0000	FLANGE SHF BOLT 6*22	2
03-13		I4301-12200	DOWEL PIN 12*20	4
03-14		A2251-HMA-0000	CYLINDER HEAD GASKET	1

4. L COVER ASSY.




ITEM	AVAIL	PART NO.	NAME	QTY
04			L COVER ASSY.	
04-1	N	A1341-RB2-0000	L COVER	1
04-2		A1342-RB1-0000	L. COVER PLATE	1
04-3		A1343-RB1-0000	L. COVER PLATE GASKET	1
04-4		A1346-HMA-0000	L. BEARING SETTING PLATE	1
04-5		A134A-RB2-0000	L COVER ASSY.	1
04-6		A1371-HMA-0000	BERING STAY COLLAR	1
04-7		A137A-HMA-0000	BEARING STAY COLLAR ASSY.	1
04-8		A1395-RB1-0000	L COVER GASKET	1
04-9		I1303-HMA-0000	O-RING 26.5*2.0	2
04-10		I3500-05012-0H	SCREW PAN M5*12	4
04-11		I4301-08140	KNOCK PIN	2
04-12		I6001-06012-00	SH. FLANGE BOLT 6*12	2
04-13		I6001-06035-00	FLANGE SH BOLT 6X35	9
04-14		I6150-60060-10	RADIAL BALL BEARING 6006LLU	1

5. L CRANK CASE




ITEM	AVAIL	PART NO.	NAME	QTY
05			L CRANK CASE	
05-1		A1200-RB1-0000	L CRANK CASE COMP	1
05-2		A1205-RB1-0000	SETTING PLATE	2
05-3		A1221-RB1-0000	MISSION BREATHER TUBE	1
05-4		A1230-RA1-0000	DRAIN TUBE ASSY.	1
05-5		A5772-500-0000	TUBE CLIP	1
05-6		C575A-RB1-0200	CHANGE SW. SET	1
05-6-1		C5759-RB1-0200	CHANGE SW. COMP	1
05-6-2		C5751-RB1-0200	CHANGE SW. COLLAR	2
05-7		I0032-HMA-0000	CYLINDER STUD BOLT B	2
05-8		I0051-RB1-0000	SPRING FIXED CATCH	1
05-9		I0052-RB1-0000	SCREW FIXING	1
05-10	N	I2800-12000	DRAIN PLUG BOLT 12MM	1
05-11		I4109-12000	DRAIN PLUG WASHER 12MM	1
05-12		I4109-14000	DRAIN PLUG WASHER 14MM	1
05-13		I6001-06012-00	SH. FLANGE BOLT 6*12	3
05-14		I6001-06018-00	FLANGE BOLT SH 6*18	2
05-15		I6001-06050-00	FLANGE SH BOLT 6X50	4
05-16		I6001-06070-00	SH. FLANGE BOLT 6*70mm	7
05-17		I6211-12000	STELL BALL 12	1
05-18		A1206-RB1-0000	L. CASE SEALING BOLT	1
05-19		I0403-RB1-0000	L. CASE SEALING WASHER	1
05-20		I4101-06800	PLAIN WASHER 6mm	2

6. R CRANK CASE




ITEM	AVAIL	PART NO.	NAME	QTY
06			R CRANK CASE	
06-1		A1100-RB1-0000	R CRANK CASE COMP	1
06-2		A1191-RB1-0000	CRANK CASE GASKET	1
06-3		I6001-06010-08	FLANGE BOLT SH 6*10	1
06-4		A4151-HMA-0000	CAM CHAIN SETTING PLATE	1
06-5		B8101-RB1-0000	STAR. REDUCTION GEAR COMP	1
06-6		B8102-RB1-0000	STA. REDUCTION GEAR SHAFT	1
06-7		C1200-RB1-0000	START MOTOR ASSY.	1
06-8		I6001-06022-00	FLANGE BOLT SH 6*22	2
06-9		I4301-08140	KNOCK PIN	2
06-10		I0031-HMA-0000	CYLINDER STUD BOLT A	2
06-11		I6001-06055-00	BOLT FLANGE SH 6*55	2
06-12		A5200-HMA-0000	OIL RELIEF VALVE ASSY.	1
06-12-1		A5201-HMA-0000	OIL RELIEF VALVE	1
06-12-2		A5203-HMA-0000	OIL RELIEF SPRING	1
06-12-3		I6211-14000	STEEL BALL 14	1
06-12-4		A5202-HMA-0000	OIL RELIEF WASHER	1
06-12-5		I4520-12000	IN. CIRCLIP 12mm	1

7. R CASE COVER




ITEM	AVAIL	PART NO.	NAME	QTY
07			R CASE COVER	
07-1		A1330-RB1-0000	R CASE COVER COMP	1
07-2		A5713-HMA-0000	OIL BAFFLE PLATE	1
07-3		I6001-06070-00	SH. FLANGE BOLT 6*70mm	1
07-4		A236A-V02-0000	TAPPET ADJ HOLE CAP ASSY.	1
07-5		A5421-M9Q-0000	OIL FILTER SCREEN	1
07-6		A5426-M9Q-0000	OIL FILTER SCREW SPG.	1
07-7		A565A-RB1-0000	OIL LEVEL GAUGE ASSY.	1
07-8		A9215-HLA-0000	WATER PUMP IMPELLER	1
07-9		A9217-H9A-3000	MECHANICAL SEAL	1
07-10		A9229-H9A-0000	WATER PUMP GASKET	1
07-11		A922A-HLA-0000	WATER PUMP COVER COMP	1
07-12		A9231-HMA-0000	WATER PUMP SHAFT	1
07-13		A9502-RB1-0000	WATER HOSE	1
07-14		A9505-KS6-7000	WATER HOSE CLAMP A	2
07-15		I008A-H9A-0000	ACG. CAP ASSY. 14MM	1
07-16		I0423-KJ9-0000	WASHER 7.2*13*1.2	1
07-17		I1001-KJ9-0000	RADIAL BALL BRG.6901	1
07-18		I1205-KF0-0000	OIL SEAL 12*20*5	1
07-19		I1302-M9Q-0000	O-RING 30.8MM	1
07-20	N	I1307-M9Q-0000	O-RING 18*3	1
07-21		I4301-08140	KNOCK PIN	2
07-22		I4520-26000	CIR CLIP IN 26	1
07-23		I6001-06022-00	FLANGE BOLT SH 6*22	2
07-24		I6001-06032-00	FLANGE SH BOLT 6X32	2
07-25		I6001-06045-00	FLANGE BOLT SH 6*45	10
07-26		I6100-60000-00	RADIAL BALL BRG. 6000	1

8.MOVABLE DRIVE FACE




ITEM	AVAIL	PART NO.	NAME	QTY
08			MOVABLE DRIVE FACE	
08-1		B2132-HMA-0000	SLIDE PIECE	3
08-2		B2131-HMA-0000	RAMP PLATE	1
08-3		A0001-RB1-0000	WEIGHT ROLLER COMP	1
08-3-1		B2121-RB1-0000	WEIGHT ROLLER	6
08-4		B2110-HMA-0000	MOVABLE DRIVE FACE COMP.	1
08-5		B2105-HMA-0000	DRIVE FACE BOSS	1
08-6		B2000-RB1-0000	MOVABLE DRIVE FACE ASSY.	1
08-7		B2102-HMA-0000	DRIVE FACE	1
08-8		I0401-KJ9-0000	THRUST WASHER 14*28*2	1
08-9		I0201-KR8-0000	FLANGE NUT 14MM	1

9. CRANK SHAFT




ITEM	AVAIL	PART NO.	NAME	QTY
09			CRANK SHAFT	
09-1		A3000-RB1-0000	CRANKSHAFT COMP	1
09-2		A3010-HMA-0000	PISTON RING SET	1
09-3		A3101-RB1-0000	PISTON	1
09-4		A3111-HMA-0000	PISTON PIN	1
09-5	N	A3201-RB1-0000	CONNECTING ROD	1
09-6	N	A320A-RB1-0000	CONN. ROD ASSY.	1
09-7	N	A3331-RB1-3000	BALANCE SHAFT DRIVE GEAR	1
09-8	N	A3371-HMA-3000	R CRANK SIDE PLATE	1
09-9	N	A3381-HMA-3000	CRANK PIN	1
09-10		I0601-HMA-0000	PISTON PIN CLIP 17MM	2
09-11		I0701-HB6-0000	WOODRUFF KEY 25*14*4	1
09-12	N	I1004-RB1-0000	CONN. ROD BRG. PK32*41*17.8	1
09-13		I1201-HMA-3000	OIL SEAL TC27*42*7	1
09-14		I6100-62070-10	RADIAL BALL BRG. 6207	1
09-15	N	I1002-RB1-0000	RADIAL BALL BRG. 6306	1

10. AC GEN FLYWHEEL




ITEM	AVAIL	PART NO.	NAME	QTY
10			AC GEN FLYWHEEL	
10-1		A1394-RB1-0000	R COVER GASKET	1
10-2		B8110-HMA-0000	STARTING CLUTCH GEAR COMP	1
10-3		B812A-HMA-0000	ONE WAY CLUTCH ASSY.	1
10-4		C110A-RB1-0000	AC GEN FLYWHEEL SET	1
10-5		C1110-RB1-0000	FLYWHEEL COMP.	1
10-6		C1120-RB2-0000	STATOR COMP	1
10-7		I0201-KR8-0000	FLANGE NUT 14MM	1
10-8		I0401-KJ9-0000	THRUST WASHER 14*28*2	1
10-9		I1202-HMA-0000	OIL SEAL TC12*22*5	1
10-10		I2101-05012-0H	HEX BOLT 5*12mm	2
10-11		I6001-06040-00	SH. FLANGE BOLT 6*40	3
10-12		I4301-08140	KNOCK PIN	2
10-13		I4520-32000	CIRCLIP	1
10-14		I6140-62013-10	RADIAL BALL BRG. 6201LUC3	1
10-15		I0157-F3G-0000	SOCKET BOLT 8X20	3

11. BALANCE SHAFT



ITEM	AVAIL	PART NO.	NAME	QTY
11			BALANCE SHAFT	
11-1		A3300-RB1-0000	BALANCE SHAFT COMP	1
11-2	N	A3301-RB1-0000	BALANCE SHAFT	1
11-3	N	A3302-RB1-0000	WAVE WASHER 28.3*36*1	1
11-4	N	A3332-RB1-3000	BALANCE SHAFT DRIVE GEAR A	1
11-5	N	A3333-RB1-0000	BALANCE SHAFT DRIVE GEAR B	1
11-6	N	A3334-RB1-0000	BALANCE SHAFT DRIVE GEAR SPRING	4
11-7	N	A3337-RB1-0000	WASHER 28.3*47.5*1.4	1
11-8	N	A3338-RB1-0000	WASHER 28.3*36*1	1
11-9	N	I4510-28000	CIR CLIP EX 28MM	1
11-10		I6100-62040-10	RADIAL BALL BRG. 6204	2


12. MISSION CASE



ITEM	AVAIL	PART NO.	NAME	QTY
12			MISSION CASE	
12-1		B1200-RB1-0100	MISSION CASE	1
12-2		B1201-RB1-0000	INNER COVER STAY A	1
12-3		B1395-RB1-0000	MISSION CASE GASKET	1
12-4		B3411-RB1-0000	DRIVE SHAFT	1
12-5		B3420-RB1-0000	COUNTER SHAFT ASSY.	1
12-6		B3421-RB1-0000	COUNTER SHAFT	1
12-7		B3422-RB1-0000	COUNTER GEAR A	1
12-8		B3423-RB1-0000	COUNTER GEAR B COMP	1
12-9		B3424-RB1-0000	BUSH 20*13	1
12-10		B3425-RB1-0000	SPACER	1
12-11		B3430-RB1-0100	FINAL SHAFT COMP	1
12-12		B3431-RB1-3100	FINAL SHAFT	1
12-13		B3432-RB1-3000	FINAL GEAR	1
12-14		B3475-RB1-0000	CLIDING CLAW	1
12-15		B3500-RB1-0000	REVERSE SHAFT COMP	1
12-16		B3800-RB1-0000	DRIVE SPROCKET	1
12-17		B3801-RB1-0000	DRIVE SPROCKET FIXING PLATE	1
12-18		B4211-RB1-0000	SHIFT FORK	1
12-19		B4241-RB1-0000	SHIFT FORK SHAFT	1
12-20		B4300-RB1-0000	SHIFT DRUM COMP	1
12-21		B4319-R02-0000	GEAR INDICATION DRILL SPG	1
12-22		B4323-R02-0000	GEAR INDICATION DRILL	1
12-23		B4610-RB1-0000	GEAR SHIFT SPINDLE COMP	1
12-24		I0401-RB1-0000	PLAIN WASHER 25MM	2
12-25		I0402-RB1-0000	PLAIN WASHER 20MM	2
12-26		I0454-RB1-0000	THRUST WASHER 20.5*38*2	1
12-27		I0474-M9Q-0000	WASHER 8MM	1
12-28		I1003-RB1-0000	NEEDLE BRG. HK2016	1
12-29		I1103-X17-0000	NEEDLE BRG. K25X29X10	1
12-30		I1209-RCA-0000	OIL SEAL TC 25*52*7	1
12-31		I1202-RB1-0000	OIL SEAL TC14*26*6	1
12-32		I1204-HMA-0000	OIL SEAL TC25*40*7	1
12-33		I2101-06010-0H	HEX BOLT 6*10	2
12-34	N	I2800-12000	DRAIN PLUG BOLT 12MM	1
12-35		I4109-12000	DRAIN PLUG WASHER 12MM	1
12-36		I4301-10140	KNOCK PIN	2
12-37		I4510-25000	CIRCLIP EX	2
12-38		I4520-52000	CIRCLIP IN	1


12-39		I5701-08012-00	BOLT FLANGE 8*12	1
12-40		I5701-08040-00	FLANGE BOLT 8*40	9
12-41		I6100-62040-10	RADIAL BALL BRG. 6204	3
12-42		I6100-63040-10	RADIAL BALL BRG. 6304	1
12-43		I6100-63053-00	RADIAL BALL BRG. 6305	1
12-44		I6100-62050-00	RADIAL BALL BEARING 6205	1

13. OIL PUMP ASSY.




ITEM	AVAIL	PART NO.	NAME	QTY
13			OIL PUMP ASSY.	
13-1		A5100-HMA-0000	OIL PUMP ASSY.	1
13-2		A5133-HMA-0000	OIL PUMP DRIVEN SPROCKET	1
13-3		A5141-HMA-0000	OIL PUMP CHAIN 48L	1
13-4	N	I1101-HMA-0000	ROLLER 2.5*11.8	1
13-5		I3500-06025-0H	PAN SCREW 6X25	2
13-6		I4510-10000	CIR CLIP EX 10	1

14. CYL. HEAD SIDE COVER ASSY.




ITEM	AVAIL	PART NO.	NAME	QTY
14			CYL. HEAD SIDE COVER ASSY.	
14-1		A230A-RB1-0000	CYL. HEAD SIDE COVER ASSY.	1
14-2		A2314-RB1-0000	BREATHER TUBE	1
14-3		A4105-A31-0000	CAM SPROCKET	1
14-4		A4105-X01-0000	CAM SPROCKET WASHER	1
14-5		A4108-M36-0000	CENTRIFUGAL DISK	1
14-6		A4401-HMA-0000	CAM CHAIN 100L	1
14-7		I0083-X01-0000	LOCK BOLT 6MM	2
14-8		I6001-06018-00	FLANGE BOLT SH 6*18	3

15. DRIVEN PULLEY SET




ITEM	AVAIL	PART NO.	NAME	QTY
15			DRIVEN PULLEY SET	
15-1		B2101-HMA-0000	CLUTCH OUTER	1
15-2		B2300-HMA-0000	DRIVE PLATE ASSY.	1
15-8		B3010-HMA-0000	DRIVEN PULLEY ASSY	1
15-9		B3100-RB1-0000	DRIVE BELT	1
15-10		B3200-HMA-0000	DRIVEN FACE ASSY.	1
15-11	N	B3210-HMA-0000	DRIVEN FACE COMP.	1
15-12		B3220-HMA-0000	MOVABLE DRIVEN FACE COMP.	1
15-13		B3225-HMA-0000	ROLLER GUIDE PIN	4
15-14		B3226-HMA-0000	GUIDE ROLLER	4
15-15		B3233-HMA-0000	DRIVEN FACE SPRING	1
15-16		B3237-HMA-0000	SEAL COLLAR	1
15-17	N	B3238-HMA-0000	SPRING COLLER	1
15-18		I0201-KR8-0000	FLANGE NUT 14MM	1
15-19		I0202-HMA-0000	SPECIAL NUT 36MM	1
15-20		I0401-KJ9-0000	THRUST WASHER 14*28*2	1
15-21	N	I0602-HMA-0000	IN. CIRCLIP	1
15-22	N	I1006-HMA-3000	NEEDLE BEARING HKS25*32*14	1
15-23	N	I1007-HMA-3000	RADIAL BALL BRG. 6903LU	1
15-24		I1211-HMA-0000	OIL SEAL TC41*48*4	2
15-25		I1305-HMA-0000	O-RING 47*2.0	2

16. A.I.C.V. ASSY




ITEM	AVAIL	PART NO.	NAME	QTY
16			A.I.C.V. ASSY.	
16-1		A865A-LRA0-0000	AICV ASSY	1
16-1-1	N	A8650-HMA-0000	AICV	1
16-1-2	N	A8811-N14-000	A.I.A.C SETTING BAND	1
16-1-3	N	A8657-RB1-0000	A.I.C.V. INLET PIPE JOINT TUBE ASSY.	1
16-2		A7401-LRA0-0000	STAY AICV	1
16-3		I0149-06012	FLANGE BOLT, HEX.	2
16-4		A8655-LRA0-0000	AICV JOINT TUBE	1
16-5		A8656-LRA0-0000	AICV-REED VALVE JOINT TUBE	1

17. CARBURETOR ASSY




ITEM	AVAIL	PART NO.	NAME	QTY
17			CARBURETOR ASSY	
17-1		A6100-RB1-0000	CARB. ASSY.	1
17-1-1		K3500-076-0000	FLOAT CHAMBER BODY ASSY	1
17-1-1		K3500-076-0000	FLOAT CHAMBER BODY ASSY	1
17-1-1-1		A6157-RB2-0000	BOWL GASKET	1
17-1-1-1		A6157-RB2-0000	BOWL GASKET	1
17-1-1-1		A6157-RB2-0000	BOWL GASKET	1
17-1-1-2		S391-0030	DRAIN SCREW ASSY	1
17-1-1-2		S391-0030	DRAIN SCREW ASSY	1
17-1-1-2		S391-0030	DRAIN SCREW ASSY	1
17-1-2		D1310-850-0000	FLOAT COMP	1
17-1-2		D1310-850-0000	FLOAT COMP	1
17-1-3		A230-846-2000	COVER, DIAPHRAGM	1
17-1-3		A230-846-2000	COVER, DIAPHRAGM	1
17-1-4		W1711-300-990	COIL SPRING	1
17-1-4		W1711-300-990	COIL SPRING	1
17-1-5		A20A-106H-9900	DIAPHRAGM COMP	1
17-1-5	N	A20A-106H-9000	DIAPHRAGM COMP	1
17-1-6		A6075-KG8-901	O-RING	1
17-1-6		A6075-KG8-901	O-RING	1
17-1-7		N4460-28B00	ADJUST SCREW	1
17-1-7		N4460-28B00	ADJUST SCREW	1
17-1-8		A300-KG8H-901	COMPRESSION COIL SPRING	1
17-1-8		A300-KG8H-901	COMPRESSION COIL SPRING	1
17-1-9		A795-LG8H-901	WASHER	1
17-1-9		A795-LG8H-901	WASHER	1
17-1-10		W9576-0100	STOP SCREW	1
17-1-10		W9576-0100	STOP SCREW	1
17-1-11		A300-KG8H-Q01	COMPRESSION COIL SPRING	1
17-1-11		A300-KG8H-Q01	COMPRESSION COIL SPRING	1
17-1-12		K5020-RB1-0000	THROTTLE VALVE ASSY	1
17-1-12		K5020-RB1-0000	THROTTLE VALVE ASSY	1
17-1-13		K590-076-0000	TOP ASSY	1
17-1-13		K590-076-0000	TOP ASSY	1
17-1-14		A290-B97-2000	COIL SPRING	1
17-1-14		A290-B97-2000	COIL SPRING	1
17-1-15		A0100-43FH-9000	NEEDLE JET	1
17-1-15		A0100-43FH-9000	NEEDLE JET	1
17-1-16		K6165-M47-0000	NEEDLE JET HOLDER ASSY	1


17-1-16		K6165-M47-0000	NEEDLE JET HOLDER ASSY	1
17-1-17		D1424-KAG-0000	SLOW JET	1
17-1-17		D1424-KAG-0000	SLOW JET	1
17-1-18		I4608-RB2-0000	O-RING	1
17-1-18		I4608-RB2-0000	O-RING	1
17-1-19		K7850-076-0000	RUBBER PIPE ASSY	1
17-1-19		K7850-076-0000	RUBBER PIPE ASSY	1
17-1-20		A305-491H-990	TORSION COIL SPRING	1
17-1-20		A305-491H-990	TORSION COIL SPRING	1
17-1-21		A1130-HB7H-6000	CHOKE LVEVR	1
17-1-21		A1130-HB7H-6000	CHOKE LVEVR	1
17-1-22		D1141-A63-010	STAY PLATE	1
17-1-22		D1141-A63-010	STAY PLATE	1
17-1-23		I3892-04008-10	WASHER SCREW	1
17-1-23		I3892-04008-10	WASHER SCREW	1
17-1-24		A6119-MZ2-6000-K2	STAY PLATE	1
17-1-24		A6119-MZ2-6000-K2	STAY PLATE	1
17-1-25		A6155-ZG8-L100	FLOAT VALVE COMP	1
17-1-25		A6155-ZG8-L100	FLOAT VALVE COMP	1
17-1-26		I3892-04010-18	WASHER SCREW	2
17-1-26		I3892-04010-18	WASHER SCREW	2
17-1-27		I3892-04016-18	WASHER SCREW	3
17-1-27		I3892-04016-18	WASHER SCREW	3
17-1-28		A6124-RB2-0000	FLOAT PIN	1
17-1-28		A6124-RB2-0000	FLOAT PIN	1
17-2		I4050-06000	NUT FLANGE 6MM	2
17-3		A711A-RB1-0000	INLET PIPE ASSY.	1
17-3-1		I1308-HMA-0000	O-RING 34*2.0	1
17-4		I6001-06022-00	FLANGE BOLT SH 6*22	2
17-5		I6001-06025-00	FLANGE BOLT SH 6*25	2




ITEM	AVAIL	PART NO.	NAME	QTY
18			GEAR SHAFT LEVER, SAFETY SWITCH	
18-1		B464A-LRA0-0000	SHAFT COMP ROD	1
18-1-1		B4641-LRA0-0000	ROD SHIFT	1
18-1-2		B4622-GJA0-0000	FIXED SUPPORT CATCH	1
18-1-3		B4643-V30-0000	FIXED SUPPORT ROD SHIFT	1
18-1-4		I4104-08515	WASHER	2
18-1-5		B4644-GJA0-0000	SPRING ROD SHIFT	1
18-1-6		I4201-46195	SPLIT PIN	2
18-1-7		B4645-V30-0000	PIN ROD SHIFT	1
18-1-8		I5701-06025-0C	FLANGE BOLT, HEX.	1
18-1-9		I4540-1201A	CIRCLIP	1
18-1-10		B4646-LRA0-0000	SHIFT TRANSLATOR	1
18-2		B4642-LRA0-0000	HANDLE PLASTICS ASSY.	1
18-3		I3600-05015-0G	NO:009 SCREW FLAT	1
18-4		B4648-LRA0-0000	SHIFT TIE-ROR	1
18-4-1		I2900-08320-0C	STUD BOLT	1
18-4-2		I5013-08030C	BALL JOINT R	1
18-4-3		I5013-08030C-L	BALL JOINT L	1
18-4-4		I4001-081C0	NUT HEX	1
18-4-5		I4001-081C0-L	NUT HEX	1
18-5		I0149-08016	FLANGE BOLT, HEX.	2
18-6		I6800-08030-0C	SOCKET BOLT	2
18-7		I5611-08200	HEX. FLANGE NUT, SAFETY	1
18-8		B4612-V30-0000	ARM GEAR SHIFT	1
18-9		I0149-06035	FLANGE BOLT, HEX.	1




ITEM	AVAIL	PART NO.	NAME	QTY
19			AIR CLEANER	
19-1		A7200-RB2-0000	AIR/C ASSY	1
19-1-1		A7202-RB1-0000	AIR/C ELEMENT ASSY	1
19-1-2		A7214-RB1-0000	AIR/C COVER SEAL	1
19-1-3	N	A7230-RB1-0000	AIR/C CASE	1
19-1-4		A7231-RB1-0000	AIR/C COVER	1
19-1-5		A7232-RB1-0000	AIR/C COVER CLAMP	4
19-1-6	N	A7253-RB1-0000	AIR/C CONN TUBE	1
19-1-7		A7255-B1C-0000	A/C CONNECTING TUBE BAND	1
19-1-8		A7255-RB1-0000	AIR/C INLET DUCT	1
19-1-9	N	A7257-RB2-0100	AIR/C CASE DUCT	1
19-1-10		A7370-M9Q-0000	BREATHER TUBE PLUG	1
19-1-11		A7371-M9Q-0000	BREATHER TUBE CLIP	1
19-1-12		I0652-M8Q-0000	AIR/C CONN TUBE BAND 46	1
19-1-13		I0652-RB1-0000	AIR/C CONN TUBE BAND 58	1
19-1-14		I3893-05010-08	SCREW WASHER (5x10)	1
19-1-15		I5002-80000	TUBE CLIP C12	1
19-1-16		I5003-23010-60	V TUBE (8x12x100)	1
19-2		I0111-06020	FLANGE BOLT	4




ITEM	AVAIL	PART NO.	NAME	QTY
20			CABLE	
20-1		A7910-LRA0-0000	CABLE THROTTLE	1
20-2		A7920-LRA0-0000	CABLE ,AIR CUT	1




ITEM	AVAIL	PART NO.	NAME	QTY
21			WATER COOLER	
21-1		A900A-LRA0-0000	RADIATOR SET	1
21-1-1		A9010-LRA0-0000	RADIATOR COMP	1
21-1-2		A9005-LRA0-0000	SHROUD ASSY	1
21-1-3		I5801-06012-08	FLANGE BOLT 6x12	3
21-1-4		A9039-LRA0-0000	FILLER NECK	1
21-1-5	N	I5002-40850-00	TUBE CLIP D8.5	1
21-1-6		A9124-LRA0-0000	RADIATOR HOSE A	1
21-1-7	N	I5002-40730-00	TUBE CLAMP D7.3	1
21-2		A9125-LRA0-0000	RADIATOR HOSE OSE	1
21-2-1		A8657-LRA0-0000	FASTENER	1
21-3		C7760-LRA0-0000	THRMO. SW. ASSY	1
21-4		I0119-06030	BOLT, HEX.	4
21-5		A9111-LRA0-0000	RADIATOR FILLER CAP	1
21-6		I0149-06012	FLANGE BOLT, HEX.	1
21-7		A9121-LRA0-0000	RAD. INLET HOSE	1
21-8		A9123-LRA0-0000	RAD. OUTLET HOSE	1
21-9		A910A-LRA0-0000	RESERVE TANK ASSY	1
21-9-1		A9101-LRA0-0000	RESERVE TANK	1
21-9-2		A9108-LRA0-0000	RESERVE TANK OUTLET HOSE	1
21-9-3		A9104-LRA0-0000	TANK RESERVE CAP	1
21-9-4		A9109-LRA0-0000	RESERVE TANK HOSE	1
21-10		A9401-LRA0-0000	SHROUD RADIATOR ASSY	1
21-10-1		A9400-LRA0-0000	SHROUD RADIATOR	1
21-10-2		E0415-LRA0-0000	FTLTER NET	1
21-11		I0119-06821	BOLT, HEX.	2




ITEM	AVAIL	PART NO.	NAME	QTY
22			ENGINE	
22-1		AA000-RB2-0000	ENG ASSY	1
22-2		B0100-LRA0-0000	CVT INLET TUBE	1
22-3		A1346-LRA0-0000	CVT OUTLET TUBE	1
22-4		A1349-LRA0-0000	CVT OUTLET TUBE BAND	1
22-5		H3936-5AA0-0000	WIRE CLAMP	2
22-6		D0105-RB2-0000	CHAIN PROTECTO	1
22-7		I0119-05071	BOLT, HEX.	3



ITEM	AVAIL	PART NO.	NAME	QTY
23			MUFFLER	
23-1		A8000-LRA0-0000	MUFFLER ASSY.	1
23-1-1		A8310-RB2-3000	EXH. MUFFLER COMP	1
23-1-2		A832A-RB2-0000	EXH. PIPE ASSY	1
23-1-2-1		A8302-LRC0-0000	HEAT INSULATION BOARD	1
23-1-2-2		I5801-06011-3A	BOLT FLANGE	2
23-2		A8291-RB2-0000	EXH. PIPE GASKET	1
23-3		I0043-HMA-0000	CAP NUT 8MM	2
23-4		I0149-08012	FLANGE BOLT, HEX.	2




ITEM	AVAIL	PART NO.	NAME	QTY
24			FRAME	
24-1		E0100-LRC0-1A02	FRAME FRONT	1
24-2		E0110-LRA0-1A01	FRAME REAR	1
24-3	N	H7501-LRC0-0000	VIN PLATE	1
24-4		H750A-5BA1-0000	NAIL, PULL	2
24-5		I0149-10022	SCREW,FLANGE	4
24-6		I5701-12100-0C	BOLT FLANGE, HEX.	2
24-7		I5601-12200	FLANGE NUT, SAFETY	3
24-8		I5801-10016-0HA	BOLT, FLANGE (M10x16)	4
24-9		I6100-6002ZZ	BEARING (6002ZZ)	1
24-10		I4510-32000	C CLIP EX 32	1
24-11		E0101-LRA0-0000	LEFT ENG.BRACKET	1
24-12		E0102-LRA0-0000	RIGHT ENG.BRACKET	1
24-13		I5701-12160-0C	FLANGE BOLT, HEX.	1
24-14		E0170-LRA0-0000	SEAT STEY	1
24-15		I0149-06012	FLANGE BOLT, HEX.	9
24-16		E0105-LRA0-0000	UPPER SUPPORT BAR,FRONT FENDER	1
24-16-1		E0707-5EE0-0000	RUBBER PLUG	2
24-17		E0106-LRA0-0000	LOWER SUPPORT BAR,FRONT FENDER	1
24-18		E0107-LRA0-0000	SUPPORT BAR,REAR FENDER	1
24-19		C6602-LRA0-0000	HOLDER RELAY	1
24-20		I0149-08016	FLANGE BOLT, HEX.	2
24-21		H1104-BCA0-0000	COLLAR	2
24-22		F0703-BCA0-0000	DAMPER	2
24-23		I0119-06821	BOLT, HEX.	2
24-24		E0111-LRA0-0000	STAY HEAD LAMP	2
24-25		I3903-312B0	TRUSS	4
24-26		D3211-LRA0-0000	CLIP	4




ITEM	AVAIL	PART NO.	NAME	QTY
25			FENDER	
25-1		F4300-LRA0-0700	FR. FENDER ASSY(SILVER)	1
25-1		F4300-LRA0-0800	FR. FENDER ASSY(BLACK)	1
25-1		F4300-LRA0-5400	FR. FENDER ASSY(BLUE)	1
25-1		F4300-LRA0-1E00	FR. FENDER ASSY(ORANGE)	1
25-2		I0119-06821	BOLT, HEX.	8
25-3		F4301-LRA0-0000	FRONT CENTRAL COVER	1
25-4		F4302-LRA0-0001	REAR CENTRAL COVER	1
25-5		I8310-FIA0-0000	PLASTIC SCREW	10
25-6		F4303-LRA0-0000	FR NT SIDE COVER R	1
25-7		F4304-LRA0-0000	FR NT SIDE COVER L	1
25-8		E0117-9EA0-0000	SCREW, TRUSS	10
25-9		I5611-06200-0G	HEX. FLANGE NUT, SAFETY	6
25-10		H3500-LRA0-0700	REAR FENDER (SILVER)	1
25-10		H3500-LRA0-5400	REAR FENDER (BLUE)	1
25-10		H3500-LRA0-0800	REAR FENDER (BLACK)	1
25-10		H3500-LRA0-1E00	REAR FENDER (ORANGE)	1
25-11		I5900-06160	SPRING NUT	12
25-12		H3511-LRA0-0000	OIL CAP PLUG	1
25-13		H3520-LRA0-0000	FOOTREST,RIGHT	1
25-14		H3620-LRA0-0000	FOOTREST,LEFT	1
25-15		F4400-LRA0-0700	RIGHT SIDE COVER(SILVER)	1
25-15		F4400-LRA0-0800	RIGHT SIDE COVER(BLACK)	1
25-16		F4500-LRA0-0800	LEFT SIDE COVER(BLACK)	1
25-16		F4500-LRA0-0700	LEFT SIDE COVER(SILVER)	1
25-17		C7203-LRA0-0000	SPEEDOMETER BRACKET	1
25-18		C7204-LRC0-0000	BRACKET HANDLE COVER L	1
25-19		C7205-LRC0-0000	BRACKET HANDLE COVER R	1
25-20		F4316-LRA0-0000	FRONT FENDER ADORNMENT COMP	1
25-20-1	N	F4305-LRA0-0000	FRONT FENDER ADORNMENT	1
25-20-2	N	C3143-LRA0-0000	POSITION LAMP ASSY	1
25-20-3		I3903-312B0	TRUSS	4
25-21		B4627-LRA0-0000	SHIFT STAY	1
25-22		H750A-5BA1-0000	NAIL, PULL	6
25-23		I3893-06016-0H	SCREW WASHER	2
25-24		H7129-FIA0-0000	STICKER,INDICATE GEAR	1
25-25		H7100-LRC0-0000	LABEL TTRE	1
25-26		I8556-06012	SCREW PAN	2


25-27		H7127-LRC0-0700	STICKER ,REAR FENDER(SILVER)	1
25-27		H7127-LRC0-1E00	STICKER ,REAR FENDER(ORANGE)	1
25-27		H7127-LRC0-0800	STICKER ,REAR FENDER(BLACK)	1
25-28		H7103-LRC0-0800	STICKER ,VECTOR 250 L(BLACK)	1
25-28		H7103-LRC0-1E00	STICKER ,VECTOR 250 L(ORANGE)	1
25-28		H7103-LRC0-0700	STICKER ,VECTOR 250 L(SILVER)	1
25-29		H7108-5BA2-0700	STICKER E-TON(SILVER)	1
25-29		H7108-5EB0-0000	STICKER, E-TON	1
25-30		H7131-FIB0-0000	STICKER,POWER SUPPLY	1
25-31		E3205-LRC0-0000	FRONT COVER,HANDLE BAR	1
25-32		I3903-312B0	TRUSS	7
25-33		E3206-LRA0-0001	REAR COVER,HANDLE BAR	1
25-34		E0701-GJA0-0000	FOOTREST BAR	2
25-35		I0149-06016	FLANGE BOLT, HEX.	4
25-36		C3140-RA1-0000	POSITION LAMP ASSY	1
25-37		I0119-06802	BOLT, HEX.	2
25-40		F4315-LRF0-0000	LAGGING ALUMINUM FOIL	1




ITEM	AVAIL	PART NO.	NAME	QTY
26			SWING ARM	
26-1		E020A-LRA0-0701	ARM,SUSPENSION,L.U.ASSY(SILVE)	1
26-1-1		E0200-LRA0-0700	ARM,SUSPENSION,L.U.(SILVE)	1
26-1-2		A1203-LRA0-0000	BUSH,ARM SUSPENSION	2
26-1-3		E0230-LRA0-0001	BALL JOINT	1
26-1-4		I4510-30000	CIRCLIP	1
26-2		E021A-LRA0-0701	ARM,SUSPENSION,R.U.ASSY(SILVE)	1
26-2-1		E0210-LRA0-0700	ARM,SUSPENSION,R.U.(SILVE)	1
26-2-2		A1203-LRA0-0000	BUSH,ARM SUSPENSION	2
26-2-3		E0230-LRA0-0001	BALL JOINT	1
26-2-4		I4510-30000	CIRCLIP	1
26-3		E022A-LRA0-0701	ARM,SUSPENSION,LOWER ASSY(SILVE)	2
26-3-1		E0220-LRA0-0701	ARM,SUSPENSION,LOWER (SILVE)	2
26-3-2		A1203-LRA0-0000	BUSH,ARM SUSPENSION	4
26-3-3		E0230-LRA0-0001	BALL JOINT	2
26-3-4		I4510-30000	CIRCLIP	2
26-4		I5701-10060-0A	FLANGE BOLT, HEX.	8
26-5		I4011-121H0	CASTLE NUT(M12)	4
26-6		I4201-46325	SPLIT PIN	4
26-7		D3211-LRA0-0000	CLIP	2
26-8		E2200-LRA0-0000	SWING ARM SUB	1
26-9		I1600-4T30203	BEARING	2
26-10		I1201-LRA0-0000	OIL SEAL40*20*8	2
26-11		E2201-LRA0-0000	SWING RAM RIGHT BOLT	1
26-12		E2203-LRA0-0000	SWING RAM LEFT BOLT	1
26-13		I0231-LRA0-0000	NUT SWING ARM	1
26-14		E2202-LRA0-0000	RUBBER SLEEVE	1
26-15		E2204-LRA0-0000	WASHER	2
26-16		D4611-9EA0-0000	FLANGE NUT, HEX.	8
26-17		E2205-LRA0-0000	PLUG	2
26-18		I0109-5BA1-0000	BOLT FLANGE	1
26-19		H7106-FIA0-0000	WARNING STICKER , CHAIN	1




ITEM	AVAIL	PART NO.	NAME	QTY
27			SEAT	
27-1		G7200-LRC0-0000	SEAT ASSY	1
27-1-1		G7201-LRA0-0000	SEAT FASTENER	2
27-2		G7212-5EA0-0000	RUBBER DAMPER	2



ITEM	AVAIL	PART NO.	NAME	QTY
28			FUEL TANK	
28-1		A7500-LRC0-0000	FUEL TANK COMP	1
28-2		A7514-LRA0-0000	FUEL TUBE	1
28-2-1		A7516-5EA0-0000	CLIP(A)	2
28-3		A762A-LRA0-0000	FUEL TANK CAP ASSY.	1
28-3-1		A7620-LRA0-0000	FUEL TANK CAP	1
28-3-2		A7621-LRA0-0000	BREATHE TUBE	1
28-4		A7510-FIA0-0000	FUEL TANK RUBBER PAD	4
28-5		A7511-FIA0-0000	RUBBER INSULATOR	4
28-6		I0119-06030	BOLT, HEX.	4
28-7		A6701-LRA0-0000	FUEL COCK ASSY	1
28-7-1		A7519-LRA0-0000	FILTER FUEL	1
28-8		A6702-LRA0-0000	FUEL COCK COVER	1
28-9		C780A-LRA0-0000	METER FUEL LEVER	1
28-10		I0200-50160	CROSS BOLT, HEX.	4
28-11		A751B-FIA0-0000	VACUUM TUBE COMP	1
28-11-1		A7518-FIA0-0000	CLIP	2
28-11-1		A7518-FIA0-0000	CLIP	2
28-12		I8506-04016	SCREW,PAN HEAD	1




ITEM	AVAIL	PART NO.	NAME	QTY
29			SUSPENSION	
29-1		E1105-LRA0-0000	SUSPENSION, FRONT	2
29-2		E2400-LRA0-0000	SUSPENSION, REAR	1
29-3		I2811-10050-0G	NO:001 BOLT FLANGE	2
29-4		I0102-10048	FLANGE BOLT, HEX.	4
29-5		D4611-9EA0-0000	FLANGE NUT, HEX.	4
29-6		I0468-12006	PIN	2




ITEM	AVAIL	PART NO.	NAME	QTY
30			FRONT WHEEL	
30-1		D471A-FIE0-0S00	FRONT WHEEL ASSY.,LEFT(ON ROAD,STEEL 10*5.5)	1
30-1		D471A-LRF0-00NA	FRONT WHEEL ASSY.,LEFT(ON ROAD ,ALUMINUM)(10*5.5)	1
30-1		D471A-LRF0-00FA	FRONT WHEEL ASSY.,LEFT(OFF ROAD ,ALUMINUM)(10*5.5)	1
30-1		D471A-LRC0-0SFS	FRONT WHEEL ASSY.,LEFT(OFF ROAD, STEEL 10*5.5)	1
30-1-1		D4710-FIE0-0000	WHEEL TIRE (ON ROAD)	1
30-1-1		D4710-LRA0-0000	WHEEL TIRE (OFF ROAD)	1
30-1-1		D4710-LRA0-0000	WHEEL TIRE (OFF ROAD)	1
30-1-1		D4710-FIE0-0000	WHEEL TIRE (ON ROAD)	1
30-1-2		D4601-FIC0-0S00	WHEEL RIM 10*5.5"	1
30-1-2		D4601-FIC0-0S00	WHEEL RIM 10*5.5"	1
30-1-2		D4601-FIC0-0S00	WHEEL RIM 10*5.5"	1
30-1-2		D4601-FIC0-9700	WHEEL RIM(ALUMINUM)(10"x5.5)	1
30-2		D471B-LRF0-00NA	FRONT WHEEL ASSY.,RIGHT(ON)(ALUMINUM)	1
30-2		D471B-LRF0-00FA	FRONT WHEEL ASSY.,RIGHT(OFF ROAD ,ALUMINUM 10*5.5)	1
30-2		D471B-FIE0-0S00	FRONT WHEEL ASSY.,RIGHT(ON ROAD, STEEL 10*5.5)	1
30-2		D471B-LRC0-0SFS	FRONT WHEEL ASSY.,RIGHT(OFF ROAD,STEEL 10*5.5")	1
30-2-1		D4710-FIE0-0000	WHEEL TIRE (ON ROAD)	1
30-2-1		D4710-LRA0-0000	WHEEL TIRE (OFF ROAD)	1
30-2-1		D4710-FIE0-0000	WHEEL TIRE (ON ROAD)	1
30-2-1		D4710-LRA0-0000	WHEEL TIRE (OFF ROAD)	1
30-2-2		D4601-FIC0-0S00	WHEEL RIM 10*5.5"	1
30-2-2		D4601-FIC0-0S00	WHEEL RIM 10*5.5"	1
30-2-2		D4601-FIC0-0S00	WHEEL RIM 10*5.5"	1
30-2-2		D4601-FIC0-9700	WHEEL RIM(ALUMINUM)(10"x5.5)	1
30-3		D461A-LRA0-0000	WHEEL HUB ASSY	2
30-3-1		D4610-LRA0-0000	WHEEL HUB	2
30-3-2		D4612-GJA0-0000	BOLT	8
30-3-3		I6100-6203LLU	BEARING(6203-LLU)	2
30-3-4		I1307-24040-10	OIL SEAL	2
30-3-5		D4620-LRA0-0000	INNER SPACER	2
30-3-6		I6150-60040-10	BEARING, BALL, RADIAL	2
30-3-7		I1202-LRA0-0000	OIL SEAL	2

30-4		C7205-5PA0-0000	MAGNET	1
30-5		D4613-5PA0-0000	SCREW	1
30-6		D4621-FIA0-0000	OUTER SPACER	2
30-7		D4621-LRA0-0000	OUTER SPACER	2
30-8		D5351-GJA0-0000	BRAKE DISC	2
30-9		D4611-FIC0-0000	NUT	8
30-10		I9905-14200	WASHER	2
30-11		I5500-14100	CASTLE NUT	2
30-12		I4201-46325	SPLIT PIN	2
30-13		D4609-9FA0-0000	RUBBER CAP	2
30-14		D5350-FIC0-0000	BOLT,ROUND HEAD	8




ITEM	AVAIL	PART NO.	NAME	QTY
31			REAR WHEEL	
31-1		D472C-LRC0-0SNS	REAR WHELL ASSY,LEFT(ON ROAD,STEEL 10*8)	1
31-1		D472C-LRF0-00FA	REAR WHELL ASSY,LEFT(OFF ALUMINUM 10*8)	1
31-1		D472C-LRC0-0SFS	REAR WHELL ASSY,LEFT(OFF ROAD,STEEL 10*8)	1
31-1-1		D471C-LRC0-0SFS	REAR WHELL COMP,RIGHT(OFF ROAD)	1
31-1-1		D471C-LRC0-0SFS	REAR WHELL COMP,RIGHT(OFF ROAD)	1
31-1-1		D471C-LRC0-0SNS	REAR WHELL COMP,LEFT(ON ROAD)	1
31-1-1		D471C-LRF0-00FA	REAR WHELL COMP,LEFT(ALUMINUM)	1
31-1-1-1		D4720-LRA0-0000	WHEEL TIRE (OFF ROAD)	1
31-1-1-1		D4720-LRA0-0000	WHEEL TIRE (OFF ROAD)	1
31-1-1-1		D4720-LRC0-0000	WHEEL TIRE (ON ROAD)	1
31-1-1-1		D4720-LRA0-0000	WHEEL TIRE (OFF ROAD)	1
31-1-1-2		D4602-FIC0-8S00	WHEEL RIM	1
31-1-1-2		D4602-FIC0-8S00	WHEEL RIM	1
31-1-1-2		D4602-FIC0-8S00	WHEEL RIM	1
31-1-1-2		D4602-FIC0-7700	WHEEL RIM(ALUMINUM) (10"x8)	1
31-1-2		D2705-GJA0-0000	SHAFT CONNECTER WITH BOLTS	1
31-1-2		D2705-GJA0-0000	SHAFT CONNECTER WITH BOLTS	1
31-1-3		D4611-FIC0-0000	NUT	4
31-1-3		D4611-FIC0-0000	NUT	4
31-2		D472D-LRC0-0SNS	REAR WHELL ASSY,RIGHT(ON ROAD,STEEL 10*8)	1
31-2		D472D-LRF0-00FA	REAR WHELL ASSY,RIGHT(OFF ALUMINUM)(10*8)	1
31-2		D472D-LRC0-0SFS	REAR WHELL ASSY,RIGHT(OFF ROAD,STEEL 10*8)	1
31-2-1		D471D-LRC0-0SFS	REAR WHELL COMP,RIGHT(OFF)	1
31-2-1		D471D-LRC0-0SFS	REAR WHELL COMP,RIGHT(OFF)	1
31-2-1		D471D-LRC0-0SNS	REAR WHELL COMP,RIGHT(ON)	1
31-2-1		D471D-LRF0-00FA	REAR WHELL COMP,RIGHT(OFF ALUMINUM)	1
31-2-1-1		D4720-LRA0-0000	WHEEL TIRE (OFF ROAD)	1
31-2-1-1		D4720-LRA0-0000	WHEEL TIRE (OFF ROAD)	1
31-2-1-1		D4720-LRC0-0000	WHEEL TIRE (ON ROAD)	1

31-2-1-1		D4720-LRA0-0000	WHEEL TIRE (OFF ROAD)	1
31-2-1-2		D4602-FIC0-8S00	WHEEL RIM	1
31-2-1-2		D4602-FIC0-8S00	WHEEL RIM	1
31-2-1-2		D4602-FIC0-8S00	WHEEL RIM	1
31-2-1-2		D4602-FIC0-7700	WHEEL RIM(ALUMINUM) (10"x8)	1
31-2-2		D2705-GJA0-0000	SHAFT CONNECTER WITH BOLTS	1
31-2-2		D2705-GJA0-0000	SHAFT CONNECTER WITH BOLTS	1
31-2-3		D4611-FIC0-0000	NUT	4
31-2-3		D4611-FIC0-0000	NUT	4
31-3		D2309-5EA0-0000	WASHER	2
31-4		I4012-140H0	CASTLE NUT	2
31-5		I4201-46325	SPLIT PIN	2
31-6		D4609-5EA0-0001	RUBBER CAP	2




ITEM	AVAIL	PART NO.	NAME	QTY
32			FRONT BRAKE SYSTEM	
32-1		G7120-FIC0-0001	BRAKE CALLIPER (L)	1
32-1-1		G7131-5EE0-0000	BRAKE SHOE COMP	1
32-1-1		G7131-5EE0-0000	BRAKE SHOE COMP	1
32-1-2		G7132-5EE0-0000	BOLT LEAKAGE	1
32-1-2		G7132-5EE0-0000	BOLT LEAKAGE	1
32-1-3		G7133-BCA0-0000	CAP LEAKAGE	1
32-1-3		G7133-BCA0-0000	CAP LEAKAGE	1
32-1-4		G7139-5EE0-0000	SPRING,PAO	1
32-1-4		G7139-5EE0-0000	SPRING,PAO	1
32-2		G7140-FIC0-0001	BRAKE CALLIPER	1
32-2-1		G7131-5EE0-0000	BRAKE SHOE COMP	1
32-2-1		G7131-5EE0-0000	BRAKE SHOE COMP	1
32-2-2		G7132-5EE0-0000	BOLT LEAKAGE	1
32-2-2		G7132-5EE0-0000	BOLT LEAKAGE	1
32-2-3		G7133-BCA0-0000	CAP LEAKAGE	1
32-2-3		G7133-BCA0-0000	CAP LEAKAGE	1
32-2-4		G7139-5EE0-0000	SPRING,PAO	1
32-2-4		G7139-5EE0-0000	SPRING,PAO	1
32-3		I7507-FIA0-0000	BOLT, HEX.	4
32-4		I0401-10034	FLANGE BOLT, HEX.	3
32-5		I0201-10118	WASHER	6
32-6		G7110-LRC0-0000	FRONT BRAKE OIL TUBE ASSY	1
32-7		I5821-08020	FLANGE BOLT, HEX.	1




ITEM	AVAIL	PART NO.	NAME	QTY
33			REAR BRAKE SYSTEM	
33-1		D2310-LRA0-0000	BEARING SEAT ASSY., REAR WHEEL AXLE	1
33-2		D2311-FIA0-0000	SPACER	1
33-3		I6100-6007LLU	BEARING	2
33-4		D2315-FIA0-0000	OIL SEAL	1
33-5		I5701-12165-0C	FLANGE BOLT, HEX.	2
33-6		G7130-LRA0-0000	RR. CALIPER ASSY	1
33-6-1		G7131-LRA0-0000	PAD ASSY BRAKE	1
33-6-1		G7131-LRA0-0000	PAD ASSY BRAKE	1
33-6-2		G7132-LRA0-0000	BOLT LEAKAGE	1
33-6-2		G7132-LRA0-0000	BOLT LEAKAGE	1
33-6-3		G7133-LRA0-0000	CAP LEAKAGE	1
33-6-3		G7133-LRA0-0000	CAP LEAKAGE	1
33-6-4		G7139-5EE0-0000	SPRING,PAO	1
33-7		I5701-10035-0C	FLANGE BOLT, HEX.	2
33-8		E0209-5EA0-9000	CAP, GREASE VALVE	1
33-9		D3520-LRA0-0000	BRAKE DISK	1
33-10		D3251-FIA0-0000	BRAKE DISK MOUNTING SEAT	1
33-11		I0110-10811	BOLT, SOCKET	3
33-12		I0401-10034	FLANGE BOLT, HEX.	2
33-13		I0201-10118	WASHER	4
33-14		D3210-LRA0-0000	REAR BRAKE OIL TUBE	1
33-15		D2313-FIA0-0000	OIL SEAL(48×62×7)	1
33-16		I5601-12200	FLANGE NUT, SAFETY	2
33-17		G7100-LRC0-0000	FOOT MASTER CYLINDER ASSY.	1
33-18		I6705-06012-0C	BOLT, FLANGE (M8×12)	3
33-19		I0149-06016	FLANGE BOLT, HEX.	1
33-20		D3410-LRC0-0000	BRAKE MASTER CYLINDER ARM F	1
33-21		D3411-LRC0-0000	BRAKE MASTER CYLINDER ARM R	1
33-22		E7401-BCA0-0000	RUBBER,BUFFER	1
33-23		G7202-GJA0-0000	SWITCH (FLOOR)	2
33-24		E0711-FIC0-9000	SPG,BRAKE LAMP SWITCH	2
33-25		I7510-06016-1B	PIN	4
33-26		I5300-00500-N	E CLIP, EX	4
33-27		E0708-LRF0-0001	PEDAL COMP BRAKE	1
33-28		G7180-LRC0-0000	MASTER CYLINDER HOLDER	1
33-29		E0720-LRC0-0000	AXLE FIXED	1

33-30		I6800-08015-0H	SOCKET BOLT	1
33-31		D3419-LRC0-0000	FRONT RETURN SPRING	1
33-32		I6600-06000	GREASE VALVE	1
33-33		E5451-LRC0-0000	CABEL,BRAKE	2
33-34		H7118-FIB0-0000	STICKER,WARNING	1


34 HANDLE BAR




ITEM	AVAIL	PART NO.	NAME	QTY
34			HANDLE BAR	
34-1		E3100-LRA0-0000	HANDLE BAR ASSY	1
34-2		E3180-LRC0-0000	LEVER ASSY,RIGHT	1
34-2-1		E3181-LRC0-0000	LEVER ,RIGHT	1
34-2-2		E3175-LRC0-0000	LEVER,WASHER WAVE	1
34-3		E3190-GJA0-0000	THROT HOOSING ASSY	1
34-4		E3170-LRC0-0000	LEVER ASSY,LEFT	1
34-4-1		E3171-FIA0-0000	LEVEL,LEFT	1
34-4-2		E3175-LRC0-0000	LEVER,WASHER WAVE	1
34-5		E3166-5EA0-0000	GRIP	2
34-6		E3112-5EA0-0000	BOTTOM,HANDLE BAR CLAMP	2
34-7		E3110-5EA0-0000	CAP,HANDEL BAR CLAMP(L)	1
34-8		E3111-5EA0-0000	CAP,HANDEL BAR CLAMP(R)	1
34-9		I0050-06025	BOLT, SOCKET	6
34-10		I5611-10200	HEX. FLANGE NUT, SAFETY	2
34-11		D3701-LRA0-0000	PARKING HOLDER	1
34-11-1		E3185-LRA0-0000	ADJUSTER BOLT	1
34-11-1		E3185-LRA0-0000	ADJUSTER BOLT	1
34-12		D3702-LRA0-0000	PARKING PLATE	1
34-13		D3703-LRA0-0000	PARKING LEVER	1
34-14		D3704-LRA0-0000	PARKING CABLE	1
34-15		I8501-06010	SCREW, PAN	2
34-16		H475B-5BA1-0000	PAD, LICENSE PLATE	1
34-17		H7140-LRA0-0000	STICKER,PARKING ADJUSTER NOTICE	1




ITEM	AVAIL	PART NO.	NAME	QTY
35			BUMPER, FOOTREST	
35-1		E0700-FIA0-0000	FOOTREST BAR	1
35-2		E0700-FID0-0000	FOOTREST BAR	1
35-3		I7507-FIA0-0000	BOLT, HEX.	8
35-4		I5611-06200-0G	HEX. FLANGE NUT, SAFETY	3
35-5		I0149-06823	SCREW	7
35-6		I0119-06802	BOLT, HEX.	1
35-7		E0400-LRC0-0000	BUMPER FRONT	1
35-8		E0430-LRC0-0000	BUMPER FRONT COVER	1
35-9		I8310-06020-01	SCREW, OVAL	3
35-10		I0110-40120	SCREW,TAPPING	4
35-11		I0149-08016	FLANGE BOLT, HEX.	6
35-12		H4751-LRC0-0000	PLASTIC PLATE,LICENSE	1
35-13		H1104-BCA0-0000	COLLAR	2
35-14		F0703-BCA0-0000	DAMPER	2
35-15		C3741-5BA0-0000A	RETRO REFLECTOR	2
35-16		C3744-LRA0-0000	STAY REFLECTOR LEFT	1
35-17		C3745-LRA0-0000	STAY REFLECTOR RIGHT	1
35-18		I3891-06020-0C	SCREW WASHER	4
35-19		I4050-05055-0A	FLANGE NUT, HEX.	2



ITEM	AVAIL	PART NO.	NAME	QTY
36			REAR WHEEL AXLE	
36-1		D0100-LRA0-0000	DRIVE CHAIN ASSY(520HX90)	1
36-1-1		D0104-FIC0-0000	MASTERLINK	1
36-2		D0101-LRA0-0000	PROTECT COVER	1
36-3		I0149-08016	FLANGE BOLT, HEX.	4
36-4		D2301-LRA0-0000	REAR AXLE	1
36-5		D2303-LRA0-0000	AXLE CLIP,REAR	1
36-6		D0110-LRA0-0000	SPROCKET HOLDERREAR ASSY	1
36-6-1		D0111-LRA0-0000	SPROCKET HOLDERREAR (38T)	1
36-6-2		D1111-LRA0-0000	GEAR(520X38T)	1
36-6-3		D2706-9EA0-0000	BOLT	4
36-6-4		I5611-10200	HEX. FLANGE NUT, SAFETY	4
36-7		D2302-FIA0-0000	NUT REAR WHEEL AXLE(M28x1.5)	2
36-8		D0120-LRA0-0000	ADJUSTERCHAIN	1
36-8-1		I2201-08050-0H	BOLT	1
36-8-2		I5800-08300	NUT, HEX.	1
36-9		D0102-FIA0-0000	DRIVE CHAIN COVER	1
36-10		I5701-06020-0C	BOLT, FLANGE (M6x20)	1
36-11		I5611-06200-0G	HEX. FLANGE NUT, SAFETY	2
36-12		I0149-06012	FLANGE BOLT, HEX.	1
36-13		H3503-LRA0-0000	T COLLAR	3
36-14		D2303-GJA0-0000	PLATE FIXED REAR AXLE(USED WITH D2301-GJ)	1
36-15		D0130-LRA0-0000	GUIDE CHAIN	1
36-16		I4104-05501	WASHER	2




ITEM	AVAIL	PART NO.	NAME	QTY
37			STEERING	
37-1		E3200-LRC0-0000	SHAFT ASSYSTEERING	1
37-2		E3201-5EA0-0000	OIL SEAL	1
37-3		I3102-5AC0-0000	OIL SEAL	1
37-4		D4620-5EA0-0000	COLLAR	1
37-5		I5611-14200	HEX. FLANGE NUT, SAFETY	1
37-6		E0258-LRA0-0000	STEERING TIE-ROD ASSYLEFT	1
37-6-1		E0251-LRA0-0000	BOLTSTUD	1
37-6-2		E0252-5EA0-0000	NUT (R)	1
37-6-3		E0253-5EA0-0000	NUT (L)	1
37-6-4		E0255-LRA0-0000	UNIVERSAL JOINT(L)	1
37-6-5		E0256-LRA0-0000	UNIVERSAL JOINT(R)	1
37-7		E0205-LRA0-0000	KNUCKLELEFT	1
37-8		E0215-LRA0-0000	KNUCKLERIGHT	1
37-9		G7112-BCA0-0000	BRACKET BRAKE HOSE	2
37-10		I0149-06012	FLANGE BOLT, HEX.	2
37-11		E3209-FIA0-0000	OIL SEAL(31.8×37.8×4)	2
37-12		E3202-FIA0-0000	HOLDER, STEERING SHAFT	2
37-13		E3203-FIA0-0000	FIX PLATE, STEERING SHAFT	1
37-14		I0020-08060	BOLT, HEX.	2
37-15		E3210-LRB0-0000	HOLDERSTEERING SHAFT PRESSED PLATED	1
37-16		E3208-FIA0-0000	STEERING , COLLAR	2
37-17		E0259-LRA0-0000	STEERING TIE-ROD ASSYRIGHT	1
37-17-1		E0251-LRA0-0000	BOLTSTUD	1
37-17-2		E0252-5EA0-0000	NUT (R)	1
37-17-3		E0253-5EA0-0000	NUT (L)	1
37-17-4		E0255-LRA0-0000	UNIVERSAL JOINT(L)	1
37-17-5		E0256-LRA0-0000	UNIVERSAL JOINT(R)	1
37-18		D4611-9EA0-0000	FLANGE NUT, HEX.	4
37-19		I9900-25019	PIN, SPLIT	5




ITEM	AVAIL	PART NO.	NAME	QTY
38			ELECTRICAL EQUIPMENT	
38-1		C2100-LRC0-0000	WIRE HARNESS	1
38-1-1		C2010-GJA0-0000	FUSE(10A)	1
38-1-2		C2011-GJA0-0000	FUSE(15A)	2
38-1-3		C2013-LRA0-0000	FUSE(30A)	1
38-2		C2102-LRA0-0000	EARTH CABLE	1
38-3		I0153-06012	SCREW	1
38-4		C1500-LRA0-0000	BATTERY ASSY. (12AH)	1
38-5		C1502-LRA0-0000	BATTERY BAND	1
38-6		A7509-FID0-0000	LH. BACK MIRROR ASSY	1
38-7		I0149-06012	FLANGE BOLT, HEX.	2
38-8		C501A-LRC0-0001	MAIN SWITCH COMP	1
38-8-1		C5010-LRA0-0000	MAIN SWITCH	1
38-8-2		C5011-FIC0-0000	FAUCET LOCK	1
38-8-3		C5013-9FA0-0000	MATERIAL KEY (RIGHT CUT)	1
38-8-4		C5018-9FA0-0000	MATERIAL KEY (LEFT CUT)	1
38-9		I8501-5BA1-0000	BOLT,BROKENABLE	2
38-10		C5200-LRC0-0000	LEVER HOLDER ASSY., LEFT	1
38-10-1		C5201-LRC0-0000	LEVER HOLDER , LEFT	1
38-10-2		C5202-5EE0-0000	AIR CUT, LEVER	1
38-11		C1802-FIB0-0000	POWER SUPPLY	1
38-12		H9020-FIA0-0000	TOOL PACK	1
38-13		H9021-9FA0-0000	WIRE CLAMP	1
38-14		C8110-GJA0-0000	HORN	1
38-15		I0149-08012	FLANGE BOLT, HEX.	1
38-16		C1600-LRA0-0001	REG. REC. COMP.	1
38-17		I0149-06016	FLANGE BOLT, HEX.	2
38-18		C0410-RB1-0000	CDI UNIT ASS'Y	1
38-19		C051A-RB1-0000	IGN COIL ASS'Y	1
38-20		I2140-60001	WASHER	1
38-21		I0020-05024	BOLT HEX.	1
38-22		C585A-LRA0-0000	REALY ASSY, START	1
38-22-1		C5850-LRA0-0000	START RELAY	1
38-22-1	N	C5850-LRA0-0000	START RELAY	1
38-22-2		C2101-LRA0-0000	POSITIVE CABTE	1
38-22-2		C2101-LRA0-0000	POSITIVE CABTE	1
38-23		C576A-LRA0-0000	SHIFT GEAR CONTROL UNIT ASS'Y	1
38-24		I7701-50016	SCREW, TAPPING	1

38-25		C3401-LRC0-0000	TURN LAMP ASSY F.R	1
38-25-1		F1231-LRF0-0000	BULB	1
38-26		I7701-50016	SCREW, TAPPING	4
38-27		C3451-LRC0-0000	TURN LAMP ASSY F.L	1
38-27-1		F1231-LRF0-0000	BULB	1
38-28		F1240-LRC0-0000	TURN LAMP ASSY R.L	1
38-28-1		C3402-FIE0-0000	TURN LAMP BULB(10W)	1
38-29		F1230-LRC0-0000	TURN LAMP ASSY R.R	1
38-29-1		C3402-FIE0-0000	TURN LAMP BULB(10W)	1
38-30		I3903-312B0	TRUSS	4
38-31		C7200-LRA0-0000	SPEEDOMETER ASSY	1
38-31		C7200-LRA9-0000	SPEEDOMETER ASSY	1
38-31-1		C7201-LRA0-0000	SPEEDOMETER	1
38-31-2		C7207-FIC0-9000	METER SENSOR	1
38-32		I8506-05010	SCREW PAN	2
38-33		C850A-LRA0-0000	ELEC.RELAY ASSY	2
38-34		C872A-LRA0-0000	HAZARD CONTROL NUIT ASSY	1
38-35		C8301-LRA0-0000	WINKER RELAY COMP	1
38-36		I0149-06012	FLANGE BOLT, HEX.	1
38-37		C8400-EMA0-0000	BUZZER	1
38-38		I2600-03012	SCREW, PAN	2
38-39		H0109-RB1-0000	MAG.STAY	1



ITEM	AVAIL	PART NO.	NAME	QTY
39			PACKING CASE,EXTERNAL	
39-1		H9500-LRA0-0000	PACKING CASE,EXTERNAL	1
39-2	N	H9900-LRC0-0000	OWNER'S MANUAL	1
39-3		C5031-LRA0-0000	TAIL LIGHT	1
39-3-1		C5004-5BA1-0000	LAMP	1
39-4		I5611-06200-0G	HEX. FLANGE NUT, SAFETY	2
39-5		I7701-50016	SCREW, TAPPING	4
39-6		C5020-LRC0-0000	HEAD LIGHT ASSY.,LEFT	1
39-6-1		C5003-LRA0-0000	BULB	1
39-7		C5030-LRC0-0000	HEAD LIGHT ASSY.,RIGHT	1
39-7-1		C5003-LRA0-0000	BULB	1
39-8		E0117-9EA0-0000	SCREW, TRUSS	2
39-9		H8100-LRC0-0000	BACK MIRROR ASSY	1
39-9-1		H8110-LRC0-0000	REAR VIEW MIRROR ASSY,R	1
39-9-2		H8120-LRC0-0000	REAR VIEW MIRROR ASSY,L	1
39-10	N	H9905-LRC0-0000	CERTIFICAT OF ORIGIN	1

40 ACCESSORIES



ITEM	AVAIL	PART NO.	NAME	QTY
40			ACCESSORIES	
40-1		E041C-LRA0-0000		1
40-1-1		E0418-LRA0-0000	VEHICLE A HOOK	1
40-1-2		I0149-10030	BOLT,FLANGE	2
40-1-3		I4111-10625-1A	SPRING WASHER	2
40-2	N	E0419-FIB0-9000	VEHICLE A HOOK BALL (2 inch)	1
40-2	N	E0419-FIB0-0000	VEHICLE A HOOK BALL (1 7/8 inch)	1
40-2-1		I3300-20000-0B	SPRING WASHER	1
40-2-2		I4100-19016	NUT	1
40-3		E0411-LRA0-9000	REAR PACK	1
40-4		I0149-08016	FLANGE BOLT, HEX.	4
40-5		H7113-9FB0-0000	CARRIER COVER,STICKER	1
40-6		I5616-08200	NUTFLANGE CHECK	1
40-7		E041A-LRA0-0000	HANDRAIL ASSY	1
40-7-1	N	E0410-LRA0-0000	HANDRAIL	1
40-7-2		I0149-08030	FLANGE BOLT, HEX.	2
40-7-3		I5821-08020	FLANGE BOLT, HEX.	1
40-7-4		E0408-LRA0-0000	HANDRAIL COVER	1
40-7-5		I3903-312B0	TRUSS	2
40-8		MH8402-100-0800	LUGGAGE BAGS	1

No picture.

ITEM	AVAIL	PART NO.	NAME	QTY
41			SERVICE KITS,BRAKE CALLIPER	
41-1		G7120-FIC0-0001	BRAKE CALLIPER (L)	1
41-1-1		G7131-5EE0-0000	BRAKE SHOE COMP	1
41-1-1		G7137-5EE0-0000	SERVICE KITS, BRAKE CALIPER	1
41-1-1-1		G7134-5EE0-0000	RING,SEAL	1
41-1-1-1		G7134-5EE0-0000	RING,SEAL	1
41-1-1-2		G7135-5EE0-0000	RING,DUST RESISTANT	1
41-1-1-2		G7135-5EE0-0000	RING,DUST RESISTANT	1
41-1-1-3		G7136-5EE0-0000	PISTON, BRAKE CALIPER	1
41-1-1-3		G7136-5EE0-0000	PISTON, BRAKE CALIPER	1
41-1-1-4		G7138-5EE0-0000	BRAKE SHOE ASSY	1
41-1-1-4-1		G7131-5EE0-0000	BRAKE SHOE COMP	1
41-1-1-4-2		G7139-5EE0-0000	SPRING,PAO	1
41-1-2		G7132-5EE0-0000	BOLT LEAKAGE	1
41-1-3		G7133-BCA0-0000	CAP LEAKAGE	1
41-1-4		G7139-5EE0-0000	SPRING,PAO	1
41-2		G7140-FIC0-0001	BRAKE CALLIPER	1
41-2-1		G7131-5EE0-0000	BRAKE SHOE COMP	1
41-2-1		G7137-5EE0-0000	SERVICE KITS, BRAKE CALIPER	1
41-2-1-1		G7134-5EE0-0000	RING,SEAL	1
41-2-1-1		G7134-5EE0-0000	RING,SEAL	1
41-2-1-2		G7135-5EE0-0000	RING,DUST RESISTANT	1
41-2-1-2		G7135-5EE0-0000	RING,DUST RESISTANT	1
41-2-1-3		G7136-5EE0-0000	PISTON, BRAKE CALIPER	1
41-2-1-3		G7136-5EE0-0000	PISTON, BRAKE CALIPER	1
41-2-1-4		G7138-5EE0-0000	BRAKE SHOE ASSY	1
41-2-1-4-1		G7131-5EE0-0000	BRAKE SHOE COMP	1
41-2-1-4-2		G7139-5EE0-0000	SPRING,PAO	1
41-2-2		G7132-5EE0-0000	BOLT LEAKAGE	1
41-2-3		G7133-BCA0-0000	CAP LEAKAGE	1
41-2-4		G7139-5EE0-0000	SPRING,PAO	1
41-3		G7130-LRA0-0000	RR. CALIPER ASSY	1
41-3-1		G7131-LRA0-0000	PAD ASSY BRAKE	1
41-3-1		G7137-LRA0-0000	SERVICE KITS,BRAKE CALLIPER	1
41-3-1-1		G7134-LRA0-0000	RING,SEAL	1
41-3-1-1	N	G7134-LRA0-0000	RING,SEAL	1
41-3-1-2		G7135-LRA0-0000	RING,DUST RESISTANT	1
41-3-1-2	N	G7135-LRA0-0000	RING,DUST RESISTANT	1
41-3-1-3		G7136-LRA0-0000	PISTON,BRAKE CALLIPER	1

41-3-1-3	N	G7136-LRA0-0000	PISTON,BRAKE CALLIPER	1
41-3-2		G7132-LRA0-0000	BOLT LEAKAGE	1
41-3-3		G7133-LRA0-0000	CAP LEAKAGE	1
41-3-4		G7139-5EE0-0000	SPRING,PAO	1

No picture.

ITEM	AVAIL	PART NO.	NAME	QTY
42			TOOL	
42-1		A4451-HMA-FT1	TAKING TAPPET PIN TOOL	1
42-2		A4711-HMA-FT1	TAKING & FABRICATING IN. VALVE TOOL	1
42-3		A4721-HMA-FT1	ADJUST TAPPET IMPLEMENT	1
42-4		A9217-H9A-FT1	KNOCKING WATER PUMP OIL SEAL(IRON) IMPL	1
42-5		B2101-HMA-FT1	ALL-PURPOSE FIXER	1
42-6		I6150-RB1-FT1	TAKING BRG. RB1 TOOL	1
42-7		B3411-RB1-FT1	ASSEMBLING DRIVE SHAFT TOOL	1
42-8		C1110-RB1-FT1	TACKING ACG FLY WHEEL TOOL	1
42-9		E0205-LRA0-FT1	Ball Joint Puller	1
42-10		E1105-LRA0-FT1	Adjustable Hook Spencer	1
42-11		I0202-HMA-FT1	TAKING & LOCKING SPECIAL NUT 36MM SLEEVE	1
42-12		I1001-KJ9-FT1	KNOCKING BRG.(6901) WATER PUMP IMPLEMENT	1
42-13		I1003-RB1-FT1	COUNTER SHIFT IMPLEMENT	1
42-14		I1201-HMA-FT1	SLEEVE OF FABRICATING L CRANK & OIL SEAL	1
42-15		I1202-RB1-FT1	SLEEVE OF FABRICATING TRANSMISSION SHAFT	1
42-16		I1205-KF0-FT1	KNOCKING WATER PUMP OIL SEAL IMPLEMENT (	1
42-17		I6100-6204-FT3	TAKING BRG. 62040 LARGE-SIZE TOOL	1
42-18		I6100-6204-FT2	KNOCKING BRG.(6204) IMPLEMENT	1
42-19		I6100-6305-FT1	TAKING TRANSMISSION SHAFT BRG. 6305 TOOL	1
42-20		I6140-6201-FT1	FABRICATING R CRANK CASE COVER 6201 BRG	1
42-21		I6150-6006-FT1	L CRANK CASE COVER 6006 BRG. FABRICATIN	1
42-22		I6150-6205-FT1	TAKING 6205 BRG. TOOL	1
42-23		I6150-6205-FT2	6205 BRG. KNOCK TOOL	1
42-24		I6150-6205-FT3	PNEUMATIC TAKING BRG. 6205 TOOL	1