

PARTS CATALOGUE

VIPER 150 RXL-150



CONTENTS


PARTS ITEM:

- 01 CRANK CASE, L COVER, SPINDLE ASSY.
- 02 CRANK SHAFT, PISTON, CYLINDER, TENSIONER
- 03 OIL PUMP, STARTING MOTOR
- 04 RIGHT CRANK CASE COVER, GENERATOR
- 05 COVER HEAD, HEAD, CAM SHAFT, VALVE
- 06 FAN COVER, SHROUD
- 07 DRIVEN RULLEY (CVT)
- 08 TRANSMISSION
- 09 GEAR SHAFT LEVER, SAFETY SWITCH
- 10 AIR CLEANER
- 11 CARBURETOR (MANUAL CHOKE WITHOUT THREE
- 11 CARBURETOR (MANUAL CHOKE WITH THREE THR
- 11 CARBURETOR (AUTO-BY/STARTER)
- 12 OIL COOLER
- 13 ENGINE
- 14 MUFFLER(U.S)
- 14 MUFFLER(E.P)
- 15 FRAME
- 16 FENDER
- 17 SWING ARM
- 18 SEAT
- 19 FUEL TANK
- 19 FUEL TANK
- 20 SUSPENSION
- 21 FRONT WHEEL
- 22 REAR WHEEL
- 23 FRONT BRAKE SYSTEM

- 24 REAR BRAKE SYSTEM
- 25 HANDLE BAR
- 26 BUMPER, FOOTREST
- 27 REAR WHEEL AXLE
- 28 STEERING
- 29 ELECTRICAL EQUIPMENT
- 30 PACKING CASE,EXTERNAL
- 31 OPIIONAL
- 35 MANUAL CHOKE KIT
- 36 TOOL

N & sign meaning: not available to sale


1. CRANK CASE · L COVER · SPINDLE ASSY



ITEM	AVAIL	PART NO.	NAME	QTY
01			CRANK CASE, L COVER, SPINDLE ASSY.	
01-1		A1200-V30-0900	CRANK CASE ASSY LEFT	1
01-2		I6100-62030	BEARING, BALL RADIAL	1
01-3		I6100-62020	BEARING, BALL, RADIAL	1
01-4		I6100-62043	BEARING, BALL, RADIAL	1
01-5		B3411-V30-9000	SHAFT DRIVE (13T)	1
01-6		I1202-A04-0000	OIL SEAL (20×32×6)	1
01-7		I4510-20000	CIRCLIP EX	1
01-8		I4608-09424	O-RING	1
01-9		I6150-62000-10	BEARING, BALL, RADIAL	1
01-10		A1103-V30-0000	RUBBER BUSH ENGINE HANGER	4
01-11		A8255-V30-0000	BOSS (A)	1
01-12		I4301-08140	KNOCK PIN	2
01-13		I0032-08208-0H	STUD BOLT (B)	2
01-14		I0031-08200-0H	STUD BOLT (A)	2
01-15		A1100-V30-0900	CRANK CASE COMP R (OIL COOLER)	1
01-16		I6001-06050-0H	BOLT FLANGE	2
01-17		A1250-A14-0000	PLATE COMP, L CRANK CASE	1
01-17-1		A1207-A14-0001	PLATE CRANK CASE L	1
01-17-2		I4608-10720	O-RING	1
01-17-3		I1202-A26-9000	OIL SEAL (L)	1
01-18		I6001-06020-0H	FLANGE BOLT, HEX.	2
01-19		I4608-06017	O-RING	2
01-20		A1221-V30-0000	HOSE BREATHER	1
01-21		A1106-A00-0000	CONNECTER TUBE BREATHER	1
01-22		I4104-12120	WASHER	2
01-23		I2800-12015-0C	BOLT, HEX.	2
01-24		B4305-V30-0000	SCREW FIXING	1
01-25		I4104-14210	WASHER	1
01-26		B4306-V30-0000	SPRING FIXING	1
01-27		B4307-V30-0000	BALL BEARING	1
01-28		A1206-V30-0000	CONNECTER TUBE BREATHER	1
01-29		A7232-V30-0000	DRAIN TUBE	1
01-30		A1192-A08-0000	GASKET CRANK CASE	1
01-31		I4104-10010	WASHER	1
01-32		C5750-V30-0000	NEUTROL SWITCH COMP	1
01-32-1	N	C5752-V30-0000	NEUTRAL SWITCH CONNECTER	1
01-32-2	N	I3500-04006	SCREW, CROSS RECESS HEAD	1


01-32-3	N	C5751-V30-0000	WIRING COMP	1
01-33		I4301-10140	KNOCK PIN	2
01-34		A1341-V30-0300	COVER L SIDE	1
01-35		A1395-V30-0000	GASKET L COVER	1
01-36		I6001-06040-0C	BOLT, HEXAGON HEAD	7
01-37		I6001-06040-0H	FLANGE BOLT, HEX.	1
01-38		B825A-V30-0000	SPINDLE ASSY. KICK STARTER	1
01-38-1	N	B8250-A14-0001	SPINDLE COMP KICK START	1
01-38-2		B8281-A14-0000	SPG KICK STARTER	1
01-38-3		B8253-V30-0000	BOSS KICK SPINDLE (B)	1
01-38-4		I4608-13824A	O-RING	1
01-39		I4104-14520A	WASHER	1
01-40		I4510-14000	CIRCLIP EX	1
01-41		B823A-A14-0001	GEAR ASSY STARTER IDLE	1
01-41-1		B8230-A14-0001	GEAR COMP STARTER IDLE	1
01-41-1	N	B8230-A14-0001	GEAR COMP STARTER IDLE	1
01-41-2		B8223-A14-0000	SPG. FRICTION START GEAR	1
01-41-2	N	B8223-A14-0000	SPG. FRICTION START GEAR	1
01-42		I4102-10505	WASHER	1
01-43		B8300-V30-9000	ARM COMP KICK STARTER	1
01-44		I5701-06035-0C	BOLT , HEXAGON HEAD	1
01-45		I4104-06515A	WASHER	1
01-46		I6001-06012-0H	FLANGE BOLT, HEX.	1

2. CRANK SHAFT 、 PISTON 、 CYLINDER 、 TENSIONER




ITEM	AVAIL	PART NO.	NAME	QTY
02			CRANK SHAFT, PISTON, CYLINDER, TENSIONER	
02-1		A3000-V30-0001	CRANK SHAFT COMP	1
02-1-1		I4401-25046	WOODRUFF KEY	2
02-2		I4601-15000	CLIP, PISTON PIN 15mm	2
02-3		A3111-A08-0000	PIN, PISTON	1
02-4		A3101-A08-0000	PISTON	1
02-5		A3011-A08-0000	RING SET, PISTON	1
02-5-1	N	A3121-A08-0000	RING PISTON TOP	1
02-5-2	N	A3131-A08-0000	RING PISTON 2ND	1
02-5-3	N	A3141-A08-0000	RING PISTON OIL	1
02-6		I4301-10140	KNOCK PIN	2
02-7		A2191-A08-0000	GASKET CYLINDER	1
02-8		A2100-A08-0000	CYLINDER COMP	1
02-9		I5801-06012-0C	FLANGE BOLT, HEX.	1
02-10		I4104-06512	WASHER	1
02-11		I4301-06240	KNOCK PIN	1
02-12		A4510-A04-0000	TENSIONER CAM CHAIN	1
02-13		A4610-A04-0000	GUIDE COMP CAM CHAIN	1
02-14		A4401-A07-0000	CHAIN CAM	1
02-15		I3700-06005	SCREW, OVAL TAP	1
02-16		I6001-06020-0H	FLANGE BOLT, HEX.	2
02-17		I4608-09515	O-RING	1
02-18		A4520-A04-0000	LIFTER ASSY .TENSIONER	1
02-19		A4523-A04-0000	GASKET TENSIONER LIFTER	1

3.OIL PUMP · STARTONG MOTOR




ITEM	AVAIL	PART NO.	NAME	QTY
03			OIL PUMP, STARTING MOTOR	
03-1		A5100-A07-0000	PUMP ASSY. OIL	1
03-1-1		I3500-03010-0G	SCREW,CROSS RECESS HEAD	1
03-1-2		A5116-A04-0000	PLATE OIL PUMP	1
03-1-3		A5331-A07-0000	ROTOR OIL PUMP INNER	1
03-1-4		A5332-A07-0000	ROTOR OIL PUMP OUTER	1
03-1-5		I4303-04065	KNOCK PIN	1
03-1-6		A5101-A07-0000	BODY OIL PUMP	1
03-1-7		A5132-A04-0000	SHAFT OIL PUMP	1
03-2		I3600-06030-0H	SCREW ,CROSS RECESS HEAD	2
03-3		A5133-A04-0000	SPROCKET OIL PUMP DRIVEN	1
03-4		I4050-0600G	NUT	1
03-5		A5141-A04-0000	CHAIN OIL PUMP	1
03-6		A5711-A04-0000	SEPARATOR OIL	1
03-7		I6001-06012-0H	FLANGE BOLT, HEX.	2
03-8		C1200-V30-0000	MOTOR START COMP	1
03-8-1		I1309-24031	O-RING	1
03-8-2		I3892-04006-08	SCREW WASH	2
03-8-3		C1221-A04-0000	CARBON BRUSH	2
03-9		I6001-06016-0C	BOLT , HEXAGON HEAD	2
03-10		B8102-A04-0000	SHAFT STARTER REDUCTION GEAR	1
03-11		B8101-A04-0000	GEAR STARTER REDUCTION	1
03-12		I0231-A04-0000	NUT LOCK	1
03-13		B812A-A04-0000	OUTER ASSY .STARTING CLUTCH	1
03-13-1		B8125-A04-0000	FLANGE STARTING CLUTCH	1
03-13-2		B8126-A04-0000	CAP SPRING ROLLER SP	3
03-13-3		I6220-A0100	ROLLER	3
03-13-4		B8127-A04-0000	SPRING STARTING CLUTCH ROLLER	3
03-13-5		B8120-A04-0000	OUTER COMP STARTING CLUTCH	1
03-13-6		I6600-06010-0A	SOCKET BOLT	3
03-13-7		I4303-05060	KNOCK PIN	1
03-13-8		I1110-2832168	BEARING, NEEDLE	1
03-14		B8110-A04-0000	GEAR COMP STARTING CLUTCH	1
03-15		I4104-22225	WASHER	1

4. RIGHT CRAANK CASE COVER, GENERATOR



ITEM	AVAIL	PART NO.	NAME	QTY
04			RIGHT CRANK CASE COVER, GENERATOR	
04-1		I4301-08140	KNOCK PIN	2
04-2		I1201-A26-9000	OIL SEAL (R)	1
04-3		A1394-A04-0000	GASKET R CRANK CASE COVER	1
04-4		A1331-V30-0900	COVER R CRANK CASE	1
04-5		A5650-A04-0000	GAUGE COMP OIL LEVEL	1
04-5-1		A5651-A04-0000	GAUGE OIL LEVEL	1
04-5-1	N	A5651-A04-0000	GAUGE OIL LEVEL	1
04-5-2		I4608-18030	O-RING	1
04-5-2		I4608-12625	O-RING	1
04-6		A5421-A00-0000	SCREEN, OIL FILTER	1
04-7		A5426-A04-0000	SPG OIL FILTER SCREEN	1
04-8		A2360-A04-0001	HOLE CAP TAPPET COMP	1
04-8-1		I4608-30832	O-RING	1
04-8-1		A2361-A04-0000	HOLE CAP TAP ADJUSTING	1
04-8-2		A2361-A04-0000	HOLE CAP TAP ADJUSTING	1
04-8-2		I4608-30832	O-RING	1
04-9		C2961-A04-0000	CLAMPER A.C.G GENERATOR	1
04-10		I6001-06040-0C	BOLT, HEXAGON HEAD	1
04-11		I6001-06110-0C	BOLT , HEXAGON HEAD	2
04-12		I6001-06100-0H	FLANGE BOLT, HEX.	1
04-13		I6001-06032-0H	BOLT , HEXAGON HEAD	1
04-14		I6001-06095-0C	BOLT , HEXAGON HEAD	4
04-15		C1120-V30-9000	STARTOR COMP(CDI)	1
04-16		C1110-V30-0000	FLYWHEEL COMP	1
04-17		I3412-05014-0H	BOLT, HEX.	2
04-18		I6001-06020-0H	FLANGE BOLT, HEX.	2
04-19		I4104-12522	WASHER	1
04-20		I4050-12110-0H	FLANGE NUT, HEX.	1
04-21		A9510-A04-0000	FAN COMP COOLING	1
04-22		I6001-06018-0H	BOLT , HEXAGON HEAD	4


5. HEAD COVER 、 HEAD 、 CAM SHAFT 、 VALVE



ITEM	AVAIL	PART NO.	NAME	QTY
05			COVER HEAD, HEAD, CAM SHAFT, VALVE	
05-1		I4301-10140	KNOCK PIN	4
05-2		A2251-A08-0000	GASKET CYLINDER HEAD	1
05-3		A220A-A08-0001	HEAD CYLINDER ASS'Y	1
05-3-1		A2200-A08-0001	HEAD COMP CYLINDER	1
05-3-1-1		I4608-09016	O-RING	2
05-3-1-2		A2237-A04-0000	GUIDE IN VALVE	1
05-3-1-3		A2245-A04-0000	GUIDE EX VALVE	1
05-3-2		A4721-A08-0000	VALVE EXHAUST	1
05-3-3		A4711-A08-0000	VALVE INLET	1
05-3-4		I2900-06016-0A	BOLT, STUD	2
05-3-5		I2900-06050-0A	BOLT, STUD	2
05-3-6		I8000-V30-0000	SPARK PLUG	1
05-3-7		A4781-A04-0000	COTTER, VALVE	4
05-3-8		A4771-A04-0000	RETAINER, VALVE SPRING	2
05-3-9		A4761-A07-0000	SPG VALVE INNER	2
05-3-10		A4751-A07-0000	SPG VALVE OUTER	2
05-3-11		I4104-16508	WASHER	2
05-3-12		A2209-A04-0000	SEAL VALVE STEM	2
05-4		I0012-A04-0000	SCREW ADJUSTING	2
05-5		A4431-A07-0001	ARM VALVE ROCKER	2
05-6		A4450-A04-0000	SHAFT COMP IN ROCKET ARM	1
05-7		I6001-06100-0H	FLANGE BOLT, HEX.	2
05-8		A4452-A04-0000	SHAFT EX ROCKET ARM	1
05-9		A6201-A04-0000	GASKET CARB INSULATOR	1
05-10		A6211-A04-0000	INSULATOR CARB	1
05-11		A711A-V30-0000	PIPE ASSY INLET	1
05-11-1		A7256-V30-0000	AIR CLEANER CONNECTING TUBE	1
05-11-2		A7110-A07-9000	PIPE COMP INLET	1
05-11-3		I4608-27020	O-RING	1
05-12		I4050-0600G	NUT	2
05-13		I4101-08523	WASHER	4
05-14		I4050-08075-0H	NUT HEXAGON HEAD	4
05-15		A2211-A04-0000	HOLDER CAM SHAFT	1
05-16		A230A-A04-0000	COVER ASSY HEAD CYLINDER	1
05-16-1		A2301-A04-0001	COVER HEAD CYLINDER	1
05-16-2		A2391-A04-0000	GASKET COVER HEAD CYLINDER	1

05-16-3		A2305-A04-0000	JOINT COMP BREATHER	1
05-17		I6001-06025-0C	FLANGE BOLT, HEX.	4
05-18		A4150-A04-0000	PLATE COMP STOPPER	1
05-19		A8291-A04-0000	GASKET EXHAUST PIPE	1
05-20		A4100-A07-0001	SHAFT COMP CAM	1
05-21		I4001-050K0	NUT HEX	2

6. FAN COVER、SHROUD




ITEM	AVAIL	PART NO.	NAME	QTY
06			FAN COVER, SHROUD	
06-1		A9620-A07-0001	SHROUD COMP A	1
06-1-1		A9621-V30-0000	SHROUD A	1
06-1-2		A9637-V30-0000	NUT SPRING	1
06-1-3		A9625-A04-0000	SEAL SHROUD A	1
06-2		A963A-V30-0001	SHROUD B ASSY	1
06-2-1		A9630-V30-0000	SHROUD B COMP	1
06-2-2		A9636-V30-0000	CLAMPER CABLE	1
06-2-3		A9637-V30-0000	NUT SPRING	1
06-2-4		A9633-A04-0000	GROMMET SHROUD(B)	1
06-2-5		A9635-A04-0000	SEAL SHROUD B	1
06-3		A961A-V30-0000	FAN COVER ASSY	1
06-3-1		A9610-V30-0000	COVER COMP FAN	1
06-3-2		G0529-A04-0000	GROMMET SHROUD	1
06-3-3		A9615-A04-0000	DUCT CARBURETOR COOLING	1
06-3-4		H7541-V30-0000	LABEL OIL CAP	1
06-3-5		G0529-V30-0000	GROMMET SHROUD	1
06-3-6		A9616-V30-0000	DUCT INLET	1
06-3-7		I3902-304B0	SELF-TAPPING SCREW	3
06-4		I3904-316B0	TAPPING SCREW, HEX.	2
06-5		I3500-05025-0G	SCREW, PAN	2
06-6		A1385-V30-0000	CLAMPER CARB DRAIN TUBE	1
06-7		I6001-06025-0C	FLANGE BOLT, HEX.	3

ITEM	AVAIL	PART NO.	NAME	QTY
07			DRIVEN RULLEY (CVT)	
07-1		I4050-12110-0H	FLANGE NUT, HEX.	2
07-2		B301A-V30-9000	PULLEY ASSY DRIVEN	1
07-2-1		B2101-A04-9000	OUTER CLUTCH	1
07-2-2		I0202-A04-9000	NUT SPECIAL	1
07-2-3		B2300-V30-0000	PLATE COMP DRIVE	1
07-2-3-1		B2350-A04-0000	PLATE COMP DRIVE	1
07-2-3-2		B2804-A04-0000	RUBBER CLUTCH DAMPER	3
07-2-3-3		B2401-A04-0000	SPRING CLUTCH	3
07-2-3-4		B2530-V30-0000	WEIGHT SET CLUTCH	1
07-2-3-5		B2361-A04-0000	PLATE CLUTCH SIDE	1
07-2-3-6		I4540-0701A	CIRCLIP	3
07-2-4		B3238-A04-0000	COLLAR SPRING	1
07-2-5		B3233-A08-0000	SPRING DRIVER FACE	1
07-2-6		B3237-A04-0000	COLLAR SEAL	1
07-2-7		I1351-A04-0000	O-RING PINION CAP	2
07-2-8		I1211-A04-0000	SEAL DRIVEN FACE (34x41x4)	2
07-2-9		B3225-A04-0000	PIN ROLLER GUIDE	3
07-2-10		B3226-A04-0000	ROLLER GUIDE	3
07-2-11		B3220-A04-0000	FACE COMP MOVABLE DRIVEN	1
07-2-12		B3200-A04-0000	FACE COMP DRIVEN	1
07-2-12-1		B3210-A04-0000	FACE DRIVEN	1
07-2-12-2		I6140-6902LU3	BEARING, BALL, RADIAL	1
07-2-12-3		I4520-28000	CIR CLIP IN	1
07-2-12-4		I1120-202918	BEARING, NEEDLE	1
07-3		B3100-A07-0000	BELT DRIVE	1
07-4		B3240-V30-0000	DISK CLUTCH FRICTON COMP	1
07-4-1		B3241-V30-0000	STOPPER PUMP	1
07-4-2		B3242-V30-0000	STOPPER	1
07-4-3		B3243-V30-0000	CLUTCCH	6
07-4-4		B3244-V30-0000	BRAKE LINING	6
07-4-5		I3501-V30-0000	SCREW BUTTON HEAD CAP	3
07-4-5		I3501-V30-0000	SCREW BUTTON HEAD CAP	3
07-4-6		I3502-V30-0000	SCREW BUTTON HEAD CAP	3
07-5		I4104-15023	WASHER	1
07-6		B2102-A14-0000	FACE DRIVE	1
07-7		B2105-A04-0000	BOSS DRIVE FACE	1
07-8		B2110-A08-0000	FACE ASSY. MOVABLE DRIVE	1
07-8-1		I4601-28000	CLIP	1

07-8-2		B2112-A04-0000	BOSS FACE MOVABLE DRIVE	1
07-8-3		B2111-A04-0000	FASE COMP MOVABLE DRIVE	1
07-8-4		A0001-A08-0000	ROLLER COMP WEIGHT	1
07-8-4-1		B2121-A08-0000	ROLLER SET WEIGHT	6
07-8-5		B2132-A04-0000	PIECE SLIDE	3
07-8-6		B2131-A04-0000	PLATE RAMP	1
07-9		B8211-A14-0002	RATCHET KICK STARTER	1
07-10		I4104-15104	WASHER	1


8. TRANSMISSION



ITEM	AVAIL	PART NO.	NAME	QTY
08			TRANSMISSION	
08-1		B1300-V30-0900	COVER MISSION	1
08-2		B3430-V30-0000	FINAL SHAFT COMP (40T)	1
08-3		I1130-304217	BEARING, NEEDLE	1
08-4		I1201-V30-0000	OIL SEAL	1
08-5		I6150-62053-10	BEARING, BALL, RADIAL	1
08-6		I4104-25210	WASHER	1
08-7		I4510-25000	CIRCLIP EX	1
08-8		I4520-52000	CIRCLIP IN	1
08-9		B3801-V30-0001	SPROCKET DRIVE	1
08-10		B3811-V30-0000	PLATE FIXING	1
08-11		I2201-06010-0C	BOLT	2
08-12		B3420-V30-9000	COUNTER SHAFT COMP	1
08-12-1	N	B3421-V30-0000	SHAFT COUNTER	1
08-12-2	N	B3422-V30-9000	GEAR COUNTER	1
08-13		I6100-63020	BRG RADIAL BALL	1
08-14		B3250-V30-9000	SHAFT GEAR SHIFT COMP	1
08-14-1	N	B3213-V30-0001	COLLAR SHAFT	1
08-14-2	N	I4104-15110	WASHER	2
08-14-3	N	B3440-V30-0000	SPUR GEAR ASSY	1
08-14-3-1	N	B3441-V30-9000	GEAR SPUR	1
08-14-3-2	N	B8113-V30-9000	BUSH	1
08-14-4	N	B3481-V30-0000	RATCHET SHIFT	1
08-14-5	N	I4510-22000	CIRCLIP EX	1
08-14-6	N	I0454-22030	WASHER B SPINE	1
08-14-7	N	B3460-V30-0000	REVERSE GEAR ASSY	1
08-14-7-1	N	B3461-V30-0000	GEAR REVERSE	1
08-14-7-2	N	I1130-223013	BEARING, NEEDLE	1
08-14-8	N	I4104-22010	WASHER	1
08-14-9	N	B3251-V30-9000	SHAFT MAIN TRANSMISSION	1
08-14-10		I4540-15000	CIR CLIP	1
08-14-11		I4104-15010A	WASHER	1
08-15		I6100-62043	BEARING, BALL, RADIAL	1
08-16		B4231-V30-0000	FORK SHIFT	1
08-17		B4241-V30-0000	SHAFT GEAR SHIFT	1
08-18		B4300-V30-0000	DRUM COMP GEAR SHIFT	1
08-18-1	N	B4301-V30-0000	DRUM GEAR SHIFT	1
08-18-2	N	B4302-V30-0000	GEAR SHAFT RETURN	1
08-18-3	N	I4104-13110	WASHER	1


08-18-4	N	B4303-V30-0000	SPRING GEAR SHAFT RETURN	1
08-18-5	N	B4304-V30-0000	COLLAR SHAFT	1
08-19		B461A-V30-0000	SPINDLE ASSY SHIFT	1
08-19-1		B4610-V30-0000	SPINDLE COMP SHIFT	1
08-19-2		I4540-1201A	CIRCLIP	2
08-20		I4301-10140	KNOCK PIN	2

9. GEAR SHAFT LEVER · SAFETY SWITCH




ITEM	AVAIL	PART NO.	NAME	QTY
09			GEAR SHAFT LEVER, SAFETY SWITCH	
09-1		B4640-V30-9000	SHIFT COMP ROD	1
09-1-1		B4641-V30-0001	SHAFT ROD	1
09-1-2		B4642-V30-9000	HANDLE PLASTICS	1
09-1-3		I3600-06020-0G	SCREW FLAT	1
09-2		I3892-05016-0C	SCREW WASHER	2
09-3		B1395-V30-0000	GASKET MISSION COVER	1
09-4		C2963-A09-0000	CLAMPER PULSER CORD	1
09-5		B4622-V30-0000	FIXING SUPPORT CATCH	1
09-6		B4643-V30-0000	FIXED SUPPORT ROD SHIFT	1
09-7		I4104-08515	WASHER	2
09-8		B4644-V30-0000	SPRING ROD SHIFT	1
09-9		I4201-46195	SPLIT PIN	1
09-10		B4645-V30-0000	PIN ROD SHIFT	1
09-11		I5701-06025-0C	FLANGE BOLT, HEX.	1
09-12		I1206-A00-0000	OIL SEAL	1
09-13		I5801-06012-0C	FLANGE BOLT, HEX.	2
09-14		I2800-12015-0C	BOLT, HEX.	1
09-15		I4104-12120	WASHER	1
09-16		B4624-V30-0000	SPRING TRANSMISSION PLATE	1
09-17		B4623-V30-0000	PLATE TRANSMISSION	1
09-18		I5701-06010-0C	BOLT , HEXAGON HEAD	1
09-19		I5701-06040-0C	BOLT , HEXAGON HEAD	10
09-20		A8254-V30-0000	BOSS (B)	2
09-21		A1103-V30-0000	RUBBER BUSH ENGINE HANGER	2
09-22		C510A-V30-0000	BACK POSITION SW	1
09-23		A1332-A09-0000	GAUGE OIL LEVEL	1

10.AIR CLEANER




ITEM	AVAIL	PART NO.	NAME	QTY
10			AIR CLEANER	
10-1		A720A-V30-0001	AIR CLEANER ASSY	1
10-1-1		A7230-V30-0001	CASE AIR / C	1
10-1-2		A7214-A11-0000	SEAL AIR CLEANER COVER	2
10-1-3		A7205-A12-0000	FILTER PAPER ASSY.	1
10-1-4		A7231-V30-0001	COVER AIR/C	1
10-1-5		A7256-A04-0000	BAND AIR CLEANER CONNECTING TUBE	1
10-1-6		I3903-320B0	SELF-TAPPING SCREW	4
10-1-7		I3903-430B0	SELF-TAPPING SCREW	2
10-1-8		A7253-V30-0000	AIR CLEANER CONNECTING TUBE	1
10-1-9		A7364-A11-0000	B TUBE BERATHER	1
10-2		A736A-V30-8000	CATCH TANK ASSY	1
10-3		I5701-06025-0C	FLANGE BOLT, HEX.	2


11. CARBURETOR



ITEM	AVAIL	PART NO.	NAME	QTY
11			CARBURETOR (MANUAL CHOKE WITHOUT THREE	




ITEM	AVAIL	PART NO.	NAME	QTY
11			CARBURETOR (MANUAL CHOKE WITH THREE THR	



ITEM	AVAIL	PART NO.	NAME	QTY
11			CARBURETOR (AUTO-BY/STARTER)	
11-1		A610A-V30-0000	CARBURETOR ASSY.	1
11-1-1		AC001-M1	SCREW	4
11-1-2		KAB44010-M1	PLATE FIXED PISTON COVER (B)	1
11-1-3		KAB43910-M1	PLATE FIXED PISTON COVER (A)	1
11-1-4		KAB43820-M1	VACUUM PISTON COVER ASSY	1
11-1-5		KAB73710-M1	PISTON SPRING	1
11-1-6		KAB43610-M1	SPRING PLACE	1
11-1-7		KAB73320-M1	JET NEEDLE	1
11-1-8		KAB43440-M1	VACUUM PISTON COMP	1
11-1-9		KAB41710-M1	THROTTLE ADJUSTING	1
11-1-10		A1046-M1	WASHER	1
11-1-11		KAB41810-M1	AIR SPRING	1
11-1-12		KAB41930-M1	A.C.V DIAPHRAGM ASSY	1
11-1-13		KAB42010-M1	A.C.V SPRING	1
11-1-14		KAB40410-M1	A.C.V COVER	1
11-1-15		AC036-M1	SCREW+WASHER	2
11-1-16		A0004-V30-0000	BEAR TUBE COMP	1
11-1-17		A0005-V30-0000	THREE THROUGH TUBE COMP	1
11-1-18		KAB41610-M1	CABLE FIXED SEAT	1
11-1-19		AC034-M1	SCREW	2
11-1-20		KAB42410-M1	FLOAT PIN	1
11-1-21		KAB4CC20-M1	NEEDLE VALVE ASSY.	1
11-1-22		KAB73010-M1	SLOW JET	1
11-1-23		KAB42910-M1	NEEDLE JET	1
11-1-24		KAB73110-M1	NEEDLE JET HOLDER	1
11-1-25		KAB83104	MAIN JET (# 104)	1
11-1-26		KAB42310-M1	FLOAT ASSY.	1
11-1-27		A0003-V30-0000	CARB CHAMBER COMP	1
11-1-27-1		KAB45710-M1	CHAMBER O-RING	1
11-1-28		AC033-M1	SCREW	4
11-1-29		KAB40G04-M1	AIR ADJUSTING SCREW ASSY.	1
11-1-30		KAB47210-M1	OIL SEAL	1
11-1-31		KAB40310-M1	AUTO-BY/STARTER SEAT	1
11-1-32		KAB45810-M1	PLATE AUTO-BY/STARTER	1
11-1-33		AC037-M1	SCREW+WASHER	1
11-1-34		KAB47610-M1	AUTO-BY/STARTER	1
11-1-35		KAB47611-M1	AUTO-BY/STARTER COVER	1


11-1-36		I3895-05016-1H	SCREW PAN	2
11-2		A7910-V30-0000	CABLE ASSY THROT	1

12. OIL COOLER




ITEM	AVAIL	PART NO.	NAME	QTY
12			OIL COOLER	
12-1		I902A-V30-8000	COOLER ASSY OIL	1
12-1-1		I9020-V30-9900	COOLER ASSY OIL	1
12-1-2		A9121-V30-9000	OIL HOSE COMP INLET	1
12-1-3		A9122-V30-9000	OIL HOSE COMP OUTLET	1
12-1-4		I0002-V30-0000	BOLT OIL PASS	2
12-1-5		I4104-12514	WASHER	4
12-2		I0002-V30-0000	BOLT OIL PASS	2
12-3		I4104-12514	WASHER	4

13. ENGINE




ITEM	AVAIL	PART NO.	NAME	QTY
13			ENGINE	
13-1		AA000-V30-2000	ENGINE(AUTO CHOKE)	1
13-2		B0100-FID0-0000	INLET TUBE , CVT	1
13-2-1		B0103-FID0-0000	INLET TUBE , CVT SPONGE	1
13-3		B0200-FIA0-0000	EXH TUBE , CVT	1
13-4		A7215-V30-0000	DUCT AIR CLEANER IN	1
13-5		A1105-FIA0-0000	ENGINE RUBBER PLUG	2
13-6		B0101-FID0-0000	EXH TUBE , CVT CONNECTING TUBE	1
13-7		I0119-06802	BOLT, HEX.	1

14. MUFFLER(U.S)




ITEM	AVAIL	PART NO.	NAME	QTY
14			MUFFLER(U.S)	

14. MUFFLER




ITEM	AVAIL	PART NO.	NAME	QTY
14			MUFFLER(E.P)	
14-1		A830A-FIA0-9000	EXHAUST PIPE ASSY.	1
14-1-1		A830B-FIA0-1000	DRIVE CHAIN COVER	1
14-1-2		A830C-FIA0-1000	ANTI-LOOSEN STRIP	2
14-1-3		A830D-FIA0-0000	FRONT EXHAUST PIPE COVER	1
14-1-4		A830F-FIA0-0000	BOLT WASHER	4
14-1-5		A8303-FIA0-0000	SPARK ARRESTER	1
14-1-6		A830G-FIA0-0000	SCREW	1
14-2		I7507-FIA0-0000	BOLT, HEX.	1
14-3		I0149-08036-01	BOLT,FLANGE	1
14-4		I0179-06850	NUT	2
14-5		I5611-08200	HEX. FLANGE NUT, SAFETY	1

15.FRAME



ITEM	AVAIL	PART NO.	NAME	QTY
15			FRAME	
15-1		E0100-FID0-0000	FRAME COMP.	1
15-2	N	E0101-5EA0-0000	FRAME NUMBER PLATE	1
15-3		H750A-5BA1-0000	NAIL, PULL	2
15-4		E0351-5EA0-0000	FLANGE BOLT, HEX.	3
15-5		I5611-10200	HEX. FLANGE NUT, SAFETY	5
15-6		F4309-5EA0-0000	STICKER, MFD.	1
15-7		I2501-06080-0B	BOLT, HEXAGON HEAD	4
15-8		G7223-5EB0-0000	RUBBER PAD	1
15-9		I6600-06000	GREASE VALVE	1
15-10		E0209-5EA0-9000	CAP, GREASE VALVE	1
15-11		I0149-08016	FLANGE BOLT, HEX.	2
15-12		E0350-FIA0-0000	ENGINE SUSPENSION ASSY. ,LEFT	1
15-13		E0353-FIA0-0000	ENGINE SUSPENSION ASSY. ,RIGHT	1
15-14		E0352-FIA0-0000	BOLT, QUAD	2
15-15		E0107-FID0-0000	LEFT, FIXED PLATE, FRONT FENDER	1
15-16		E0108-FID0-0000	RIGHT, FIXED PLATE, FRONT FENDER	1
15-17		E0106-FID0-0000	FRONT, FIXED PLATE, FRONT FENDER	1
15-18		I0149-06012	FLANGE BOLT, HEX.	6
15-19		E0105-FID0-0000	FIXED PLATE, FRONT FENDER	1
15-20		A7509-FID0-0000	LH. BACK MIRROR ASSY	2


16.FENDER



ITEM	AVAIL	PART NO.	NAME	QTY
16			FENDER	
16-1		F4300-FID0-0800	FRONT FENDER (BLACK)	1
16-1		F4300-FID0-5400	FRONT FENDER (BLUE)	1
16-1		F4300-FID0-1100	FRONT FENDER (YELLOW)	1
16-2		F4301-FID0-0700	FRONT CENTRAL COVER(SILVER)	1
16-2		F4301-FID0-5400	FRONT CENTRAL COVER(BLUE)	1
16-2		F4301-FID0-1100	FRONT CENTRAL COVER(YELLOW)	1
16-3		E0415-FID0-0000	FILTER NET	1
16-4		H3500-FID0-0800	REAR FENDER(BLACK)	1
16-4		H3500-FID0-5400	REAR FENDER(BLUE)	1
16-4		H3500-FID0-1100	REAR FENDER(YELLOW)	1
16-5		H3620-FID0-0800	FOOTREST, RIGHT	1
16-6		H3520-FID0-0800	FOOTREST, LEFT	1
16-7		E0417-5EE0-0000	FILTER NET PLUG	4
16-8		I0119-06802	BOLT, HEX.	5
16-9		E320A-FID0-0800	COVER, HANDLE BAR (BLACK)	1
16-9		E320A-FID0-5400	COVER, HANDLE BAR (BLUE)	1
16-9		E320A-FID0-1100	COVER, HANDLE BAR (YELLOW)	1
16-9-1		C3101-FIA0-0000	INDICATE(RED)	1
16-9-2		C3102-FIA0-0000	INDICATE(BLUE)	1
16-9-3		C3103-FIA0-0000	INDICATE(GREEN)	1
16-10		H7107-5EB0-0000	EMBLEM, E-TON LOGO(SILVER)	1
16-11		I0149-06823-01	BOLT, FLANGE(M6×23)	4
16-12		I5611-06200-0G	HEX. FLANGE NUT, SAFETY	4
16-13		I0119-06821	BOLT, HEX.	4
16-14		H7128-FID0-4200	STICKER, REAR BODY (RED)(L)	1
16-14		H7128-FID0-1100	STICKER, REAR BODY (YELLOW)(L)	1
16-14		H7128-FID0-0700	STICKER, REAR BODY (SILVER)(L)	1
16-15		H7129-FID0-0700	STICKER, REAR BODY (SILVER)(R)	1
16-15		H7129-FID0-4200	STICKER, REAR BODY (RED)(R)	1
16-15		H7129-FID0-1100	STICKER, REAR BODY (YELLOW)(R)	1
16-16		I8557-06012	SCREW WASHER	2
16-17		H7101-FIA0-9000	STICKER, WARNING (PASSENGER)	1
16-18		H7102-5EA1-9000	STICKER, CE	1


16-19		H7103-FID0-0000	STICKER, VIPER-150 (L)	1
16-20		H7104-FID0-0000	STICKER, VIPER-150 (R)	1
16-21		H7126-FID0-0000	STICKER,REAR FENDER(L)	1
16-22		H7127-FID0-0000	STICKER,REAR FENDER(R)	1
16-23		H7124-FID0-1100	FRONT BODY STICKER (YELLOW)(L)	1
16-23		H7124-FID0-4200	FRONT BODY STICKER (RED)(L)	1
16-23		H7124-FID0-0700	FRONT BODY STICKER (SILVER)(L)	1
16-24		H7125-FID0-0700	FRONT BODY STICKER (SILVER) (R)	1
16-24		H7125-FID0-1100	FRONT BODY STICKER (YELLOW) (R)	1
16-24		H7125-FID0-4200	FRONT BODY STICKER (RED) (R)	1
16-25		H7129-FIA0-0000	STICKER,INDICATE GEAR	1
16-26		H7131-FIB0-0000	STICKER,POWER SUPPLY	1
16-27		I8310-FIA0-0000	PLASTIC SCREW	2
16-28		I4104-06515	WASHER	2
16-29		H7137-FID0-0000	STICKER, ON"N" SHIFT TO START	0

17. SWING ARM




ITEM	AVAIL	PART NO.	NAME	QTY
17			SWING ARM	
17-1		E0200-FIA0-1000	ARM, SUSPENSION, L.H.	1
17-2		E0210-FIA0-1000	ARM, SUSPENSION, R.H.	1
17-3		E0201-FIA0-0000	BUSH, ARM SUSPENSION	8
17-4		E0209-FIA0-0000	SPACER	4
17-5		E2205-4HA0-0000	SWING ARM SEAL COVER (25.4)	8
17-6		E220A-FID0-0001	SWING ARM COMP.	1
17-7		E2208-5EA0-0000	SWING ARM OIL LINER	2
17-8		E2209-FIA0-0000	SPACER	1
17-9		E2205-5EA0-0000	OIL SEAL	2
17-10		E2202-FIA0-0000	RUBBER SLEEVE	1
17-11		E2201-FIA0-0000	FLANGE BOLT, HEX.	1
17-12		I5611-14200	HEX. FLANGE NUT, SAFETY	1
17-13		I0149-10080	FLANGE BOLT, HEX.	4
17-14		I5611-10200	HEX. FLANGE NUT, SAFETY	4
17-15		I6600-06000	GREASE VALVE	5
17-16		E0209-5EA0-9000	CAP, GREASE VALVE	5
17-17		E221A-FID0-0000	CHAIN TENSIONER	1
17-17-1		E2210-FID0-0000	IDLER BRACKET	1
17-17-2		E2213-FID0-0000	TENSION IDLER	1
17-17-3		E2215-FID0-0000	CIRCLIP	1
17-17-4		E2214-FID0-0000	WASHER	1
17-17-5		E2216-FID0-0000	BEARING	2
17-17-6		E2212-FID0-0000	STUD	1
17-17-7		E2211-FID0-0000	RETURN SPRING	1
17-17-7		E2211-FID0-0000	RETURN SPRING	1
17-18		I4104-08010	WASHER	1

18. SEAT




ITEM	AVAIL	PART NO.	NAME	QTY
18			SEAT	
18-1		G7200-FID0-0700	SEAT ASSY.(SILVER)	1
18-1		G7200-FID0-1100	SEAT ASSY.(YELLOW/BLACK)	1
18-1		G7200-FID0-4200	SEAT ASSY.(RED/BLACK)	1

19. FUEL TANK, OIL TANK




ITEM	AVAIL	PART NO.	NAME	QTY
19			FUEL TANK	
19-1	N	A7500-FID0-0001	FUEL TANK COMP	1
19-2		A751A-FIA0-1000	FUEL FILTER ASSY.	1
19-2-1		A7519-FIA0-1000	FUEL FILTER	1
19-2-2		A7516-5EA0-0000	CLIP(A)	2
19-2-3		A7517-FIA0-0000	CLIP	2
19-2-4		A7514-FIA0-0000	FUEL TUBE(A)	2
19-3		A762A-9FA0-0000	FUEL TANK CAP ASSY.	1
19-3-1		A7620-9FA0-0000	FUEL TANK CAP	1
19-3-1		A7620-9FA0-0000	FUEL TANK CAP	1
19-3-2		A7621-9FA0-0000	TUBE, RUBBER	1
19-3-2		A7621-9FA0-0000	TUBE, RUBBER	1
19-4		A7622-9FA0-0000	RUBBER PAD, FUEL TANK CAP	1
19-5		A7510-FIA0-0000	FUEL TANK RUBBER PAD	4
19-6		A6701-FIA0-0000	FUEL COCK ASSY.	1
19-7		A7511-FIA0-0000	RUBBER INSULATOR	4
19-8		C780A-FIA0-0000	METER FUEL LEVER	1
19-9		I7507-06225	BOLT, HEX.	4
19-10		I0200-50160	CROSS BOLT, HEX.	4
19-11		A751B-FIA0-0000	VACUUM TUBE COMP	1
19-11-1		A7518-FIA0-0000	CLIP	2
19-11-1		A7518-FIA0-0000	CLIP	2

19. FUEL TANK, OIL TANK




ITEM	AVAIL	PART NO.	NAME	QTY
19			FUEL TANK	
19-1		A7500-FIE0-0001	FUEL TANK COMP	1
19-1		A7500-FIE0-F001	FUEL TANK COMP	1
19-2		A751A-FIA0-1000	FUEL FILTER ASSY.	1
19-3		A762A-9FA0-0000	FUEL TANK CAP ASSY.	1
19-3-1		A7620-9FA0-0000	FUEL TANK CAP	1
19-3-2		A7621-9FA0-0000	TUBE, RUBBER	1
19-4		A7622-9FA0-0000	RUBBER PAD, FUEL TANK CAP	1
19-5		A7510-FIA0-0000	FUEL TANK RUBBER PAD	4
19-6		A6701-FIA0-0000	FUEL COCK ASSY.	1
19-7		A7511-FIA0-0000	RUBBER INSULATOR	4
19-8		C780A-FIA0-0000	METER FUEL LEVER	1
19-9		I7507-06225	BOLT, HEX.	4
19-10		I0200-50160	CROSS BOLT, HEX.	4
19-11		A7503-FIA0-0000	VACUUM TUBE COMP	1
19-11-1		I5002-02659	CLIP	2

20. SUSPENSION




ITEM	AVAIL	PART NO.	NAME	QTY
20			SUSPENSION	
20-1		E1105-FID0-0100	SUSPENSION, FRONT(YELLOW)	2
20-1		E1105-FID0-0700	SUSPENSION, FRONT(SILVER)	1
20-2		E2400-FID0-0200	SUSPENSION, REAR(RED)	1
20-3		I0102-10040B	FLANGE BOLT, HEX.	6
20-4		I0468-12006	PIN	2
20-5		I9900-25019	PIN, SPLIT	4

21. FRONT WHEEL




ITEM	AVAIL	PART NO.	NAME	QTY
21			FRONT WHEEL	
21-1		D471A-FID0-0S00	FRONT WHEEL ASSY(21×7-10)	2
21-1-1		D4710-FID0-0000	FRONT WHEEL TIRE (21x7-10)	1
21-1-2		D4601-FIA0-9S00	WHEEL RIM	1
21-2		D4610-FIA0-9000	BRAKE DRUM, FRONT	2
21-2-1		D4612-9FA0-0000	BOLT,STUD	8
21-3		I6150-60030-10	BEARING, BALL, RADIAL	4
21-4		I1307-24035-10	OIL SEAL	4
21-5		D4621-FIA0-0000	OUTER SPACER	2
21-6		D4620-FIA0-0000	INNER SPACER	2
21-7		D4611-9EA0-0000	FLANGE NUT, HEX.	8
21-8		I9905-14200	WASHER	2
21-9		I5500-14100	CASTLE NUT	2
21-10		I4201-46325	SPLIT PIN	2
21-11		D4609-9FA0-0000	RUBBER CAP	2

22. REAR WHEEL




ITEM	AVAIL	PART NO.	NAME	QTY
22			REAR WHEEL	
22-1		D472C-FID0-0S00	REAR WHELL ASSY	1
22-1-1		D471C-FID0-0S00	REAR WHEEL COMP	1
22-1-1-1		D4720-FID0-0000	REAR WHEEL TIRE	1
22-1-1-2		D4602-FID0-0S00	WHEEL RIM	1
22-1-2		D2705-FID0-0000	SHAFT CONNECTER WITH BOLTS	1
22-1-3		D4611-9EA0-0000	FLANGE NUT, HEX.	4
22-2		D472C-FID0-0S00	REAR WHELL ASSY	1
22-2-1		D471C-FID0-0S00	REAR WHEEL COMP	1
22-2-1-1		D4720-FID0-0000	REAR WHEEL TIRE	1
22-2-1-2		D4602-FID0-0S00	WHEEL RIM	1
22-2-2		D2705-FID0-0000	SHAFT CONNECTER WITH BOLTS	1
22-2-3		D4611-9EA0-0000	FLANGE NUT, HEX.	4
22-3		D2309-5EA0-0000	WASHER	2
22-4		I4012-140H0	CASTLE NUT	2
22-5		I4201-46325	SPLIT PIN	2
22-6		D4609-5EA0-0001	RUBBER CAP	2

23. FRONT BRAKE




ITEM	AVAIL	PART NO.	NAME	QTY
23			FRONT BRAKE SYSTEM	
23-1		D5351-FIA0-0000	FRONT BRAKE PANEL COMP., LEFT	1
23-2		D5352-FIA0-0000	FRONT BRAKE PANEL COMP., RIGHT	1
23-3		I5707-06500	FLANGE NUT, HEX.	2
23-4		D312A-A04-8000	FRONT BRAKE SHOE COMP. (80)	2
23-5		D5141-FIA0-1000	FRONT BRAKE ARM CAM	2
23-6		D5145-FIA0-0000	BRAKE INDICATOR,FRONT	2
23-7		D5410-FIA0-0000	FRONT BRAKE ARM	2
23-8		I0020-06030	BOLT	2
23-9		E5450-FIA0-1000	CABLE, FRONT BRAKE(LEFT)	1
23-9-1		E5452-FIA0-1000	NUT,ADJUSTING	1
23-9-1		E5452-FIA0-1000	NUT,ADJUSTING	1
23-10		E5451-FIA0-1000	CABLE, FRONT BRAKE(RIGHT)	1
23-10-1		E5452-FIA0-1000	NUT,ADJUSTING	1
23-10-1		E5452-FIA0-1000	NUT,ADJUSTING	1

24.REAR BRAKE(HYDRAULIC DISC BRAKE)




ITEM	AVAIL	PART NO.	NAME	QTY
24			REAR BRAKE SYSTEM	
24-1		D2310-FIA0-1000	BEARING SEAT ASSY., REAR WHEEL AXLE	1
24-2		D2311-FIA0-0000	SPACER	1
24-3		I6100-6007LLU	BEARING	2
24-4		D2315-FIA0-0000	OIL SEAL	1
24-5		I0141-12036-01	FLANGE BOLT, HEX.	4
24-6		G7130-BCA0-0000	BRAKE CALLIPER	1
24-6-1		G7131-BCA0-0000	BRAKE SHOE COMP	1
24-6-2		G7132-BCA0-0000	BOLT LEAKAGE	1
24-6-3		G7133-BCA0-0000	CAP LEAKAGE	1
24-7		I0105-08035	BOLT FLANGE	2
24-8		D3520-FIA0-0000	BRAKE DISK	1
24-9		D3251-FIA0-0000	BRAKE DISK MOUNTING SEAT	1
24-10		I0110-10811	BOLT, SOCKET	3
24-11		I0401-10034	FLANGE BOLT, HEX.	2
24-12		I0201-10118	WASHER	4
24-13		D3210-FIA0-0000	BRAKE OIL TUBE	1
24-14		G7111-BCA0-0000	BRAKE FUEL TUBE, CLIP	1
24-15		I0149-06012	FLANGE BOLT, HEX.	1
24-16		D2313-FIA0-0000	OIL SEAL(48×62×7)	1
24-18		I9901-08100	WASHER, SPRING	2

25.HANDLE BAR




ITEM	AVAIL	PART NO.	NAME	QTY
25			HANDLE BAR	
25-1		E3100-5EE0-1000	HANDLE BAR ASSY.	1
25-2		E3180-FIA0-0000	LEVEL ASSY., RIGHT	1
25-2-1		E3181-5FA0-0000	LEVEL SET,RIGHT	1
25-2-2		E319A-5FA0-0000	LEVEL ACCELERATE	1
25-2-3		E3183-FIA0-0000	COVER LEVER	1
25-2-4		E3188-FIA0-0000	GASKET	1
25-2-5		I8506-04016	SCREW,PAN HEAD	2
25-3		D3200-FIA0-0000	BRAKE MASTER CYLINDER,LEFT	1
25-3-1		D3201-FIA0-0000	LEVEL,LEFT	1
25-3-1		D3201-FIA0-0000	LEVEL,LEFT	1
25-3-2		D3202-FIA0-0000	BRAKE SWITCH ASSY.	1
25-3-2		D3202-FIA0-0000	BRAKE SWITCH ASSY.	1
25-4		E3166-5EA0-0000	GRIP	2
25-5		E3112-5EA0-0000	BOTTOM,HANDLE BAR CLAMP	2
25-6		E3110-5EA0-0000	CAP,HANDEL BAR CLAMP(L)	1
25-7		E3111-5EA0-0000	CAP,HANDEL BAR CLAMP(R)	1
25-8		I0050-06025	BOLT, SOCKET	4
25-9		I5611-10200	HEX. FLANGE NUT, SAFETY	2
25-10		E3102-5EE0-1000	HANDLE BAR PROTECT FOAM(20×42×220L)	1
25-11		E3101-5EE0-1000	HANDLE BAR PROTECT (W150×222L)	1

26.BUMPER,FOOTREST BAR




ITEM	AVAIL	PART NO.	NAME	QTY
26			BUMPER, FOOTREST	
26-1		E0700-FIA0-0000	FOOTREST BAR	1
26-2		E0700-FID0-0000	FOOTREST BAR	1
26-3		I7507-FIA0-0000	BOLT, HEX.	8
26-4		I5611-06200-0G	HEX. FLANGE NUT, SAFETY	3
26-5		I0149-06823	SCREW	7
26-6		I0119-06802	BOLT, HEX.	1
26-7		E0400-FID0-0000	BUMPER ASSY.	1
26-8		I0105-08035	BOLT FLANGE	2
26-9		E0410-FID0-0000	REAR BAR ASSY.	1
26-10		I0149-08016	FLANGE BOLT, HEX.	6
26-11		I9901-08100	WASHER, SPRING	4
26-12		E0402-FID0-0000	COLLAR, BUMPER	2
26-13		H1104-BCA0-0000	COLLAR	2
26-14		F0703-BCA0-0000	DAMPER	2

27.REAR WEHEEL AXLE




ITEM	AVAIL	PART NO.	NAME	QTY
27			REAR WHEEL AXLE	
27-1		D0100-FIB0-0000	DRIVE CHAIN ASSY.	1
27-1-1		D0104-FIC0-0000	MASTERLINK	1
27-2		D0101-FIA0-1000	PROTECT COVER	1
27-3		D2301-5IK0-0000	REAR AXLE	1
27-4		D0110-FIA0-0000	SPROCKET HOLDER,REAR ASSY.	1
27-4-1		D0111-FIA0-0000	SPROCKET HOLDER,REAR(34T)	1
27-4-1		D0111-FIA0-0000	SPROCKET HOLDER,REAR(34T)	1
27-4-2		D1111-FIA0-0000	GEAR(520X34T)	1
27-4-2		D1111-FIA0-0000	GEAR(520X34T)	1
27-4-3		D2706-9EA0-0000	BOLT	4
27-4-3		D2706-9EA0-0000	BOLT	4
27-4-4		I5611-10200	HEX. FLANGE NUT, SAFETY	4
27-4-4		I5611-10200	HEX. FLANGE NUT, SAFETY	4
27-5		D2302-FIA0-0000	NUT REAR WHEEL AXLE(M28×1.5)	2
27-6		D0120-FIA0-0001	CHAIN ADJUSTER COMP.	1
27-7		I0149-08016	FLANGE BOLT, HEX.	7
27-8		D0102-FIA0-0000	DRIVE CHAIN COVER	1
27-9		D2303-GJA0-0000	PLATE FIXED REAR AXLE(USED WITH D2301-GJ)	1

28.STEERING



ITEM	AVAIL	PART NO.	NAME	QTY
28			STEERING	
28-1		E3200-FID0-0000	SHAFT ASSY., STEERING	1
28-2		E3201-FIA0-0000	OIL LINER	2
28-3		E3204-FIA0-0000	O-RING	2
28-4		I5611-10200	HEX. FLANGE NUT, SAFETY	7
28-5		I9900-25019	PIN, SPLIT	0
28-6		E0258-GJA0-0000	STEERING TIE-ROD ASSYLEFT	1
28-6-1		E0251-FIA0-1000	BOLT,STUD	1
28-6-2		E0252-5EA0-0000	NUT (R)	1
28-6-3		E0253-5EA0-0000	NUT (L)	1
28-6-4		E0255-GJA0-0000	UNIVERSAL JOINT(L)	1
28-6-5		E0256-GJA0-0000	UNIVERSAL JOINT(R)	1
28-7		E0205-FIA0-1000	KNUCKLE, LEFT	1
28-7-1		I6600-06000	GREASE VALVE	1
28-8		E0215-FIA0-1000	KNUCKLE, RIGHT	1
28-8-1		I6600-06000	GREASE VALVE	1
28-9		E0211-9FA0-0000	SLEEVE	2
28-10		E0203-9FA0-0000	CAP	4
28-11		I5701-10105-0A	FLANGE BOLT, HEX.	2
28-12		E0209-5EA0-9000	CAP, GREASE VALVE	2
28-13		E3209-FIA0-0000	OIL SEAL(31.8×37.8×4)	2
28-14		E3202-FIA0-0000	HOLDER, STEERING SHAFT	2
28-15		E3203-FIA0-0000	FIX PLATE, STEERING SHAFT	1
28-16		I0020-08060	BOLT, HEX.	2
28-17		E3210-FID0-0000	HOLDER, STEERING SHAFT PRESSED	1
28-18		E3208-FIA0-0000	STEERING , COLLAR	2
28-19		E0259-GJA0-0000	STEERING TIE-ROD ASSYRIGHT	1
28-19-1		E0251-FIA0-1000	BOLT,STUD	1
28-19-2		E0252-5EA0-0000	NUT (R)	1
28-19-3		E0253-5EA0-0000	NUT (L)	1
28-19-4		E0255-GJA0-0000	UNIVERSAL JOINT(L)	1
28-19-5		E0256-GJA0-0000	UNIVERSAL JOINT(R)	1
28-20		I4608-09424	O-RING	1
28-21		E3230-FID0-0000	FIXED PLATE,ELECTRICAL EQUIPMENT	1
28-22		I0149-08016	FLANGE BOLT, HEX.	2
28-23		E3240-FID0-0000	STEERING CLIP	1
28-24		I0119-06802	BOLT, HEX.	1


29.ELECTRICAL EQUIPMENT



ITEM	AVAIL	PART NO.	NAME	QTY
29			ELECTRICAL EQUIPMENT	
29-1		C2100-FID0-0000	MAIN WIRE ASSY.	1
29-1-1		C2010-FIA0-0000	FUSE (10A)	1
29-2		C2101-FIA0-0000	POSITIVE HIGHT PRESSURE CABLE	1
29-3		C2102-FIA0-1000	NEGATIVE LOW PRESSURE CABLE	1
29-4		C1500-FIA0-0000	BATTERY	1
29-5		C1501-9FA0-0000	FOAM STICK, BATTERY	2
29-6		C1502-9FA0-0000	RUBBER CLAMP, BATTERY(89L)	1
29-7		C5010-9FA0-0000	MAIN SWITCH	1
29-7-1		C5013-9FA0-0000	MATERIAL KEY (RIGHT CUT)	1
29-7-1		C5013-9FA0-0000	MATERIAL KEY (RIGHT CUT)	1
29-7-2		C5018-9FA0-0000	MATERIAL KEY (LEFT CUT)	1
29-7-2		C5018-9FA0-0000	MATERIAL KEY (LEFT CUT)	1
29-8		C5200-FIA0-0000	LEVER HOLDER ASSY., LEFT	1
29-9		I8556-06016	SCREW WASHER	1
29-10		C1802-FIB0-0000	POWER SUPPLY	1
29-11		C502A-FID0-0000	HAED LIGHT ASSY(L)	1
29-11-1		C5070-FID0-0000	HEAD LIGHT COVER (L)	1
29-11-2		C5020-9PA0-0000	HAED LIGHT(L)	1
29-11-2-1		C5003-5PA0-0000	BULB	1
29-11-3		E0110-FID0-0000	HEAD LIGHT HOLDER	3
29-11-4		I2804-04010-5C	TAPPING SCREW, TRUSS	6
29-12		C503A-FID0-0000	HAED LIGHT ASSY(R)	1
29-12-1		C5080-FID0-0000	HEAD LIGHT COVER (R)	1
29-12-2		C5030-9PA0-0000	HAED LIGHT(R)	1
29-12-2-1		C5003-5PA0-0000	BULB	1
29-12-3		E0110-FID0-0000	HEAD LIGHT HOLDER	3
29-12-4		I2804-04010-5C	TAPPING SCREW, TRUSS	6
29-13		H9020-FIA0-0000	TOOL PACK	1
29-14		H3936-5AA0-0000	WIRE CLAMP	1
29-15		C8110-5BA0-E000	HORN	1
29-16		I3401-05020-07	BOLT, HEX.	1
29-17		I8556-06012	SCREW PAN	1
29-18		C8400-EMA0-0000	BUZZER	1
29-19		C0410-V30-9001	UNIT COMP C.D.I (SPEED LIMIT)	1
29-20		C051A-FIA0-0010	IGNITION COIL ASSY.	1
29-21		C1600-B00-9000	RECTIFIER & REGULATOR	1


29-22		C1850-V30-0000	PTC CONTROLLER	1
29-23		C5850-A04-0000	STARA RELAY	1
29-24		C576A-V30-0000	COUPLER LIGHT UNIT	1
29-25		I8557-06012	SCREW WASHER	1
29-26		I2600-03012	SCREW, PAN	2
29-27		I2020-60000	NUT, HEX.	2
29-28		I0153-06839	SCREW	2
29-29		I0119-06802	BOLT, HEX.	6

30.PACKING CASE,EXTERNAL



ITEM	AVAIL	PART NO.	NAME	QTY
30			PACKING CASE,EXTERNAL	
30-1		H9500-FIB0-0000	PACKING CASE,EXTERNAL	1
30-2		H990A-FID9-0000	OWNER'S MANUAL	1
30-3		C5031-FID0-0000	TAIL LIGHT	1
30-3-1		C5004-5BA1-0000	LAMP	1
30-3-1		C5004-5BA1-0000	LAMP	1
30-4		H9022-5EA0-0000	PRESSURE METER	1
30-5		I5611-06200-0G	HEX. FLANGE NUT, SAFETY	2

31.OPTIONAL



ITEM	AVAIL	PART NO.	NAME	QTY
31			OPIIONAL	
31-1		E041A-FID0-0000	REAR PACK ASSY	1
31-01-01		F4001-FIC0-0000	CARRIER COVER REAR	1
31-01-01-1		C1501-FIB0-0000	FOAM-RUBBER STICK	7
31-01-01-01		C1501-FIB0-0000	FOAM-RUBBER STICK	5
31-01-01-2		H7113-9FB0-0000	CARRIER COVER,STICKER	1
31-01-01-02		H7113-9FB0-0000	CARRIER COVER,STICKER	1
31-01-02		E0117-9EA0-0000	SCREW, TRUSS	6
31-01-03		E0411-FID0-0000	REAR PACK	1
31-01-04		E0402-9FA0-0000	COLLAR,BUMPER	2
31-01-05		I0105-08040	BOLT, FLANGE	4
31-01-06		I5616-08200	NUTFLANGE CHECK	2
31-01-07		E0402-FIE0-0000	COLLAR, BUMPER	2
31-2		MH8402-100-0800	LUGGAGE BAGS	1

No picture.

ITEM	AVAIL	PART NO.	NAME	QTY
35			MANUAL CHOKE KIT	
35-01		A611B-V30-0000	MANUAL CHOKE KIT	1
35-01-1		A6110-V30-0000	MANUAL CHOKE COMP	1
35-01-01		A6110-V30-0000	MANUAL CHOKE COMP	1
35-01-1-1		A6154-V30-0000	MANUAL CHOKE SEAT	1
35-01-01-1		A6154-V30-0000	MANUAL CHOKE SEAT	1
35-01-01-01		A6152-V30-0000	SPRING	1
35-01-1-2		A6152-V30-0000	SPRING	1
35-01-01-2		A6152-V30-0000	SPRING	1
35-01-01-02		A6153-V30-0000	MANUAL PISTON VALVE	1
35-01-1-3		A6153-V30-0000	MANUAL PISTON VALVE	1
35-01-01-3		A6153-V30-0000	MANUAL PISTON VALVE	1
35-01-01-03		A6154-V30-0000	MANUAL CHOKE SEAT	1
35-01-1-4		A6158-V30-0000	O-RING	1
35-01-01-4		A6158-V30-0000	O-RING	1
35-01-01-04		A6155-V30-0000	BEND TUBE SHEATH	1
35-01-1-5		A6157-V30-0000	PISTON VALVE SEAT	1
35-01-01-5		A6157-V30-0000	PISTON VALVE SEAT	1
35-01-01-05		A6156-V30-0000	BEND TUBE	1
35-01-1-6		A6156-V30-0000	BEND TUBE	1
35-01-01-6		A6156-V30-0000	BEND TUBE	1
35-01-01-06		A6157-V30-0000	PISTON VALVE SEAT	1
35-01-1-7		A6155-V30-0000	BEND TUBE SHEATH	1
35-01-01-7		A6155-V30-0000	BEND TUBE SHEATH	1
35-01-01-07		A6158-V30-0000	O-RING	1
35-01-2		A7920-V30-0000	CABLE	1
35-01-02		A7920-V30-0000	CABLE	1
35-01-3		C5200-FIA0-9000	LEVER HOLDER ASSY., LEFT	1
35-01-03		C5200-FIA0-9000	LEVER HOLDER ASSY., LEFT	1

35-01-3-1		C5201-FIA0-0000	LEVER HOLDER , LEFT	1
35-01-03-1		C5201-FIA0-0000	LEVER HOLDER , LEFT	1
35-01-03-01		C5201-FIA0-0000	LEVER HOLDER , LEFT	1
35-01-3-2		C5202-5EE0-0000	AIR CUT, LEVER	1
35-01-03-2		C5202-5EE0-0000	AIR CUT, LEVER	1
35-01-03-02		C5202-5EE0-0000	AIR CUT, LEVER	1

No picture.

ITEM	AVAIL	PART NO.	NAME	QTY
36			TOOL	
36-1		C1110-B00-FT1	TACKING ACG FLY WHEEL TOOL	1