

PARTS CATALOGUE

VIPER 70 RXL70-4S(2008)




CONTENTS

PARTS ITEM:

- 01 CRANK CASE
- 02 CYLINDER HEADHEAD COVER
- 03 CYLINDERPISTONCRANKSHAFT
- 04 COVER R CRANK CASE
- 05 CARBURETOR
- 06 DRIVEN PULLEY (CVT)
- 07 START MOTOROIL PUMP
- 08 FAN COVERGENERATOR
- 09 TRANSMISSION
- 10 AIR CLEANER
- 11 PREARRANGE
- 12 ENGINE
- 13 MUFFLER
- 14 FRAME
- 15 A ARMFOOTRESTFEND BAR
- 16 FENDER
- 17 SEAT
- 18 FUEL TANK
- 19 SUSPENSION
- 20 FRONT WHEEL
- 21 REAR WHEEL
- 22 FRONT BRAKE SYSTEM
- 23 REAR BRAKE SYSTEM
- 24 HANDLE BAR
- 25 REAR WHEEL AXLE
- 26 SWING ARM SUB
- 27 STEERING

- 28 ELECTRICAL EQUIPMENT
 - 29 PACKING CASE, EXTERNAL
 - 30 MANUAL CHOKE KIT
 - 31 ACCESSORIES
 - 32 SERVICE KITSBRAKE CALIPER
- N & sign meaning: not available to sale**


1.CRANK CASE



ITEM	AVAIL	PART NO.	NAME	QTY
01			CRANK CASE	
01-1	N	A1100-A12-0900	CRANK CASE COMP, RIGHT	1
01-2		A1192-A26-6000	GASKET, CRANK CASE	1
01-3		A1103-A04-0000	RUBBER BUSH ENGINE HANGER	2
01-4		I6001-06045-0H	FLANGE BOLT, HEX.	1
01-5		I4301-08140	KNOCK PIN	4
01-6		A1350-A26-0000	TUBE COMP, CVT INLET	2
01-6-1		A1351-A26-0000	TUBE, CVT INLET	1
01-6-2		A1352-A26-0000	PLUG	1
01-6-3		A7256-A26-0000	AIR DUCT CLAMP	1
01-7		A1203-A26-0000	REAR SHOCK ABSORBER BUSHING	1
01-8		I6100-62034SPC	BEARING, BALL RADIAL	3
01-9		I1204-A11-0000	OIL SEAL	1
01-10		I6100-62030	BEARING, BALL RADIAL	1
01-11		I6100-62013-10	BEARING, BALL, RADIAL	1
01-12		I1130-081210A	BEARING, NEEDLE	2
01-13		I1202-A26-9000	OIL SEAL (L)	1
01-14		I2800-12015-0C	BOLT, HEX.	1
01-15		I4104-12120	WASHER	1
01-16		I5801-08012-0H	FLANGE BOLT, HEX.	1
01-17		I4102-08020	WASHER	1
01-18		I0031-07168-0H	STUD BOLT A, CYLINDER	2
01-19		I0032-07176-0H	STUD BOLT B, CYLINDER	2
01-20		I5701-06035-0H	FLANGE BOLT, HEX.	5
01-21		I5701-06042-0H	FLANGE BOLT, HEX.	2
01-22		B825A-A14-0001	SPINDLE ASSY KICK START	1
01-22-1		B8250-A14-0001	SPINDLE COMP KICK START	1
01-22-1	N	B8250-A14-0001	SPINDLE COMP KICK START	1
01-22-2		B8281-A14-0000	SPG KICK STARTER	1
01-22-2		B8281-A14-0000	SPG KICK STARTER	1
01-22-3		B8253-A14-0000	BOSS KICK SPINDLE	1
01-22-3		B8253-A14-0000	BOSS KICK SPINDLE	1
01-23		B8255-A14-0000	BOSS DISTANCE	1
01-24		I4104-14520A	WASHER	1
01-25		I4510-14000	CIRCLIP EX	1
01-26		B823A-A14-0001	GEAR ASSY STARTER IDLE	1
01-26-1		B8230-A14-0001	GEAR COMP STARTER IDLE	1
01-26-1	N	B8230-A14-0001	GEAR COMP STARTER IDLE	1

01-26-2		B8223-A14-0000	SPG. FRICTION START GEAR	1
01-26-2	N	B8223-A14-0000	SPG. FRICTION START GEAR	1
01-27		I4102-10505	WASHER	1
01-28		A1341-A26-0100	COVER L SIDE	1
01-29		I6130-60380-10	BEARING, BALL, RADIAL	1
01-30		A1395-A26-6000	GASKET, L COVER	1
01-31		I6001-06035-0H	FLANGE BOLT, HEX.	8
01-32	N	A1200-A26-0900	CRANK CASE COMP, LEFT	1


2. CYLINDER HEAD 、 HEAD COVER



ITEM	AVAIL	PART NO.	NAME	QTY
02			CYLINDER HEADHEAD COVER	
02-1		A230A-A26-6000	COVER ASSY HEAD CYLINDER	1
02-1-1		A2301-A26-0000	COVER HEAD CYLINDER	1
02-1-2		A2305-A11-0000	JOINT COMP BREATHER	1
02-1-3		A2302-A11-0000	PLATE BREATHER SEPARATOR	1
02-1-4		I3903-380H0	TRUSS	4
02-1-5		A2391-A11-0000	GASKET COVER HEAD CYLINDER	1
02-1-6		A2303-A26-6000	GASKET, BREATHER PLATE	1
02-2		I4050-06060-0H	FLANGE NUT, HEX.	2
02-3		A6101-B02-0000	CRAB RUBBER CAP	1
02-4		I6001-06025-0C	FLANGE BOLT, HEX.	4
02-5		A220A-A26-0000	HEAD ASSY CYLINDER	1
02-5-1		A2200-A26-0000	HEAD COMP CYLINDER	1
02-5-1-1		A2237-A11-0000	GUIDE VALVE	2
02-5-1-2		I4608-09016	O-RING	2
02-5-1-3		A2202-A26-0000	SEAT, IN VALVE	1
02-5-1-4		A2203-A26-0000	SEAT, EX VALVE	1
02-5-2		I2900-06016-0A	BOLT, STUD	2
02-5-3		I2900-06050-0A	BOLT, STUD	2
02-5-4		A4781-A04-0000	COTTER, VALVE	4
02-5-5		A4771-A04-0000	RETAINER, VALVE SPRING	2
02-5-6		A4761-A11-0000	SPRING VALVE INNER	2
02-5-7		A4751-A11-0000	SPG VALVE OUTER	2
02-5-8		I4104-16508	WASHER	2
02-5-9		A2209-A04-0000	SEAL VALVE STEM	2
02-5-10		A4721-A26-0000	VALVE EXHAUST	1
02-5-11		A4711-A26-0000	VALVE INLET	1
02-5-12		I8000-V30-0000	SPARK PLUG	1
02-6		A8291-A11-0000	GASKET EXH PIPE	1
02-7		I6001-06085-0H	FLANGE BOLT, HEX.	2
02-8		I4301-08140A	KNOCK PIN	4
02-9		A2251-A26-0000	GASKET HEAD CYLINDER	1
02-10		I4104-07225	WASHER	4
02-11		I4050-07060-0H	FLANGE NUT, HEX.	4
02-12		A2211-A11-0000	HOLDER CAM SHAFT	1
02-13		A4451-A11-0000	SHAFT IN ROCKER ARM	1
02-14		A4452-A11-0000	SHAFT EX ROCKER ARM	1
02-15		A4431-A11-0000	ARM VALVE ROCKER	2


02-16		I4001-050K0	NUT HEX	2
02-17		I0012-A04-0000	SCREW ADJUSTING	2
02-18		A4100-A26-9000	CAM SHAFT COMP	1
02-19		A6201-A26-6000	GASKET, CARB INSULATOR	1
02-20		A6211-A12-0000	INSULATOR CARB	1
02-21		A711A-A26-9000	PIPE ASSY, INLET	1
02-21-1		I4608-22020	O-RING	1
02-21-2		A7110-A12-0000	PIPE COMP, INLET	1
02-21-3		A7227-A26-9000	BAND B	1

3. CYLINDER 、CRANKSHAFT 、PISTON




ITEM	AVAIL	PART NO.	NAME	QTY
03			CYLINDERPISTONCRANKSHAFT	
03-1		A3000-A25-0000	CRANK SHAFT COMP	1
03-1-1		A3321-A25-0000	CRANK SHAFT, LEFT	1
03-1-1		I4401-25046	WOODRUFF KEY	1
03-1-2		A3311-A25-0000	CRANK SHAFT, RIGHT	1
03-1-3		A3201-A11-0000	ROD CONNECTING	1
03-1-4		A3381-A11-0000	PIN, CRANK	1
03-1-5		I1110-231281139	BEARING, NEEDLE	1
03-1-6		A3371-A11-0000	PLATE R CRANK SIDE	1
03-1-7		I6100-63040	BEARING, BALL, RADIAL	2
03-1-8		A5131-A12-0000	GEAR PUMP DRIVE	1
03-1-9		A4311-A12-0000	SPROCKET TIMING	1
03-1-10		I4401-25046	WOODRUFF KEY	1
03-2		I4104-06512	WASHER	1
03-3		A3101-A26-0000	PISTON	1
03-4		A3111-A26-0000	PIN PISTON	1
03-5		I4601-13000	CLIP PISTON PIN	2
03-6		A3011-A26-0000	PISTON RING SET	1
03-7		A2191-A26-6000	GASKET, CYLINDER	1
03-8		I4301-08140A	KNOCK PIN	2
03-9		A2100-A25-0000	CYLINDER COMP	1
03-10		A4550-A09-0000	COMP, LIFTER TENSIONER	1
03-10-1	N	A4560-A09-0000	PLUG COMP ADJUSTER	1
03-10-2	N	I4104-08416	WASHER	1
03-10-3	N	A4553-A09-0000	SPRING, CAM CHAIN ADJUSTER	1
03-11		A4555-A26-6000	GASKET, LIFTER TENSIONER	1
03-12		I6001-06016-0H	FLANGE BOLT, HEX.	2
03-13		A4510-A11-0000	TENSION GUIDE , CAM CHAIN	1
03-14		A4401-A11-0000	CHAIN CAM	1
03-15		A4610-A11-0000	GUIDE, CAM CHAIN	1
03-16		A4530-A04-0000	PIVOT CAM CHAIN SET	1
03-16-1		A4531-A04-0000	PIVOT CAM CHAIN TENSION	1
03-16-1	N	A4531-A04-0000	PIVOT CAM CHAIN TENSION	1
03-16-2		I4608-15215	O-RING	1
03-16-2	N	I1301-15515	O-RING	1
03-17		I5801-06012-0C	FLANGE BOLT, HEX.	1

4. COVER R CRANK CASE




ITEM	AVAIL	PART NO.	NAME	QTY
04			COVER R CRANK CASE	
04-1		A1331-A26-0900	COVER R SIDE	1
04-2		I1201-A26-9000	OIL SEAL (R)	1
04-3		A1394-A26-6000	GASKET, R COVER	1
04-4		A5650-A04-0000	GAUGE COMP OIL LEVEL	1
04-4-1		A5651-A04-0000	GAUGE OIL LEVEL	1
04-4-1	N	A5651-A04-0000	GAUGE OIL LEVEL	1
04-4-2		I4608-18030	O-RING	1
04-4-2		I4608-18030	O-RING	1
04-5		A5421-A00-0000	SCREEN, OIL FILTER	1
04-6		A5426-A04-0000	SPG OIL FILTER SCREEN	1
04-7		A2360-A04-0001	HOLE CAP TAPPET COMP	1
04-7-1		I4608-30832	O-RING	1
04-7-1		I4608-30832	O-RING	1
04-7-2		A2361-A04-0000	HOLE CAP TAP ADJUSTING	1
04-7-2		A2361-A04-0000	HOLE CAP TAP ADJUSTING	1
04-8		I6001-06100-0H	FLANGE BOLT, HEX.	4
04-9		I6001-06085-0H	FLANGE BOLT, HEX.	4
04-10		I4301-08140	KNOCK PIN	2

5.CARBURETOR



ITEM	AVAIL	PART NO.	NAME	QTY
05			CARBURETOR	
05-1		A610A-A25-0000	CARBURETOR ASSY.	1
05-1-1		A6100-A25-0000	CARBURETOR COMP	1
05-1-1-1		A0004-A26-9000	MANUAL CHOKE COMP 2	1
05-1-1-2		A6109-A25-0000	JET NEEDLE ASSY #4T14	1
05-1-1-3		KAC73440	VACUUM PISTON COMP	1
05-1-1-4		KAC70G04	AIR ADJUSTING SCREW ASSY.	1
05-1-1-5		KAC72130	NEEDLE VALVE ASSY.	1
05-1-1-6		KAC73010	SLOW JET # 32	1
05-1-1-7		A6170-A26-6000	NOZZLE, MAIN SET	1
05-1-1-7-1		KAC73110	PIPE, BLEED	1
05-1-1-7-2		KAC72910	NOZZLE, MAIN	1
05-1-1-8		KAC83108	MAIN JET # 95	1
05-1-1-9		KAC72310	FLOAT ASSY.	1
05-1-1-10		KAC75710	CHAMBER O-RING	1
05-1-1-11		A0002-A26-9000	ACCELERATION PUMP COMP	1
05-1-1-12		KAC71520	DRAIN SCREW ASSY	1
05-1-1-13		AC001	SCREW PANHEAD	2
05-1-1-14		A6111-A26-6000	TUBE	1
05-1-1-15		KAC73820	CARB TOP COVER	1
05-1-1-16		KAC73710	SPRING	1
05-1-1-17		KAC73610	SPRING PLACE	1
05-1-1-18		I3500-05010-0H	SCREW PAN	2
05-1-1-19		KAC71610	BRACKET WIRE ASSY	1
05-1-1-20		AC033	SCREW	3
05-1-1-21		KAC70210	CARB CHAMBER	1
05-1-1-22		A6106-A26-6000	PLUG	1
05-1-1-23		KAC73510	SPRING	1
05-1-1-24	N	A0006-A26-0000	PLUG	1
05-1-1-25		KAC72410	PIN FLOAT	1
05-1-2		A0001-A26-9000	MANUAL CHOKE COMP 1	1
05-1-3		A7920-A26-9000	CABLE, AIR CUT	1
05-1-4		A0003-A26-9000	TUBE BREATHER COMP	1
05-1-4-1		KAB46510	TUBE CLIP (B)	1
05-1-4-2		KAB86210	TUBE, RUBBER (A)	1
05-1-4-3		KAB46410	TUBE CLIP (A)	2
05-1-4-4		KAB87710	PIPE, BYPASS	1
05-1-4-5		KAB87810	TUBE, RUBBER (B)	1
05-2		A7910-9KA0-0000	CABLE,THROTTLE	1


6. DRIVEN PULLEY



ITEM	AVAIL	PART NO.	NAME	QTY
06			DRIVEN PULLEY (CVT)	
06-1		B301A-A11-0000	PULLEY ASSY, DRIVEN	1
06-1-1		B2300-A11-0000	PLATE COMP DRIVE	1
06-1-1		B2300-A11-0000	PLATE COMP DRIVE	1
06-1-1-1		B2401-A11-0000	SPRING CLUTCH	3
06-1-1-1		B2401-A11-0000	SPRING CLUTCH	3
06-1-1-1	N	B2350-A11-0000	PLATE COMP DRIVE	1
06-1-1-2	N	B2401-A11-0000	SPRING CLUTCH	3
06-1-1-3	N	B2530-A11-0000	WEIGHT SET CLUTCH	3
06-1-1-4	N	B2804-A11-0000	ROLLER CLUTCH	3
06-1-1-5	N	I4540-0501D	CIRCLIP	3
06-1-1-6	N	I0442-A11-0000	WASHER CLUTCH	3
06-1-2		I4002-280A0	NUT HEX	1
06-1-2		I4002-280A0	NUT HEX	1
06-1-3		B2101-A11-0000	OUTER CLUTCH	1
06-1-3		B2101-A11-0000	OUTER CLUTCH	1
06-1-4		B3210-A11-0000	FACE COMP, DRIVEN	1
06-1-4		B3210-A11-0000	FACE COMP, DRIVEN	1
06-1-4-1	N	I6140-69013-10	BEARING BALL RADIAL	1
06-1-4-2	N	I4520-24000	CIRCLIP IN	1
06-1-4-3	N	I1120-172518	BEARING, NEEDLE	1
06-1-4-4	N	B3211-A11-0000	FACE COMP, DRIVEN	1
06-1-5		B3225-A11-0000	PIN GUIDE	3
06-1-5		B3225-A11-0000	PIN GUIDE	3
06-1-6		I1211-A11-0000	OIL SEAL	2
06-1-6		I1211-A11-0000	OIL SEAL	2
06-1-7		B3220-A11-0000	FACE COMP MOVABLE DRIVE	1
06-1-7		B3220-A11-0000	FACE COMP MOVABLE DRIVE	1
06-1-8		I4608-39822	O-RING	1
06-1-8		I4608-39822	O-RING	1
06-1-9		I4608-36015	O-RING	1
06-1-9		I4608-36015	O-RING	1
06-1-10		B3233-A11-0000	SPG DRIVEN FACE	1
06-1-10		B3233-A11-0000	SPG DRIVEN FACE	1
06-1-11		B3238-A11-0000	COLLAR SPRING	1
06-1-11		B3238-A11-0000	COLLAR SPRING	1
06-2		I4050-10090-0H	FLANGE NUT, HEX.	1
06-3		B210A-A26-9000	FACE ASSY. MOVABLE DRIVE	1
06-3-1		B2103-A11-0000	FACE DRIVER	1


06-3-2		B2105-A26-9000	BOSS DRIVE FACE	1
06-3-3		B2110-A26-9000	FACE COMP, MOVABLE DRIVE	1
06-3-4		A0005-A26-9000	ROLLER COMP WEIGHT	1
06-3-4-1		B2121-A26-9000	ROLLER WEIGHT	6
06-3-5		B2131-A26-9000	PLATE, RAMP	1
06-3-6		B2132-A26-9000	PIECE SLIDE	3
06-3-7		B2102-A11-0000	FACE DRIVE	1
06-4		B3100-A11-0000	BELT DRIVE	1
06-5		B8211-A26-9000	RATCHET KICK STARTER	1
06-6		I4104-14515	WASHER	1
06-7		I4050-12110-0H	FLANGE NUT, HEX.	1

7. START MOTOR 、 OIL PUMP



ITEM	AVAIL	PART NO.	NAME	QTY
07			START MOTOR OIL PUMP	
07-1		A5100-A12-0000	OIL PUMP COMP	1
07-1-1		I4303-04118	KNOCK PIN	1
07-2		I6001-06020-0H	FLANGE BOLT, HEX.	2
07-3		I6001-06025-0C	FLANGE BOLT, HEX.	1
07-4		A5133-A11-0000	GEAR OIL PUMP DRIVEN	1
07-5		I4050-06060-0H	FLANGE NUT, HEX.	1
07-6		I6001-06035-0H	FLANGE BOLT, HEX.	2
07-7		C1200-A26-0000	MOTOR START COMP	1
07-8		C1209-A12-0000	GEAR START COMP	1
07-9		I4301-08140	KNOCK PIN	1
07-10		I4608-09016	O-RING	2


8. FAN COVER 、 GENERATOR



ITEM	AVAIL	PART NO.	NAME	QTY
08			FAN COVERGENERATOR	
08-1		A964A-A26-0000	DUCT INLET ASSY	0
08-1-1		A961A-A26-0000	COVER ASSY FAN	1
08-1-1		A961A-A26-0000	COVER ASSY FAN	1
08-1-1-1		A9610-A26-0000	COVER COMP FAN	1
08-1-1-1		A9610-A26-0000	COVER COMP FAN	1
08-1-1-1		A9610-A26-0000	COVER COMP FAN	1
08-1-1-2		G0529-A04-0000	GROMMET SHROUD	1
08-1-1-2		G0529-A04-0000	GROMMET SHROUD	1
08-1-1-2		G0529-A04-0000	GROMMET SHROUD	1
08-1-1-3		H7541-A26-0000	LABEL OIL CAP	1
08-1-1-3		H7541-A26-0000	LABEL OIL CAP	1
08-1-1-3		H7541-A26-0000	LABEL OIL CAP	1
08-1-1-4		I6231-065120	COLLAR	2
08-1-1-4		I6231-065120	COLLAR	2
08-1-2		A9640-A26-0000	DUCT INLET COMP.	1
08-1-2		A9640-A26-0000	DUCT INLET COMP.	1
08-1-2-1		A9616-A26-0000	DUCT INLET	1
08-1-2-1		A9616-A26-0000	DUCT INLET	1
08-1-2-1		A9616-A26-0000	DUCT INLET	1
08-1-2-2		A9617-A26-0000	RUBBER	1
08-1-2-2		A9617-A26-0000	RUBBER	1
08-1-2-2		A9617-A26-0000	RUBBER	1
08-1-2-3		A9618-A26-0000	RUBBER	1
08-1-2-3		A9618-A26-0000	RUBBER	1
08-1-2-3		A9618-A26-0000	RUBBER	1
08-1-2-4		G0529-V30-0000	GROMMET SHROUD	1
08-1-2-4		G0529-V30-0000	GROMMET SHROUD	1
08-1-2-4		G0529-V30-0000	GROMMET SHROUD	1
08-1-3		I3893-05012-0H	SCREW WASHER	3
08-1-3		I3893-05012-0H	SCREW WASHER	3
08-2		A962A-A11-0000	SHROUD ASSY, A	1
08-2-1		A9620-A11-0000	SHROUD COMP, A	1
08-2-1	N	A9620-A11-0000	SHROUD COMP, A	1
08-2-1-1		A9628-A11-0000	COLLAR	1
08-2-1-1		A9628-A11-0000	COLLAR	1
08-2-1-2		A9627-A11-0000	COLLAR	1
08-2-1-2		A9627-A11-0000	COLLAR	1
08-2-2		A9637-A12-0000	NUT SPRING	1


08-2-2		A9637-A12-0000	NUT SPRING	1
08-2-3		A9637-A11-0000	CLIP SPRING	1
08-2-3		A9637-A11-0000	CLIP SPRING	1
08-3		I6001-06025-0C	FLANGE BOLT, HEX.	3
08-4		I3904-316B0	TAPPING SCREW, HEX.	2
08-5		A9625-A11-0000	SEAL SHROUD	1
08-6		I6001-06016-0H	FLANGE BOLT, HEX.	4
08-7		A9510-A12-0000	FAN COMP COOLING	1
08-8		I4050-12110-0H	FLANGE NUT, HEX.	1
08-9		C1110-A12-9000	FLYWHEEL COMP	1
08-10		I6001-06020-0H	FLANGE BOLT, HEX.	2
08-11		C1120-A26-0000	STATOR COMP	1
08-12		I3412-05014-0H	BOLT, HEX.	2
08-13		A963A-A11-0000	SHROUD ASSY, B	1
08-13-1		A9630-A11-0000	SHROUD COMP, B	1
08-13-1	N	A9630-A11-0000	SHROUD COMP, B	1
08-13-1-1		A9628-A11-0000	COLLAR	1
08-13-1-1		A9628-A11-0000	COLLAR	1
08-13-2		A9636-A12-0000	BOX TENSIONER LIFTER	1
08-13-2		A9636-A12-0000	BOX TENSIONER LIFTER	1
08-13-3		A9637-A12-0000	NUT SPRING	1
08-13-3		A9637-A12-0000	NUT SPRING	1
08-13-4		I3903-316B0	TAPPING SCREW, TRUSS	2
08-13-4		I3903-316B0	TAPPING SCREW, TRUSS	2
08-13-5		A9637-A11-0000	CLIP SPRING	1
08-13-5		A9637-A11-0000	CLIP SPRING	1
08-13-6		A9638-A12-0000	CLAMPER CABLE	1
08-14		C2963-A09-0000	CLAMPER PULSER CORD	1
08-15		A9619-A26-9000	FENDER	1
08-16		I5701-06025-0C	FLANGE BOLT, HEX.	1
08-17		A9634-A25-0000	SPACER	1
08-18		I6001-06016-0H	FLANGE BOLT, HEX.	1

9. TRANSMISSION



ITEM	AVAIL	PART NO.	NAME	QTY
09			TRANSMISSION	
09-1		B1300-A26-0900	COVER COMP, MISSION	1
09-2		A1260-A26-0000	PIN COMP	1
09-2-1		A1261-A26-0000	PIN	1
09-2-2		I4608-07515	O-RING	1
09-3		I0309-0800H	HEX. NUT, SAFETY	1
09-4		I6100-60043	BEARING, BALL RADIAL	1
09-5		I6100-62013-10	BEARING, BALL, RADIAL	2
09-6		B1395-A25-6000	GASKET, MISSION COVER	1
09-7		I1225-42007	OIL SEAL(INNER)	1
09-8		B3430-A25-0000	SHAFT COMP, FINAL	1
09-8-1		B3431-A25-0000	SHAFT, FINAL	1
09-8-2		B3432-A25-0000	GEAR, FINAL	1
09-9		I4301-10140	KNOCK PIN	2
09-10		B3411-A26-0000	SHAFT, DRIVE	1
09-11		I4104-12114-1G	WASHER	1
09-12		B3420-EV1-0000	SHAFT COMP COUNTER	1
09-12-1		B3421-EV1-0000	SHAFT, COUNTER	1
09-12-2		B3432-A25-0000	GEAR, FINAL	1
09-13		B3801-A26-0000	SPROCKET DRIVE	1
09-14		A1240-A26-0000	BRACKET COMP ENGINE	1
09-14-1		A1241-A26-0000	ENGINE BRACKET	1
09-14-2		A1203-A26-0000	REAR SHOCK ABSORBER BUSHING	1
09-15		I5702-12045-0A	FLANGE BOLT, HEX.	1
09-16		I4050-12110-0H	FLANGE NUT, HEX.	1
09-17		I2201-06010-0H	BOLT, HEX.	2
09-18		B3811-A00-0000	PLATE FIXING	1
09-19		I4510-20000	CIRCLIP EX	1

10. AIR CLEANER




ITEM	AVAIL	PART NO.	NAME	QTY
10			AIR CLEANER	
10-1		A723A-A26-9000	AIR CLEANER ASSY	1
10-1-1		A7230-A26-9000	CASE, AIR/C	1
10-1-1-1		A7209-A09-0000	AIR CLEANER CASE BUSH	2
10-1-2		A7209-A09-0000	AIR CLEANER CASE BUSH	2
10-1-3		A7206-A09-9000	COVER DOWN	2
10-1-4		A7205-A09-9000	FILTER ELEMENT	2
10-1-5		A7207-A09-9000	COVER TOP	2
10-1-6		I3903-412B0	TRUSS	2
10-1-7		I4608-94535	O-RING	2
10-1-8		A7231-A09-9000	COVER AIR/C	2
10-1-9		I3903-220B0	TAPPING SCREW, TRUSS	6
10-1-10		A7253-A26-0000	AIR CLEANER CONNECTOR TUBE	1
10-1-11		A5055-A26-0000	TUBE BREATHER	1
10-1-12		A7255-A26-0000	BAND CONNECTING TUBE	2
10-1-13		I5002-12312	TUBE CLIP	4
10-1-14		A7234-B00-0000	TUBE DRAIN	2
10-1-15		A7232-B00-0000	CAP	2
10-2		A736A-A26-6000	OIL CATCH TANK ASSY	1
10-2-1		A7365-A26-0000	TUBE, BREATHER A	1
10-2-2		A7364-A26-6000	TUBE, BREATHER B	1
10-2-3		I5002-10810-0H	TUBE CLIP	2
10-2-4		I5002-14510-0H	TUBE CLIP	1
10-2-5		I5002-08510-0H	TUBE CLIP	1
10-2-6		A7369-A26-0000	TUBE, PROTECTION	1
10-2-7		A7360-A26-6000	OIL CATCH TANK COMP	1
10-2-8		A7363-A26-6000	RUBBER CAP	1
10-3		I6001-06025-0H	BOLT FLANGE SH	1
10-4		A7261-A25-0000	AIR CLEANER BRACKET	1
10-5		I6001-06028-0H	FLANGE BOLT, HEX.	2

No picture.


ITEM	AVAIL	PART NO.	NAME	QTY
11			PREARRANGE	

12. ENGINE




ITEM	AVAIL	PART NO.	NAME	QTY
12			ENGINE	
12-1		AA000-A25-0000	ENGINE	1
12-2		A1000-5EA0-9000	RUBBER CAP KICK SHAFT	1
12-3		B8300-B00-9001	ARM COMP KICK STARTER	1

13.MUFFLER




ITEM	AVAIL	PART NO.	NAME	QTY
13			MUFFLER	
13-1		A830A-7KA0-1000	MUFFLER PIPE ASSY.	1
13-1-1		A8301-7KA0-0000	MUFFLER PIPE , FRONT	1
13-1-2		A8302-7KA0-0000	MUFFLER PIPE , REAR	1
13-1-3		A8303-FIA0-0000	SPARK ARRESTER	1
13-1-4		A8304-9KA0-0000	SPRING	1
13-1-5		A8305-9KA0-0000	SOCKET BOLT	1
13-1-6		A8306-9KA0-0000	HEX, NUT, SAFETY	1
13-2		I0179-06850	NUT	2
13-3		I5827-08030	FLANGE BOLT, HEX.	1
13-4		I5611-08200	HEX. FLANGE NUT, SAFETY	1

14. FRAME




ITEM	AVAIL	PART NO.	NAME	QTY
14			FRAME	
14-1		E010A-7KC0-0000	FRAME COMP.	1
14-1-1		E0100-7KC0-0000	FRAME	1
14-1-2		G7212-5EA0-0000	RUBBER DAMPER	2
14-2		I6100-6002ZZ	BEARING (6002ZZ)	1
14-3		I4510-32000	C CLIP EX 32	1
14-4		I2502-10170-6C	FLANGE BOLT, HEX	1
14-5		E035A-9KA0-0000	ENGINE SUSPENSION ASSY	1
14-5-1		E0350-9KA0-0000	ENGINE SUSPENSION	1
14-5-2		E0201-5EA0-0000	BUSH	2
14-5-3		E0360-9KA0-0000	COLLAR	1
14-6		E0351-5EA0-0000	FLANGE BOLT, HEX.	1
14-7		I9905-10100	WASHER	2
14-8		I5612-10200	HEX. FLANGE NUT, SAFETY	3
14-9		I2502-10165-6C	FLANGE BOLT, HEX	1
14-10	N	E0101-5EA0-0000	FRAME NUMBER PLATE	1
14-11		H750A-5BA1-0000	NAIL, PULL	2
14-12		I5611-06200-0G	HEX. FLANGE NUT, SAFETY	2
14-13		H7138-7KA0-0000	STICER,EMISSION CONTROL	1
14-14		B0101-9KA0-0000	CVT BAND INSULATOR	1
14-15		E0107-9KC0-0000	FIXED PLATE, FRONT FENDER L	1
14-16		E0108-9KC0-0000	FIXED PLATE, FRONT FENDER R	1
14-17		I0149-06823-01	BOLT,FLANGE(M6×23)	2
14-18		I0149-06012	FLANGE BOLT, HEX.	5
14-19		D0103-9KA0-0000	DRIVE CHAIN COVER	1
14-20		I0149-06016	FLANGE BOLT, HEX.	2
14-21		H3503-LRA0-0000	T COLLAR	3
14-22		G7232-9FA0-0000	PLUG RUBBER	2
14-23		F4309-5EA0-0000	STICKER, MFD.	1
14-24		E0130-9KA0-0000	FRONT REINFORCEMENT POLE	2
14-25		I0149-10020	BOLT,FLANGE	4

15. A ARM, FOOTREST, FENDER BAR



ITEM	AVAIL	PART NO.	NAME	QTY
15			A ARMFOOTRESTFEND BAR	
15-1		E020A-5EE0-0700	ARM, SUSPENSION, L.H. ASSY	1
15-1-1		E0200-5EE0-0700	ARM, SUSPENSION, L.H.	1
15-1-2		E0201-5EA0-0000	BUSH	2
15-1-3		E0207-5EA0-0000	OIL LINER(15.5)	1
15-1-4		E0206-5EA0-0000	OIL LINER(17)	1
15-2		E021A-5EE0-0700	ARM, SUSPENSION, R.H. ASSY	1
15-2-1		E0210-5EE0-0700	ARM, SUSPENSION, R.H.	1
15-2-2		E0201-5EA0-0000	BUSH	2
15-2-3		E0207-5EA0-0000	OIL LINER(15.5)	1
15-2-4		E0206-5EA0-0000	OIL LINER(17)	1
15-3		E0202-5EA0-0000	WATERPROOF SEAL	2
15-4		E0203-5EA0-0000	DUST SEAT	2
15-5		I0102-10048	FLANGE BOLT, HEX.	4
15-6		I5611-10200	HEX. FLANGE NUT, SAFETY	4
15-7		I6600-06000	GREASE VALVE	2
15-8		E0209-5EA0-9000	CAP, GREASE VALVE	2
15-9		E0700-9KA0-0000	FOOTREST BAR ASSY.(LEFT)	1
15-10		E0706-9KA0-0000	FOOTREST BAR ASSY.(RIGHT)	1
15-11		E040A-5EE0-0700	FEND BAR ASSY FRONT ASSY	1
15-11-1		E0400-5EE0-0700	FEND BAR ASSY FRONT	1
15-11-2		E0707-5EE0-0000	RUBBER PLUG	4
15-12		I0149-08016	FLANGE BOLT, HEX.	4
15-13		E0703-9KA0-0000	FOOTREST REAR BAR (L)	1
15-14		E0705-9KA0-0000	FOOTREST REAR BAR (R)	1
15-15		I0149-06012	FLANGE BOLT, HEX.	6
15-16		E0410-7KA0-0000	BUMPER REAR,ASSY	1
15-17		I7507-FIA0-0000	BOLT, HEX.	8
15-18		I0149-06823-01	BOLT,FLANGE(M6×23)	2
15-19		I5611-06200-0G	HEX. FLANGE NUT, SAFETY	2
15-22		I0149-08012	FLANGE BOLT, HEX.	2


16.FENDER



ITEM	AVAIL	PART NO.	NAME	QTY
16			FENDER	
16-1		F4300-5EE0-5400	FRONT BODY COVER(BLUE)	1
16-1		F4300-5EE0-4200	FRONT BODY COVER(RED)	1
16-1		F4300-5EE0-0800	FRONT BODY COVER(BLACK)	1
16-2		H3500-5EE0-0800	REAR BODY COVER (BLACK)	1
16-2		H3500-5EE0-4200	REAR BODY COVER (RED)	1
16-2		H3500-5EE0-5400	REAR BODY COVER (BLUE)	1
16-3		F1100-9KC0-5400	FRONT FENDER (L) (BLUE)	1
16-3		F1100-9KC0-0800	FRONT FENDER (L) (BLACK)	1
16-3		F1100-9KC0-4200	FRONT FENDER (L) (RED)	1
16-4		F1200-9KC0-4200	FRONT FENDER (R) (RED)	1
16-4		F1200-9KC0-5400	FRONT FENDER (R) (BLUE)	1
16-4		F1200-9KC0-0800	FRONT FENDER (R) (BLACK)	1
16-5		H7101-FIA0-7000	WARNING LABEL, OPERATE	1
16-6		H7102-5EB0-8000	WARNING LABEL, AGE Y6	1
16-8		F1500-9KC0-0700	CENTER COVER, FRONT(SILVER)	1
16-8		F1500-9KC0-4200	CENTER COVER, FRONT(RED)	1
16-8		F1500-9KC0-5400	CENTER COVER, FRONT(BLUE)	1
16-9		F1510-9KC0-0000	CENTER COVER GRILLE, FRONT	1
16-10		E0417-5EE0-0000	FILTER NET PLUG	5
16-11		H7107-5EB0-0000	EMBLEM, E-TON LOGO(SILVER)	1
16-12		H7030-9KC0-0000	FRONT BODY STICKER (L)	1
16-13		H7040-9KC0-0000	FRONT BODY STICKER (R)	1
16-14		E320A-7KA0-0801	COVER,HANDLE BAR ASSY.(BLACK)	1
16-14-1		E3205-5EE0-0800	COVER,HANDLE BAR(BLACK)	1
16-14-2		C5010-9FA0-0001	MAIN SWITCH COMP	1
16-14-2-1		C5013-9FA0-0000	MATERIAL KEY (RIGHT CUT)	1
16-14-2-2		C5018-9FA0-0000	MATERIAL KEY (LEFT CUT)	1
16-15		H3720-5EE0-5400	REAR FENDER (L)(BLUE)	1
16-15		H3720-5EE0-0800	REAR FENDER (L)(BLACK)	1
16-15		H3720-5EE0-4200	REAR FENDER (L)(RED)	1
16-16		H3820-5EE0-4200	REAR FENDER (R)(RED)	1
16-16		H3820-5EE0-0800	REAR FENDER (R)(BLACK)	1
16-16		H3820-5EE0-5400	REAR FENDER (R)(BLUE)	1
16-17		H3520-5EE0-0000	FOOTREST,(L)	1
16-18		H3620-5EE0-0000	FOOTREST,(R)	1
16-19		H7045-9KC0-0000	LABEL, FRONT FENDER R	1
16-20		I3414-06012-0H	BOLT WASHER	9


16-21		I0119-06821	BOLT, HEX.	2
16-22		I8310-06020-01	SCREW, OVAL	8
16-23		I5611-06200-0G	HEX. FLANGE NUT, SAFETY	4
16-24		E0117-9EA0-0000	SCREW, TRUSS	4
16-25		I8310-FIA0-0000	PLASTIC SCREW	2
16-26		H7106-5ED0-0000	WARNING STICKER,MUFFLER	1
16-27		I3500-06012-1A	SCREW PAN	2
16-28		H7050-9KC0-0000	STICKER, REAR BODY(L)	1
16-29		H7060-9KC0-0000	STICKER, REAR BODY (R)	1
16-30		H7103-7EE0-0000	STICKER, VIPER-70 (L)	1
16-31		H7104-7EE0-0000	STICKER, VIPER-70 (R)	1
16-35		H7139-FIA0-0000	SPARK ARRESTER DECLARATION	1
16-37		H7055-9KC0-0000	LABEL,REAR FENDER L	1
16-38		H7103-5EA0-0001	WARNING LABLE, TIRE PRESSURE	1
16-39		H7104-FIA0-0000	WARNING LABLE, NO PRASSENGER	1

17. SEAT




ITEM	AVAIL	PART NO.	NAME	QTY
17			SEAT	
17-1		G720A-5EE0-0700	SEAT ASSY(BLACK/SLIVER)	1
17-1		G720A-5EE0-0800	SEAT ASSY.(BLACK)	1
17-1-1		G7200-5EE0-0700	SEAT (BLACK/SILVER)	1
17-1-1		G7200-5EE0-0800	SEAT (BLACK)	1
17-2		G7201-9ED0-0000	SEAT FIXER,ASSY	1

18. FUEL TANK




ITEM	AVAIL	PART NO.	NAME	QTY
18			FUEL TANK	
18-1		A7500-9KA0-0000	METAL FUEL TANK	1
18-2		A762A-9KB0-V000	FUEL TANK CAP ASSY.	1
18-2-1		A7620-9KB0-V000	FUEL TANK CAP COMP	1
18-2-2		A7621-9FA0-0000	TUBE, RUBBER	1
18-3		I7507-06225	BOLT, HEX.	2
18-4		A751A-9KA0-9000	FUEL FILTER ASSY	1
18-4-1		A7519-FIA0-1000	FUEL FILTER	1
18-4-2		A7514-9KA0-9000	FUEL TUBE	2
18-4-3		I5002-40850-04	CLAMP, TUBE	2
18-4-4		I5002-50000	CLIP, TUBE	2
18-5		A7501-5EE0-9000	FUEL PIPE COMP(A)	1
18-5		A7501-5EE0-0000	FUEL TUBE	1
18-5-1		I5005-050242-6	RUBBER TUBE	1
18-5-1		A7516-5EA0-0000	CLIP(A)	1
18-5-2		I5002-50000	CLIP, TUBE	1
18-5-2		A7517-5EA0-0000	CLIP(B)	1
18-5-3		I5002-41200-04	CLIP	1
18-6		A7502-9KA0-0000	FUEL TUBE	1
18-6		A7502-9KA0-9000	FUEL PIPE COMP(B)	1
18-6-1		A7516-5EA0-0000	CLIP(A)	1
18-6-1		I5005-050252-6	RUBBER TUBE	1
18-6-2		A7517-5EA0-0000	CLIP(B)	1
18-6-2		I5002-50000	CLIP, TUBE	1
18-6-3		I5002-41200-04	CLIP	1
18-7		A7520-5EA0-0000	MANUAL FUEL CUP	1
18-8		I8506-05016	SCREW PAN	2
18-9		A7622-5EA0-0000	RUBBER PAD	1
18-10		F6520-5EE0-0000	DAMPER	2
18-11		G5010-5EE0-0000	COLLAR	2
18-12		F6520-9KC0-0000	DAMPER	2

19. SUSPENSION




ITEM	AVAIL	PART NO.	NAME	QTY
19			SUSPENSION	
19-1		E1105-7KA0-0700	SUSPENSION, FRONT (SILVER)	2
19-2		I0102-10040	BOLT, HEX	6
19-3		I5701-10500	FLANGE NUT, HEX.	4
19-4		E2400-5EE0-0000	SUSPENSION, REAR	1
19-5		I9900-25019	PIN, SPLIT	5
19-6		I0468-12006	PIN	1

20. FRONT WHEEL




ITEM	AVAIL	PART NO.	NAME	QTY
20			FRONT WHEEL	
20-1		D471A-7EE0-0S00	WHEEL ASSY.,LEFT(16×8-7)	1
20-1-1		D4710-7EE0-0000	TIRE	1
20-1-2		D4601-7EE0-0S00	WHEEL RIM(7×5.5)	1
20-2		D471B-7EE0-0S00	WHEEL ASSY.,RIGHT(16×8-7)	1
20-2-1		D4601-7EE0-0S00	WHEEL RIM(7×5.5)	1
20-2-2		D4710-7EE0-0000	TIRE	1
20-3		D4610-9EA0-0000	BRAKE DRUM, FRONT	2
20-3-1		D4612-9EA0-0000	BOLT, STUD	8
20-4		I3102-5AC0-0000	OIL SEAL	4
20-5		D4620-5EA0-0000	COLLAR	2
20-6		D4621-5EA0-0000	OUTER SPACER	2
20-7		I6100-6002LLU	BEARING(6002LLU)	2
20-8		I6150-60030-10	BEARING, BALL, RADIAL	2
20-9		I5500-12000	CASTLE NUT	2
20-10		I3000-13000-0C	WASHER	2
20-11		I4201-46325	SPLIT PIN	2
20-12		D4609-5EA0-0001	RUBBER CAP	2
20-13		D4608-5EA0-0000	FRONT WHEEL SHAFT WASHER	2
20-14		D4611-9EA0-0000	FLANGE NUT, HEX.	8

21. REAR WHEEL




ITEM	AVAIL	PART NO.	NAME	QTY
21			REAR WHEEL	
21-1		D472A-7EE0-0S00	WHEEL ASSY.,LEFT(16×8-7)	1
21-1-1		D4710-7EE0-0000	TIRE	1
21-1-2		D4601-7EE0-0S00	WHEEL RIM(7×5.5)	1
21-1-3		D2705-9EA0-1000	SHAFT CONNECTER WITH BOLTS	1
21-1-4		D4611-9EA0-0000	FLANGE NUT, HEX.	4
21-2		D472B-7EE0-0S00	WHEEL ASSY.,RIGHT(16×8-7)	1
21-2-1		D4710-7EE0-0000	TIRE	1
21-2-2		D4601-7EE0-0S00	WHEEL RIM(7×5.5)	1
21-2-3		D2705-9EA0-1000	SHAFT CONNECTER WITH BOLTS	1
21-2-4		D4611-9EA0-0000	FLANGE NUT, HEX.	4
21-3		I5500-14100	CASTLE NUT	2
21-4		I9905-14200	WASHER	2
21-5		D2309-5EA0-0000	WASHER	2
21-6		D4609-5EA0-0001	RUBBER CAP	2
21-7		I4201-46325	SPLIT PIN	2

23.REAR BRAKE SYSTEM




ITEM	AVAIL	PART NO.	NAME	QTY
23			REAR BRAKE SYSTEM	
23-1		D2310-5EE0-0000	REAR WHEEL BEARING SEAT ASSY	1
23-2		D2311-5EA0-0000	SPACER	1
23-3		I6100-6006ZZ	BEARING, BALL RADIAL	2
23-4		D2313-9EA0-0000	OIL SEAL	2
23-5		I0141-12025-01	FLANGE BOLT, HEX.	1
23-6		G7130-5EE0-0000	BRAKE CALLIPER	1
23-6-1		G7131-5EE0-0000	BRAKE SHOE COMP	1
23-6-2		G7132-5EE0-0000	BOLT LEAKAGE	1
23-6-3		G7133-BCA0-0000	CAP LEAKAGE	1
23-6-4		G7139-5EE0-0000	SPRING,PAO	1
23-6-5		G7134-5EE0-0000	RING,SEAL	1
23-6-6		G7136-5EE0-0000	PISTON, BRAKE CALIPER	1
23-6-7		G7135-5EE0-0000	RING,DUST RESISTANT	1
23-6-8		G71C1-5EE0-0000	BOOT	1
23-6-9		G71C2-5EE0-0000	BOOT	1
23-6-10		G71C3-5EE0-0000	BRACKET, CALLIPER	1
23-7		D0114-9EA0-0000	SPACER	1
23-8		D3520-FIA0-0000	BRAKE DISK	1
23-9		D3251-5EE0-0000	BRAKE DISK MOUNTING SEAT	1
23-10		D3210-5EE0-0000	BRAKE OIL TUBE	1
23-11		I0105-08035	BOLT FLANGE	2
23-12		I0110-10811	BOLT, SOCKET	3
23-13		I0401-10034	FLANGE BOLT, HEX.	1
23-14		I0201-10118	WASHER	2
23-15		G7111-BCA0-0000	BRAKE FUEL TUBE, CLIP	1
23-16		I0149-06012	FLANGE BOLT, HEX.	1
23-17		I0141-12028-01	BOLT FLANGE	3
23-18		I9901-08100	WASHER, SPRING	2
23-19		D3211-9KA0-0000	CLIP	1

24. HANDLE BAR




ITEM	AVAIL	PART NO.	NAME	QTY
24			HANDLE BAR	
24-1		E3100-9KC0-0000	HANDLE BAR ASSY.	1
24-2		E3166-5EA0-0000	GRIP	2
24-3		E3112-5EA0-0000	BOTTOM,HANDLE BAR CLAMP	2
24-4		E3110-5EA0-0000	CAP,HANDEL BAR CLAMP(L)	1
24-5		E3111-5EA0-0000	CAP,HANDEL BAR CLAMP(R)	1
24-6		I0050-06025	BOLT, SOCKET	4
24-7		D3200-5EG0-0000	BRAKE MASTER CYLINDER,LEFT	1
24-7-1		D6110-9KB0-0000	BRAKE LEVER, LEFT	1
24-7-2		D3202-FIA0-0000	BRAKE SWITCH ASSY.	1
24-7-3		D3208-5EG0-0000	FIXED SUPPORT COMP	1
24-8		E3180-FIA0-0000	LEVEL ASSY., RIGHT	1
24-8-1		E3181-5FA0-0000	LEVEL SET,RIGHT	1
24-8-2		E319A-5FA0-0000	LEVEL ACCELERATE	1
24-8-3		E3183-FIA0-0000	COVER LEVER	1
24-8-4		E3188-FIA0-0000	GASKET	1
24-8-5		I8506-04016	SCREW,PAN HEAD	2
24-9		I5611-10200	HEX. FLANGE NUT, SAFETY	2
24-10		I0401-10034	FLANGE BOLT, HEX.	1
24-11		I0201-10118	WASHER	2

25.REAR WHEEL AXLE



ITEM	AVAIL	PART NO.	NAME	QTY
25			REAR WHEEL AXLE	
25-1		D2300-9KC0-0000	REAR AXLE	1
25-2		D0110-9KC0-0000	DRIVE CHAIN ASSY	1
25-2-1		D0111-9KC0-0000	SPROCKET HOLDER, REAR	1
25-2-2		D1111-9EA0-0000	GEAR(28T)	1
25-2-3		D2706-9EA0-0000	BOLT	4
25-2-4		I5611-10200	HEX. FLANGE NUT, SAFETY	4
25-2-4		I5611-10200	HEX. FLANGE NUT, SAFETY	4
25-3		D2302-9EA0-0000	NUT, HEX.	2
25-4		D0100-9EA0-0000	DRIVE CHAIN COMP	1
25-4-1		D0104-9EA0-0000	DRIVE CHAIN LINK(#520)	1
25-4-2		D0105-9EA0-0000	DRIVE CHAIN	1
25-5		D0510-5EE9-0000	DRIVE CHAIN COVER	1
25-6		I0149-08016	FLANGE BOLT, HEX.	2
25-7		D2303-9KC0-0000	AXLE CLIP, REAR	1

26.SWING ARM




ITEM	AVAIL	PART NO.	NAME	QTY
26			SWING ARM SUB	
26-1		E220A-9KB0-0000	SWING ARM COMP	1
26-1-1		E2208-5EA0-0000	SWING ARM OIL LINER	2
26-1-2		E2200-9KB0-0000	SWING ARM	1
26-2		E2209-5EA0-0000	SWING ARM SPACER	1
26-3		E2205-5EA0-0000	OIL SEAL	2
26-4		E2201-5EA0-0000	FLANGE BOLT, HEX.	1
26-5		I5611-14200	HEX. FLANGE NUT, SAFETY	1
26-6		D3617-5EE0-0000	REAR BRAKE PROTECTIVE COVER	1
26-7		I0149-08012	FLANGE BOLT, HEX.	2
26-8		D0140-9KB0-0000	PROTECTIVE COVER	1
26-9		I9901-08100	WASHER, SPRING	3
26-10		D0120-9KB0-0000	CHAIN ADJUSTER COMP.	1
26-10-1		D0121-9KB0-0000	CHAIN ADJUSTER	1
26-10-2		I4051-061T1	FLANGE NUT, HEX	2
26-11		I0149-08016	FLANGE BOLT, HEX.	3
26-12		E221A-FID0-0000	CHAIN TENSIONER	1
26-12-1		E2210-FID0-0000	IDLER BRACKET	1
26-12-2		E2213-FID0-0000	TENSION IDLER	1
26-12-3		E2215-FID0-0000	CIRCLIP	1
26-12-4		E2214-FID0-0000	WASHER	1
26-12-5		E2216-FID0-0000	BEARING	2
26-12-6		E2212-FID0-0000	STUD	1
26-12-7		E2211-FID0-0000	RETURN SPRING	1
26-13		I4104-08010	WASHER	1
26-14		I0109-5BA1-0000	BOLT FLANGE	1
26-15		E2202-9KB0-0000	RUBBER SLEEVE	1

This exploded view diagram illustrates the components of a steering system. The central component is a long vertical shaft (1). At the top, there is a mounting bracket (7) secured by bolts (6), which connects to a control lever or arm (14). A horizontal cross member (13) is attached to the shaft via two sets of joints (13-1, 13-2 and 13-3, 13-4). These joints include sleeves (13-5) and pins/bushings (15). On each end of the cross member are knuckle arms (9 and 8) which terminate in ball joints (10). Various other parts like washers (2, 4), spacers (3), and nuts (5) are shown at the bottom, along with additional pins/bushings (11) used in the assembly.


Page 35.

28.ELECTRICAL EQUIPMENT



ITEM	AVAIL	PART NO.	NAME	QTY
28			ELECTRICAL EQUIPMENT	
28-1		C2100-9KC0-0000	MAIN WIRE ASSY.	1
28-1-1		C2010-5EA0-0000	FUSE(7A)	1
28-2		C1500-9FA0-0000	BATTERY	1
28-3		C5200-9KC0-0000	LEVER HOLDER ASSY., LEFT	1
28-3-1		C5201-9KC0-0000	LEVER HOLDER, LEFT	1
28-3-2		C5202-5EE0-0000	AIR CUT, LEVER	1
28-4		C1501-9FA0-0000	FOAM STICK, BATTERY	2
28-5		I8506-05016	SCREW PAN	2
28-6		C2102-9KA0-0000	EARTH CABLE	1
28-7		I3401-05020-07	BOLT, HEX.	1
28-8		C0510-A26-3000	COIL COMP IGN	1
28-9		C0410-A25-9000	C.D.I. UNIT ASSY.	1
28-10		C1600-B00-0000	RECTIFIER COMP REGULATE	1
28-11		I0153-06012	SCREW	1
28-12		C585A-LRA0-0000	REALY ASSY, START	1
28-12-1		C5850-LRA0-0000	START RELAY	1
28-12-2		C2101-LRA0-0000	POSITIVE CABTE	1
28-13		C1502-9ED0-0000	FIX STRIP(175L)	1
28-14		C2108-7EE0-0000	HANDLE BAR SAFETY ASSY	1

29.PACKING CACE, EXTERNAL




ITEM	AVAIL	PART NO.	NAME	QTY
29			PACKING CASE, EXTERNAL	
29-1		H9500-9KA0-0000	PACKING CASE,EXTERNAL	1
29-2		H9020-9KB0-0000	TOOL SET	1
29-3		H9021-9FA0-0000	WIRE CLAMP	1
29-4		H990A-9KC0-0001	OWNER'S MANUAL ASSY	1
29-5		H9022-5EA0-0000	PRESSURE METER	1
29-6		H9910-7KA0-0000	CONSUMER HANG TAP	1
29-8		H9911-7KC0-0000	TAG, WARNING	1

No picture.

ITEM	AVAIL	PART NO.	NAME	QTY
30			MANUAL CHOKE KIT	
30-1		A611A-9KA0-0000	MANUAL CHOKE KIT	1
30-1-1		A0001-A26-9000	MANUAL CHOKE COMP 1	1
30-1-2		A7920-A26-9000	CABLE, AIR CUT	1
30-1-3		C5200-9KC0-0000	LEVER HOLDER ASSY., LEFT	1
30-1-3-1		C5201-9KC0-0000	LEVER HOLDER, LEFT	1
30-1-3-2		C5202-5EE0-0000	AIR CUT, LEVER	1

31.ACCESSORIES



ITEM	AVAIL	PART NO.	NAME	QTY
31			ACCESSORIES	
31-1		H840A-9EF0-0000	FLAG HOLDER ASSY	1
31-1-1		H8401-9EF0-0000	FLAG HOLDER	1
31-1-2		H8402-9EF0-0000	FLAG HOLDER SEAT	1
31-1-3		I3415-08016-0C	BOLT HEXAGON HEAD WITH WASHER	1

No picture.

ITEM	AVAIL	PART NO.	NAME	QTY
32			SERVICE KITSBRAKE CALIPER	
32-1		G7137-5EE0-0000	SERVICE KITS, BRAKE CALIPER	1
32-1-1		G7134-5EE0-0000	RING,SEAL	1
32-1-2		G7135-5EE0-0000	RING,DUST RESISTANT	1
32-1-3		G7136-5EE0-0000	PISTON, BRAKE CALIPER	1
32-1-4		G7138-5EE0-0000	BRAKE SHOE ASSY	1
32-1-4-1		G7131-5EE0-0000	BRAKE SHOE COMP	1
32-1-4-2		G7139-5EE0-0000	SPRING,PAO	1