

PARTS CATALOGUE

VIPER 90R RXL90R-4S



CONTENTS


PARTS ITEM:

- 01 CRANK CASE
- 02 CYLINDER HEADHEAD COVER
- 03 CYLINDERPISTONCRANKSHAFT
- 04 COVER R CRANK CASE
- 05 CARBURETOR
- 06 DRIVEN PULLEY (CVT)
- 07 START MOTOROIL PUMP
- 08 FAN COVERGENERATOR
- 09 TRANSMISSION
- 10 AIR CLEANER
- 11 PREARRANGE
- 12 ENGINE
- 13 MUFFLER
- 14 FRAME
- 15 SWING ARMFOOTRESTFEND BAR
- 16 FENDER
- 17 SEAT
- 18 FUEL TANK
- 19 SUSPENSION
- 20 FRONT WHEEL
- 21 REAR WHEEL
- 22 FRONT BRAKE
- 23 REAR BRAKE
- 24 HANDLE BAR
- 25 REAR WHEEL AXLE
- 26 SWING ARM SUB,PROTECT COVER
- 27 STEERING

- 28 ELECTRICAL EQUIPMENT
- 29 PACKING CASEEXTERNAL
- 30 MANUAL CHOKE KIT
- 31 ACCESSORIES
- 32 SERVICE KITS,BRAKE CALLIPER
- 33 TOOL

N & sign meaning: not available to sale


1. CRANK CASE



ITEM	AVAIL	PART NO.	NAME	QTY
01			CRANK CASE	
01-1		A1000-A26-9000	CRANK CASE ASSY	1
01-1-1		A1100-A12-0900	CRANK CASE COMP, RIGHT	1
01-1-1	N	A1100-A12-0900	CRANK CASE COMP, RIGHT	1
01-1-2		A1200-A26-6900	CRANK CASE COMP, LEFT	1
01-1-2	N	A1200-A26-9900	CRANK CASE COMP, LEFT	1
01-2		A1192-A26-6000	GASKET, CRANK CASE	1
01-3		A1103-A04-0000	RUBBER BUSH ENGINE HANGER	2
01-4		I6001-06045-0H	FLANGE BOLT, HEX.	1
01-5		I4301-08140	KNOCK PIN	4
01-6		I4104-52010	WASHER	2
01-7		A1203-A26-0000	REAR SHOCK ABSORBER BUSHING	1
01-8		C5750-B07-0000	SENSOR, SHIFT	3
01-9		C5760-A26-9000	SHIFT SWITCH LINE	1
01-10		B1322-B07-0000	DUST COVER B	1
01-11		A1220-A26-9000	BREATHER HOSE COMP	1
01-11-1		A1206-B00-0000	BREATHER JOINT	1
01-11-1	N	A1206-B00-0000	BREATHER JOINT	1
01-11-2		A1221-A26-9000	HOSE BREATHER	1
01-11-2	N	A1221-A26-9000	HOSE BREATHER	1
01-11-3		I5002-06008	TUBE CLIP	1
01-11-3		I5002-06008	TUBE CLIP	1
01-12		A5651-B00-0000	PLUG, OIL	1
01-13		I1202-A26-9000	OIL SEAL (L)	1
01-14		I2800-12015-0C	BOLT, HEX.	1
01-15		I4104-12120	WASHER	1
01-16		I5801-08012-0H	FLANGE BOLT, HEX.	1
01-17		I4102-08020	WASHER	1
01-18		I0031-07181-0H	STUD BOLT (A), CYLINDER	2
01-19		I0032-07189-0H	STUD BOLT (B), CYLINDER	2
01-20		B4691-A26-9000	GASKET MOTOR CAP	1
01-21		C2300-A26-9000	MOTOR COMP SHIFT	1
01-22		B825A-A14-0001	SPINDLE ASSY KICK START	1
01-22-1		B8250-A14-0001	SPINDLE COMP KICK START	1
01-22-1	N	B8250-A14-0001	SPINDLE COMP KICK START	1
01-22-2		B8281-A14-0000	SPG KICK STARTER	1
01-22-2		B8281-A14-0000	SPG KICK STARTER	1
01-22-3		B8253-A14-0000	BOSS KICK SPINDLE	1

01-22-3		B8253-A14-0000	BOSS KICK SPINDLE	1
01-23		B8255-A14-0000	BOSS DISTANCE	1
01-24		I4104-14520A	WASHER	1
01-25		I4510-14000	CIRCLIP EX	1
01-26		B823A-A14-0001	GEAR ASSY STARTER IDLE	1
01-26-1		B8230-A14-0001	GEAR COMP STARTER IDLE	1
01-26-1	N	B8230-A14-0001	GEAR COMP STARTER IDLE	1
01-26-2		B8223-A14-0000	SPG. FRICTION START GEAR	1
01-26-2	N	B8223-A14-0000	SPG. FRICTION START GEAR	1
01-27		I4102-10505	WASHER	1
01-28		A1341-A26-0100	COVER L SIDE	1
01-29		I6130-60380-10	BEARING, BALL, RADIAL	1
01-30		A1395-A26-6000	GASKET, L COVER	1
01-31		I6001-06035-0H	FLANGE BOLT, HEX.	8
01-32		A1350-A26-0000	TUBE COMP, CVT INLET	1
01-32-1		A1351-A26-0000	TUBE, CVT INLET	1
01-32-2		A1352-A26-0000	PLUG	1
01-32-3		A7256-A26-0000	AIR DUCT CLAMP	1
01-33		I4104-14210	WASHER	1
01-34		B4305-V30-0000	SCREW FIXING	1
01-35		C231A-A26-9000	SHIFT MOTOR ASS'Y	1
01-35-1		A6116-A26-9000	RUBBER PLUG	1
01-35-2		B4460-A26-9900	CAP MOTOR	1
01-35-3	N	C2310-A26-9000	SHIFT MOTOR	1
01-36		I3500-05028-0H	SCREW PAN	2
01-37		I4608-13825	O-RING	1
01-38		A7261-A26-9000	AIR CLEANER HOLDER	1
01-39		I6001-06012-0H	FLANGE BOLT, HEX.	2
01-40		I6001-06028-0H	FLANGE BOLT, HEX.	2
01-41		B4307-V30-0000	BALL BEARING	1
01-42		B4306-V30-0000	SPRING FIXING	1


2. CYLINDER HEAD 、 HEAD COVER



ITEM	AVAIL	PART NO.	NAME	QTY
02			CYLINDER HEADHEAD COVER	
02-1		A230A-A26-6000	COVER ASSY HEAD CYLINDER	1
02-1-1		A2301-A26-0000	COVER HEAD CYLINDER	1
02-1-2		A2305-A11-0000	JOINT COMP BREATHER	1
02-1-3		A2302-A11-0000	PLATE BREATHER SEPARATOR	1
02-1-4		I3903-380H0	TRUSS	4
02-1-5		A2391-A11-0000	GASKET COVER HEAD CYLINDER	1
02-1-6		A2303-A26-6000	GASKET, BREATHER PLATE	1
02-2		I4050-06060-0H	FLANGE NUT, HEX.	2
02-3		A6101-B02-0000	CRAB RUBBER CAP	1
02-4		I6001-06025-0C	FLANGE BOLT, HEX.	4
02-5		A220A-A26-0000	HEAD ASSY CYLINDER	1
02-5-1		A2200-A26-0000	HEAD COMP CYLINDER	1
02-5-1-1		A2237-A11-0000	GUIDE VALVE	2
02-5-1-2		I4608-09016	O-RING	2
02-5-1-3		A2202-A26-0000	SEAT, IN VALVE	1
02-5-1-4		A2203-A26-0000	SEAT, EX VALVE	1
02-5-2		I2900-06016-0A	BOLT, STUD	2
02-5-3		I2900-06050-0A	BOLT, STUD	2
02-5-4		A4781-A04-0000	COTTER, VALVE	4
02-5-5		A4771-A04-0000	RETAINER, VALVE SPRING	2
02-5-6		A4761-A11-0000	SPRING VALVE INNER	2
02-5-7		A4751-A11-0000	SPG VALVE OUTER	2
02-5-8		I4104-16508	WASHER	2
02-5-9		A2209-A04-0000	SEAL VALVE STEM	2
02-5-10		A4721-A26-0000	VALVE EXHAUST	1
02-5-11		A4711-A26-0000	VALVE INLET	1
02-5-12		I8000-V30-0000	SPARK PLUG	1
02-6		A8291-A11-0000	GASKET EXH PIPE	1
02-7		I6001-06100-0H	FLANGE BOLT, HEX.	2
02-8		I4301-08140A	KNOCK PIN	4
02-9		A2251-A26-0000	GASKET HEAD CYLINDER	1
02-10		I4104-07225	WASHER	4
02-11		I4050-07060-0H	FLANGE NUT, HEX.	4
02-12		A2211-A11-0000	HOLDER CAM SHAFT	1
02-13		A4451-A11-0000	SHAFT IN ROCKER ARM	1
02-14		A4452-A11-0000	SHAFT EX ROCKER ARM	1
02-15		A4431-A11-0000	ARM VALVE ROCKER	2


02-16		I4001-050K0	NUT HEX	2
02-17		I0012-A04-0000	SCREW ADJUSTING	2
02-18		A4100-A26-9000	CAM SHAFT COMP	1
02-19		A6201-A26-6000	GASKET, CARB INSULATOR	1
02-20		A6211-A12-0000	INSULATOR CARB	1
02-21		A711A-A26-9000	PIPE ASSY, INLET	1
02-21-1		I4608-22020	O-RING	1
02-21-2		A7110-A12-0000	PIPE COMP, INLET	1
02-21-3		A7227-A26-9000	BAND B	1

3. CYLINDER / PISTON / CRANKSHAFT




ITEM	AVAIL	PART NO.	NAME	QTY
03			CYLINDERPISTONCRANKSHAFT	
03-1		A3000-A26-9000	CRANK SHAFT COMP	1
03-1-1		A3321-A26-9000	CRANK SHAFT L	1
03-1-2		A3311-A26-0000	CRANK SHAFT R	1
03-1-3		A3201-A26-0000	ROD CONNECTING	1
03-1-4		A3381-A12-0000	PIN CRANK	1
03-1-5		I1110-251301138	BEARING, NEEDLE	1
03-1-6		A3371-A26-0000	PLATE R CRANK SIDE	1
03-1-7		I6100-63040	BEARING, BALL, RADIAL	2
03-1-8		A5131-A12-0000	GEAR PUMP DRIVE	1
03-1-9		A4311-A12-0000	SPROCKET TIMING	1
03-1-10		I4401-25046	WOODRUFF KEY	1
03-2		I4104-06512	WASHER	1
03-3		A3101-A26-0000	PISTON	1
03-4		A3111-A26-0000	PIN PISTON	1
03-5		I4601-13000	CLIP PISTON PIN	2
03-6		A3011-A26-0000	PISTON RING SET	1
03-7		A2191-A26-6000	GASKET, CYLINDER	1
03-8		I4301-08140A	KNOCK PIN	2
03-9		A2100-A26-0000	CYLINDER COMP	1
03-10		A4550-A09-0000	COMP, LIFTER TENSIONER	1
03-10-1	N	A4560-A09-0000	PLUG COMP ADJUSTER	1
03-10-2	N	I4104-08416	WASHER	1
03-10-3	N	A4553-A09-0000	SPRING, CAM CHAIN ADJUSTER	1
03-11		A4555-A26-6000	GASKET, LIFTER TENSIONER	1
03-12		I6001-06016-0H	FLANGE BOLT, HEX.	2
03-13		A4510-A12-0000	GUIDE TENSION CAM CHAIN	1
03-14		A4401-A09-0000	CHAIN CAM	1
03-15		A4610-A12-0000	GUIDE CAM CHAIN	1
03-16		A4530-A04-0000	PIVOT CAM CHAIN SET	1
03-16-1		A4531-A04-0000	PIVOT CAM CHAIN TENSION	1
03-16-1	N	A4531-A04-0000	PIVOT CAM CHAIN TENSION	1
03-16-2		I4608-15215	O-RING	1
03-16-2	N	I1301-15515	O-RING	1
03-17		I5801-06012-0C	FLANGE BOLT, HEX.	1

4. COVER R CRANK CASE




ITEM	AVAIL	PART NO.	NAME	QTY
04			COVER R CRANK CASE	
04-1		A1331-A26-0900	COVER R SIDE	1
04-2		I1201-A26-9000	OIL SEAL (R)	1
04-3		A1394-A26-6000	GASKET, R COVER	1
04-4		A5650-A04-0000	GAUGE COMP OIL LEVEL	1
04-4-1		A5651-A04-0000	GAUGE OIL LEVEL	1
04-4-1	N	A5651-A04-0000	GAUGE OIL LEVEL	1
04-4-2		I4608-18030	O-RING	1
04-4-2		I4608-18030	O-RING	1
04-5		A5421-A00-0000	SCREEN, OIL FILTER	1
04-6		A5426-A04-0000	SPG OIL FILTER SCREEN	1
04-7		A2360-A04-0001	HOLE CAP TAPPET COMP	1
04-7-1		I4608-30832	O-RING	1
04-7-1		I4608-30832	O-RING	1
04-7-2		A2361-A04-0000	HOLE CAP TAP ADJUSTING	1
04-7-2		A2361-A04-0000	HOLE CAP TAP ADJUSTING	1
04-8		I6001-06100-0H	FLANGE BOLT, HEX.	4
04-9		I6001-06085-0H	FLANGE BOLT, HEX.	4
04-10		I4301-08140	KNOCK PIN	2

5. CARBURETOR



ITEM	AVAIL	PART NO.	NAME	QTY
05			CARBURETOR	
05-1		A610A-A26-9000	CARBURETOR ASSY.	1
05-1-1		A6100-A26-9000	CARBURETOR COMP	1
05-1-1-1		A0004-A26-9000	MANUAL CHOKE COMP 2	1
05-1-1-2		A6109-A26-6000	JET NEEDLE ASSY # 4T12	1
05-1-1-3		KAC73440	VACUUM PISTON COMP	1
05-1-1-4		KAC70G04	AIR ADJUSTING SCREW ASSY.	1
05-1-1-5		KAC72130	NEEDLE VALVE ASSY.	1
05-1-1-6		KAC73010	SLOW JET # 32	1
05-1-1-7		A6170-A26-6000	NOZZLE, MAIN SET	1
05-1-1-7-1		KAC73110	PIPE, BLEED	1
05-1-1-7-2		KAC72910	NOZZLE, MAIN	1
05-1-1-8		KAC73108	MAIN JET # 100	1
05-1-1-9		KAC72310	FLOAT ASSY.	1
05-1-1-10		KAC75710	CHAMBER O-RING	1
05-1-1-11		A0002-A26-9000	ACCELERATION PUMP COMP	1
05-1-1-12		KAC71520	DRAIN SCREW ASSY	1
05-1-1-13		AC001	SCREW PANHEAD	2
05-1-1-14		A6111-A26-6000	TUBE	1
05-1-1-15		KAC73820	CARB TOP COVER	1
05-1-1-16		KAC73710	SPRING	1
05-1-1-17		KAC73610	SPRING PLACE	1
05-1-1-18		I3500-05010-0H	SCREW PAN	2
05-1-1-19		KAC71610	BRACKET WIRE ASSY	1
05-1-1-20		AC033	SCREW	3
05-1-1-21		KAC70210	CARB CHAMBER	1
05-1-1-22		A6106-A26-6000	PLUG	1
05-1-2		A0001-A26-9000	MANUAL CHOKE COMP 1	1
05-1-3		A7920-A26-9000	CABLE, AIR CUT	1
05-1-4		A0003-A26-9000	TUBE BREATHER COMP	1
05-1-4-1		KAB46510	TUBE CLIP (B)	1
05-1-4-2		KAB86210	TUBE, RUBBER (A)	1
05-1-4-3		KAB46410	TUBE CLIP (A)	2
05-1-4-4		KAB87710	PIPE, BYPASS	1
05-1-4-5		KAB87810	TUBE, RUBBER (B)	1
05-2		A7910-9KA0-0000	CABLE, THROTTLE	1


6. DRIVEN PULLEY



ITEM	AVAIL	PART NO.	NAME	QTY
06			DRIVEN PULLEY (CVT)	
06-1		B301A-A11-0000	PULLEY ASSY, DRIVEN	1
06-1-1		B2300-A11-0000	PLATE COMP DRIVE	1
06-1-1		B2300-A11-0000	PLATE COMP DRIVE	1
06-1-1-1		B2401-A11-0000	SPRING CLUTCH	3
06-1-1-1		B2401-A11-0000	SPRING CLUTCH	3
06-1-1-1	N	B2350-A11-0000	PLATE COMP DRIVE	1
06-1-1-2	N	B2401-A11-0000	SPRING CLUTCH	3
06-1-1-3	N	B2530-A11-0000	WEIGHT SET CLUTCH	3
06-1-1-4	N	B2804-A11-0000	ROLLER CLUTCH	3
06-1-1-5	N	I4540-0501D	CIRCLIP	3
06-1-1-6	N	I0442-A11-0000	WASHER CLUTCH	3
06-1-2		I4002-280A0	NUT HEX	1
06-1-2		I4002-280A0	NUT HEX	1
06-1-3		B2101-A11-0000	OUTER CLUTCH	1
06-1-3		B2101-A11-0000	OUTER CLUTCH	1
06-1-4		B3210-A11-0000	FACE COMP, DRIVEN	1
06-1-4		B3210-A11-0000	FACE COMP, DRIVEN	1
06-1-4-1	N	I6140-69013-10	BEARING BALL RADIAL	1
06-1-4-2	N	I4520-24000	CIRCLIP IN	1
06-1-4-3	N	I1120-172518	BEARING, NEEDLE	1
06-1-4-4	N	B3211-A11-0000	FACE COMP, DRIVEN	1
06-1-5		B3225-A11-0000	PIN GUIDE	3
06-1-5		B3225-A11-0000	PIN GUIDE	3
06-1-6		I1211-A11-0000	OIL SEAL	2
06-1-6		I1211-A11-0000	OIL SEAL	2
06-1-7		B3220-A11-0000	FACE COMP MOVABLE DRIVE	1
06-1-7		B3220-A11-0000	FACE COMP MOVABLE DRIVE	1
06-1-8		I4608-39822	O-RING	1
06-1-8		I4608-39822	O-RING	1
06-1-9		I4608-36015	O-RING	1
06-1-9		I4608-36015	O-RING	1
06-1-10		B3233-A11-0000	SPG DRIVEN FACE	1
06-1-10		B3233-A11-0000	SPG DRIVEN FACE	1
06-1-11		B3238-A11-0000	COLLAR SPRING	1
06-1-11		B3238-A11-0000	COLLAR SPRING	1
06-2		I4050-10090-0H	FLANGE NUT, HEX.	1
06-3		B210A-A26-9000	FACE ASSY. MOVABLE DRIVE	1
06-3-1		B2103-A11-0000	FACE DRIVER	1


06-3-2		B2105-A26-9000	BOSS DRIVE FACE	1
06-3-3		B2110-A26-9000	FACE COMP, MOVABLE DRIVE	1
06-3-4		A0005-A26-9000	ROLLER COMP WEIGHT	1
06-3-4-1		B2121-A26-9000	ROLLER WEIGHT	6
06-3-5		B2131-A26-9000	PLATE, RAMP	1
06-3-6		B2132-A26-9000	PIECE SLIDE	3
06-3-7		B2102-A11-0000	FACE DRIVE	1
06-4		B3100-A11-0000	BELT DRIVE	1
06-5		B8211-A26-9000	RATCHET KICK STARTER	1
06-6		I4104-14515	WASHER	1
06-7		I4050-12110-0H	FLANGE NUT, HEX.	1

7.START MOTOR / OIL PUMP



ITEM	AVAIL	PART NO.	NAME	QTY
07			START MOTOR OIL PUMP	
07-1		I6001-06040-0H	FLANGE BOLT, HEX.	2
07-2		C1200-A26-9000	MOTOR START COMP	1
07-3		I4104-08218	WASHER	2
07-4		B8100-B00-0000	GEAR COMP STARTER REDUCTION	1
07-4-1		B8101-B00-0000	GEAR STARTER REDUCTION	1
07-4-2		I1130-081210	BEARING, NEEDLE	1
07-5		B8102-B00-0000	SHAFT START REDUCTION	1
07-6		B8105-B00-0000	PLATE START REDUCTION	1
07-7		I3892-06014-0H	SCREW, PAN	2
07-8		I4104-55506	WASHER	1
07-9		B8115-B00-0000	BOSS GEAR	1
07-10		I1100-555913	BRARING, NEEDLE	1
07-11		B8110-B00-0000	GEAR COMP STARTING CLUTCH	1
07-12		B812A-A26-9000	ONE WAY CLUTCH ASSY	1
07-13		A5100-A12-0000	OIL PUMP COMP	1
07-13-1		I4303-04118	KNOCK PIN	1
07-14		I6001-06020-0H	FLANGE BOLT, HEX.	2
07-15		I6001-06025-0C	FLANGE BOLT, HEX.	1
07-16		A5133-A11-0000	GEAR OIL PUMP DRIVEN	1
07-17		I4050-06060-0H	FLANGE NUT, HEX.	1
07-18		I4104-16230	WASHER	1
07-19		I4301-08140	KNOCK PIN	1
07-20		I4608-09016	O-RING	2


8. FAN COVER / GENERATOR



ITEM	AVAIL	PART NO.	NAME	QTY
08			FAN COVERGENERATOR	
08-1		A964A-A26-0000	DUCT INLET ASSY	0
08-1-1		A961A-A26-0000	COVER ASSY FAN	1
08-1-1		A961A-A26-0000	COVER ASSY FAN	1
08-1-1-1		A9610-A26-0000	COVER COMP FAN	1
08-1-1-1		A9610-A26-0000	COVER COMP FAN	1
08-1-1-1		A9610-A26-0000	COVER COMP FAN	1
08-1-1-2		G0529-A04-0000	GROMMET SHROUD	1
08-1-1-2		G0529-A04-0000	GROMMET SHROUD	1
08-1-1-2		G0529-A04-0000	GROMMET SHROUD	1
08-1-1-3		H7541-A26-0000	LABEL OIL CAP	1
08-1-1-3		H7541-A26-0000	LABEL OIL CAP	1
08-1-1-3		H7541-A26-0000	LABEL OIL CAP	1
08-1-1-4		I6231-065120	COLLAR	2
08-1-1-4		I6231-065120	COLLAR	2
08-1-2		A9640-A26-0000	DUCT INLET COMP.	1
08-1-2		A9640-A26-0000	DUCT INLET COMP.	1
08-1-2-1		A9616-A26-0000	DUCT INLET	1
08-1-2-1		A9616-A26-0000	DUCT INLET	1
08-1-2-1		A9616-A26-0000	DUCT INLET	1
08-1-2-2		A9617-A26-0000	RUBBER	1
08-1-2-2		A9617-A26-0000	RUBBER	1
08-1-2-2		A9617-A26-0000	RUBBER	1
08-1-2-3		A9618-A26-0000	RUBBER	1
08-1-2-3		A9618-A26-0000	RUBBER	1
08-1-2-3		A9618-A26-0000	RUBBER	1
08-1-2-4		G0529-V30-0000	GROMMET SHROUD	1
08-1-2-4		G0529-V30-0000	GROMMET SHROUD	1
08-1-2-4		G0529-V30-0000	GROMMET SHROUD	1
08-1-3		I3893-05012-0H	SCREW WASHER	3
08-1-3		I3893-05012-0H	SCREW WASHER	3
08-2		A962A-A12-0000	SHROUD A ASSY	1
08-2-1		A9620-A12-0000	SHROUD A COMP	1
08-2-1		A9620-A12-0000	SHROUD A COMP	1
08-2-1-1		I6231-065050	COLLAR	1
08-2-1-1		I6231-065050	COLLAR	1
08-2-1-2		I6231-065120	COLLAR	1
08-2-1-2		I6231-065120	COLLAR	1
08-2-2		A9637-A12-0000	NUT SPRING	1

08-2-2		A9637-A12-0000	NUT SPRING	1
08-2-3		A9637-V30-0000	NUT SPRING	1
08-2-3		A9637-V30-0000	NUT SPRING	1
08-3		I6001-06025-0C	FLANGE BOLT, HEX.	3
08-4		I3500-05025-0G	SCREW, PAN	2
08-5		A9625-A11-0000	SEAL SHROUD	1
08-6		I6001-06016-0H	FLANGE BOLT, HEX.	5
08-7		A9510-A12-0000	FAN COMP COOLING	1
08-8		I4050-12110-0H	FLANGE NUT, HEX.	1
08-9		C1110-A12-9000	FLYWHEEL COMP	1
08-10		I6001-06020-0H	FLANGE BOLT, HEX.	2
08-11		C1120-A26-0000	STATOR COMP	1
08-12		I3412-05014-0H	BOLT, HEX.	2
08-13		A963A-A12-0000	SHROUD B ASSY	1
08-13-1		A9630-A12-0000	SHROUD B COMP	1
08-13-1		A9630-A12-0000	SHROUD B COMP	1
08-13-1-1		I6231-065050	COLLAR	1
08-13-1-1		I6231-065050	COLLAR	1
08-13-2		A9636-A12-0000	BOX TENSIONER LIFTER	1
08-13-2		A9636-A12-0000	BOX TENSIONER LIFTER	1
08-13-3		A9637-A12-0000	NUT SPRING	1
08-13-3		A9637-A12-0000	NUT SPRING	1
08-13-4		I3903-380H0	TRUSS	2
08-13-4		I3903-316B0	TAPPING SCREW, TRUSS	2
08-13-5		A9637-V30-0000	NUT SPRING	1
08-13-5		A9637-V30-0000	NUT SPRING	1
08-13-6		A9638-A12-0000	CLAMPER CABLE	1
08-13-6		A9638-A12-0000	CLAMPER CABLE	1
08-14		C2963-A09-0000	CLAMPER PULSER CORD	1
08-15		A9619-A26-9000	FENDER	1
08-16		I4104-05501	WASHER	2
08-17		I5701-06025-0C	FLANGE BOLT, HEX.	1


9. TRANSMISSION



ITEM	AVAIL	PART NO.	NAME	QTY
09			TRANSMISSION	
09-1		I2201-06010-0H	BOLT, HEX.	2
09-2		B3811-A00-0000	PLATE FIXING	1
09-3		B3801-A26-0000	SPROCKET DRIVE	1
09-4		I4510-20000	CIRCLIP EX	1
09-5		I4104-20210	WASHER	1
09-6		I4520-42000	CIRCLIP IN	1
09-7		I6150-60040-10	BEARING, BALL, RADIAL	1
09-8		I1204-B00-0000	OIL SEAL	1
09-9		I4530-32000	CIRCLIP	1
09-10		B1300-A26-9900	COVER COMP, MISSION	1
09-11		I5701-08035-0H	FLANGE BOLT, HEX.	4
09-12		I5701-08040-0H	FLANGE BOLT, HEX.	2
09-13		A1203-A26-0000	REAR SHOCK ABSORBER BUSHING	1
09-14		I4301-10140	KNOCK PIN	2
09-15		I1130-253316	BEARING, NEEDLE	1
09-16		B3430-A26-9000	FINAL SHAFT COMP	1
09-17		I6100-62013-10	BEARING, BALL, RADIAL	3
09-18		I6100-62020	BEARING, BALL, RADIAL	1
09-19		B3420-A26-9000	COUNTER SHAFT COMP	1
09-20		B3411-A26-9000	SHAFT DRIVE	1
09-21		I6100-60030	BEARING, BALL, RADIAL	1
09-22		I4510-17000	CIRCLIP EX	1
09-23		I1203-B00-0000	OIL SEAL	1
09-24		I3500-06010-0A	SCREW, PAN	1
09-25		I4104-06512A	WASHER	1
09-26		B1395-A26-6000	GASKET, MISSION COVER	1
09-27		B4421-A26-9000	SHIFT PUSH	1
09-28		B4625-A26-9000	SHAFT FIXED	1
09-29		B4306-A26-9000	SHIFT FIXD SPRING	2
09-30		I4104-06010	WASHER	2
09-31		I4540-0501G	CIRCLIP	2
09-32		B4231-A26-9000	FORK SHIFT	1
09-33		B4241-B07-0000	SHAFT GEAR SHIFT	2
09-34		B4411-A26-9000	CAM SHIFT	1
09-35		I6100-69010	BEARING, BALL, RADIAL	1
09-36		B4431-A26-9000	KNOCK BLOCK	1
09-37		I4104-12310	WASHER	1

09-38		B3250-A26-9000	REVERSE GEAR COMP	1
09-39		B4308-A26-9000	INSULATOR SHIM	1
09-40		I2600-03008	SCREW, PAN	1

10. AIR CLEANER



ITEM	AVAIL	PART NO.	NAME	QTY
10			AIR CLEANER	
10-1		A723A-A26-9000	AIR CLEANER ASSY	1
10-1-1		A7230-A26-9000	CASE, AIR/C	1
10-1-1-1		A7209-A09-0000	AIR CLEANER CASE BUSH	2
10-1-2		A7209-A09-0000	AIR CLEANER CASE BUSH	2
10-1-3		A7206-A09-9000	COVER DOWN	2
10-1-4		A7205-A09-9000	FILTER ELEMENT	2
10-1-5		A7207-A09-9000	COVER TOP	2
10-1-6		I3903-412B0	TRUSS	2
10-1-7		I4608-94535	O-RING	2
10-1-8		A7231-A09-9000	COVER AIR/C	2
10-1-9		I3903-220B0	TAPPING SCREW, TRUSS	6
10-1-10		A7253-A26-0000	AIR CLEANER CONNECTOR TUBE	1
10-1-11		A5055-A26-0000	TUBE BREATHER	1
10-1-12		A7255-A26-0000	BAND CONNECTING TUBE	2
10-1-13		I5002-12312	TUBE CLIP	4
10-1-14		A7234-B00-0000	TUBE DRAIN	2
10-1-15		A7232-B00-0000	CAP	2
10-2		A736A-A26-0000	OIL GAS CATCH TANK ASSY	1
10-2-1		A7365-A26-0000	TUBE, BREATHER A	1
10-2-2		A7364-V30-9000	TUBE, BREATHER B	1
10-2-3		I5002-10810-0H	TUBE CLIP	2
10-2-4		I5002-14510-0H	TUBE CLIP	1
10-2-5		I5002-08510-0H	TUBE CLIP	1

No picture.

ITEM	AVAIL	PART NO.	NAME	QTY
11			PREARRANGE	


No picture.

ITEM	AVAIL	PART NO.	NAME	QTY
12			ENGINE	
12-1		AA000-A26-9000	ENGINE	1
12-2		A1000-5EA0-9000	RUBBER CAP KICK SHAFT	1
12-3		B8300-B00-9001	ARM COMP KICK STARTER	1

No picture.


ITEM	AVAIL	PART NO.	NAME	QTY
13			MUFFLER	
13-1		A830A-9KA0-0000	MUFFLER PIPE ASSY.	1
13-1-1		A8301-9KA0-0000	MUFFLER PIPE , FRONT	1
13-1-2		A8302-9KA0-0000	MUFFLER PIPE , REAR	1
13-1-3		A8303-FIA0-0000	SPARK ARRESTER	1
13-1-4		A8304-9KA0-0000	SPRING	1
13-1-5		A8305-9KA0-0000	SOCKET BOLT	1
13-1-6		A8306-9KA0-0000	HEX, NUT, SAFETY	1
13-2		I0179-06850	NUT	2
13-3		A7400-5PA0-0000	AICV COMP.	1
13-3-1		A7402-5PA0-0000	AICV BODY	1
13-3-2		A7403-5PA0-0000	AICV WEB	1
13-3-3		A7404-5PA0-0000	AICV FILTER	1
13-3-4		I3901-314C5	TAPPING SCREW, PAN	2
13-3-5		A7405-5PA0-0000	FIXED PLATE , REED VALVE	1
13-3-6		A7406-5PA0-0000	REED VALVE	1
13-3-7		A7407-5PA0-0000	SEAL	1
13-3-8		A7408-5PA0-0000	CAP, AICV	1
13-3-9		I3901-425C5	TAPPING SCREW ,PAN	2
13-4		A7420-9KA0-0000	CONNECTING TUBE ASSY.	1
13-4-1		A7421-9KA0-0000	CONNECTING TUBE	1
13-4-1		A7421-9KA0-0000	CONNECTING TUBE	1
13-4-2		A7422-5PA0-0000	CLAMP, TUBE	2
13-4-2		A7422-5PA0-0000	CLAMP, TUBE	2
13-5		I5827-08030	FLANGE BOLT, HEX.	1
13-6		I5611-08200	HEX. FLANGE NUT, SAFETY	1
13-7		I7701-50016	SCREW, TAPPING	2

14. FRAME




ITEM	AVAIL	PART NO.	NAME	QTY
14			FRAME	
14-1		E0100-9KA0-0000	FRAME COMP.	1
14-2		I6100-6002ZZ	BEARING (6002ZZ)	1
14-3		I4510-32000	C CLIP EX 32	1
14-4		I2502-10170-6C	FLANGE BOLT, HEX	1
14-5		E035A-9KA0-0000	ENGINE SUSPENSION ASSY	1
14-5-1		E0350-9KA0-0000	ENGINE SUSPENSION	1
14-5-2		E0201-5EA0-0000	BUSH	2
14-5-3		E0360-9KA0-0000	COLLAR	1
14-6		E0351-5EA0-0000	FLANGE BOLT, HEX.	1
14-7		I9905-10100	WASHER	2
14-8		I5612-10200	HEX. FLANGE NUT, SAFETY	3
14-9		I2502-10165-6C	FLANGE BOLT, HEX	1
14-10	N	E0101-5EA0-0000	FRAME NUMBER PLATE	1
14-11		H750A-5BA1-0000	NAIL, PULL	2
14-12		I5611-06200-0G	HEX. FLANGE NUT, SAFETY	2
14-13		G7232-9FA0-0000	PLUG RUBBER	2
14-15		E0107-9KA0-0000	LEFT, FIXED PLATE, FRONT FENDER	1
14-16		E0108-9KA0-0000	RIGHT, FIXED PLATE, FRONT FENDER	1
14-17		I0149-06823-01	BOLT, FLANGE (M6×23)	2
14-18		I0149-06012	FLANGE BOLT, HEX.	5
14-19		D0103-9KA0-0000	DRIVE CHAIN COVER	1
14-20		I0149-06016	FLANGE BOLT, HEX.	2
14-21		H3503-LRA0-0000	T COLLAR	3
14-22		F4309-5EA0-0000	STICKER, MFD.	1
14-23		G7212-5EA0-0000	RUBBER DAMPER	2
14-24		H7138-9KA0-0000	STICER, EMISSION CONTROL	1
14-25		B0101-9KA0-0000	CVT BAND INSULATOR	1
14-26		H7113-5EE0-0000	STICKER, HEAD LIGHT SEAT	1

15.SWING ARM,FOOTREST,FENDER BAR



ITEM	AVAIL	PART NO.	NAME	QTY
15			SWING ARMFOOTRESTFEND BAR	
15-1		E020A-9KA0-0700	ARM, SUSPENSION,L.U.ASSY	1
15-1-1		E0200-9KA0-0700	ARM, SUSPENSION,L.U.	1
15-1-2		E0201-9KA0-0000	BUSH, ARM SUSPENSION	2
15-1-3		E0209-9KA0-0000	COLLAR, ARM SUSPENSION	1
15-2		E021A-9KA0-0700	ARM, SUSPENSION,R.U.ASSY	1
15-2-1		E0210-9KA0-0700	ARM, SUSPENSION,R.U.	1
15-2-2		E0201-9KA0-0000	BUSH, ARM SUSPENSION	2
15-2-3		E0209-9KA0-0000	COLLAR, ARM SUSPENSION	1
15-3		E022A-9KA0-0700	ARM, SUSPENSION,L.L.ASSY	1
15-3-1		E0220-9KA0-0700	ARM, SUSPENSION,L.L.	1
15-3-2		E0201-9KA0-0000	BUSH, ARM SUSPENSION	4
15-3-3		E0208-9KA0-0000	COLLAR, ARM SUSPENSION	2
15-4		E023A-9KA0-0700	ARM, SUSPENSION,R.L.ASSY	1
15-4-1		E0230-9KA0-0700	ARM, SUSPENSION,R.L.	1
15-4-2		E0201-9KA0-0000	BUSH, ARM SUSPENSION	4
15-4-3		E0208-9KA0-0000	COLLAR, ARM SUSPENSION	2
15-5		E0700-9KA0-0000	FOOTREST BAR ASSY.(LEFT)	1
15-6		E0706-9KA0-0000	FOOTREST BAR ASSY.(RIGHT)	1
15-7		I5611-10200	HEX. FLANGE NUT, SAFETY	6
15-8		E040A-9KA0-9700	BAR COMP., CARRY FRONT	1
15-8-1		E0400-9KA0-9700	BAR, CARRY FRONT	1
15-8-1		E0400-9KA4-9700	BAR, CARRY FRONT	1
15-8-2		E0707-5EE0-0000	RUBBER PLUG	4
15-9		E0410-9KA0-0000	BUMPER REAR,ASSY	1
15-10		I0149-08012	FLANGE BOLT, HEX.	6
15-11		I0149-08016	FLANGE BOLT, HEX.	2
15-12		E0703-9KA0-0000	FOOTREST REAR BAR (L)	1
15-13		E0705-9KA0-0000	FOOTREST REAR BAR (R)	1
15-14		I0149-06012	FLANGE BOLT, HEX.	4
15-15		I7507-FIA0-0000	BOLT, HEX.	8
15-16		I2502-10170-6C	FLANGE BOLT, HEX	2
15-17		I4012-100H0	NUT	4
15-18		I4201-46325	SPLIT PIN	4
15-19		I0149-10080	FLANGE BOLT, HEX.	4
15-20		I0149-06823-01	BOLT,FLANGE(M6×23)	2
15-21		I5611-06200-0G	HEX. FLANGE NUT, SAFETY	2


16.FENDER



ITEM	AVAIL	PART NO.	NAME	QTY
16			FENDER	
16-1		F4300-5EE0-5400	FRONT BODY COVER(BLUE)	1
16-1		F4300-5EE0-1100	FRONT BODY COVER (YELLOW)	1
16-1		F4300-5EE0-4200	FRONT BODY COVER(RED)	1
16-1		F4300-5EE0-0800	FRONT BODY COVER(BLACK)	1
16-2		H3500-5EE0-5400	REAR BODY COVER (BLUE)	1
16-2		H3500-5EE0-1100	REAR BODY COVER (YELLOW)	1
16-2		H3500-5EE0-0800	REAR BODY COVER (BLACK)	1
16-2		H3500-5EE0-4200	REAR BODY COVER (RED)	1
16-3		F3520-5EE0-5400	FRONT FENDER (L) (BLUE)	1
16-3		F3520-5EE0-0800	FRONT FENDER (L) (BLACK)	1
16-3		F3520-5EE0-4200	FRONT FENDER (L) (RED)	1
16-3		F3520-5EE0-1100	FRONT FENDER (L) (YELLOW)	1
16-4		F3620-5EE0-0800	FRONT FENDER (R) (BLACK)	1
16-4		F3620-5EE0-4200	FRONT FENDER (R) (RED)	1
16-4		F3620-5EE0-1100	FRONT FENDER (R) (YELLOW)	1
16-4		F3620-5EE0-5400	FRONT FENDER (R) (BLUE)	1
16-5		H7101-9FA0-9000	STICKER,WARNING PASSENGER	1
16-6		H7102-9FA0-9000	STICKER,WARNING (Y12)	1
16-7		I7707-04016	TAPPING SCREW, TRUSS	2
16-8		F4301-5EE0-5400	FRONT CENTER COVER(BLUE)	1
16-8		F4301-5EE0-0800	FRONT CENTER COVER(BLACK)	1
16-8		F4301-5EE0-1100	FRONT CENTER COVER(YELLOW)	1
16-8		F4301-5EE0-4200	FRONT CENTER COVER(RED)	1
16-9		E0415-5EE0-0000	FILTER NET	1
16-10		E0417-5EE0-0000	FILTER NET PLUG	4
16-11		H7107-5EB0-0000	EMBLEM, E-TON LOGO(SILVER)	1
16-12		H7124-9KA0-4200	FRONT BODY STICKER (RED) (L)	1
16-12		H7124-9KA0-1100	FRONT BODY STICKER (YELLOW)(L)	1
16-13		H7125-9KA0-4200	FRONT BODY STICKER (RED)(R)	1
16-13		H7125-9KA0-1100	FRONT BODY STICKER (YELLOW) (R)	1
16-14		E3205-9EF0-4201	COVER,HANDLE BAR(RED)	1
16-14		E3205-9EF0-5401	COVER,HANDLE BAR(BLUE)	1
16-14		E3205-9EF0-0801	COVER,HANDLE BAR(BLACK)	1
16-14		E3205-9EF0-1101	COVER,HANDLE BAR(YELLOW)	1
16-14-1		C5010-9FA0-0001	MAIN SWITCH COMP	1
16-14-1		C5010-9FA0-0000	MAIN SWITCH	1


16-14-1-1		C5013-9FA0-0000	MATERIAL KEY (RIGHT CUT)	1
16-14-1-1		C5013-9FA0-0000	MATERIAL KEY (RIGHT CUT)	1
16-14-1-1		C5013-9FA0-0000	MATERIAL KEY (RIGHT CUT)	1
16-14-1-2		C5018-9FA0-0000	MATERIAL KEY (LEFT CUT)	1
16-14-1-2		C5018-9FA0-0000	MATERIAL KEY (LEFT CUT)	1
16-14-1-2		C5018-9FA0-0000	MATERIAL KEY (LEFT CUT)	1
16-15		H3720-5EE0-1100	REAR FENDER (L)(YELLOW)	1
16-15		H3720-5EE0-0800	REAR FENDER (L)(BLACK)	1
16-15		H3720-5EE0-4200	REAR FENDER (L)(RED)	1
16-15		H3720-5EE0-5400	REAR FENDER (L)(BLUE)	1
16-16		H3820-5EE0-0800	REAR FENDER (R)(BLACK)	1
16-16		H3820-5EE0-4200	REAR FENDER (R)(RED)	1
16-16		H3820-5EE0-1100	REAR FENDER (R)(YELLOW)	1
16-16		H3820-5EE0-5400	REAR FENDER (R)(BLUE)	1
16-17		H3520-5EE0-0000	FOOTREST,(L)	1
16-18		H3620-5EE0-0000	FOOTREST,(R)	1
16-19		I0119-06802	BOLT, HEX.	9
16-20		I0119-06821	BOLT, HEX.	2
16-21		I8310-06020-01	SCREW, OVAL	8
16-22		I5611-06200-0G	HEX. FLANGE NUT, SAFETY	4
16-23		E0117-9EA0-0000	SCREW, TRUSS	4
16-24		I8310-FIA0-0000	PLASTIC SCREW	2
16-25		H7106-5ED0-0000	WARNING STICKER,MUFFLER	1
16-26		I3500-06012-1A	SCREW PAN	2
16-28		H7129-9EF0-0000	STICKER,INDICATE GEAR	1
16-29		H7103-9EF0-0000	STICKER, VIPER-90R (L)	1
16-30		H7104-9EF0-0000	STICKER, VIPER-90R (R)	1
16-31		H7128-9KA0-4200	STICKER,REAR BODY (RED)(L)	1
16-31		H7128-9KA0-1100	STICKER,REAR BODY (YELLOW))(L)	1
16-32		H7129-9KA0-1100	STICKER,REAR BODY (YELLOW))(R)	1
16-32		H7129-9KA0-4200	STICKER,REAR BODY (RED)(R)	1
16-33		H7126-5EE0-0000	STICKER,REAR FENDER(L)	1
16-34		H7127-5EE0-0000	STICKER,REAR FENDER(R)	1
16-35		H7131-9EF0-0000	STICKER,REVERSE (L)	1
16-36		H7132-9EF0-0000	STICKER,REVERSE (R)	1
16-37		C7202-9EF0-0000	FUEL METER ASSY.	1
16-41		H7139-FIA0-0000	SPARK ARRESTER DECLARATION	1

17. SEAT



ITEM	AVAIL	PART NO.	NAME	QTY
17			SEAT	
17-1		G7200-5EE0-1100	SEAT ASSY.(BLACK/YELLOW)	1
17-1		G7200-5EE0-4200	SEAT ASSY.(BLACK/RED)	1
17-1-1		G7200-5EE0-1100	SEAT ASSY.(BLACK/YELLOW)	1
17-1-1		G7200-5EE0-4200	SEAT ASSY.(BLACK/RED)	1
17-1-2		G7201-9ED0-0000	SEAT FIXER,ASSY	1

18. OIL TANK, FUEL TANK



ITEM	AVAIL	PART NO.	NAME	QTY
18			FUEL TANK	
18-1		A7500-9KA0-0000	METAL FUEL TANK	1
18-2		A762A-5EA0-0000	FUEL TANK CAP ASSY	1
18-2-1		A7620-5EA0-0000	FUEL TANK CAP	1
18-2-2		A7621-9FA0-0000	TUBE, RUBBER	1
18-3		I7507-06225	BOLT, HEX.	2
18-4		A751A-9KA0-9000	FUEL FILTER ASSY	1
18-4-1		A7519-FIA0-1000	FUEL FILTER	1
18-4-2		A7514-9KA0-9000	FUEL TUBE	2
18-4-3		I5002-40850-04	CLAMP, TUBE	2
18-4-4		I5002-50000	CLIP, TUBE	2
18-5		A7501-5EE0-9000	FUEL PIPE COMP(A)	1
18-5-1		I5005-050242-6	RUBBER TUBE	1
18-5-2		I5002-50000	CLIP, TUBE	1
18-5-3		I5002-41200-04	CLIP	1
18-6		A7502-9KA0-9000	FUEL PIPE COMP(B)	1
18-6-1		I5005-050252-6	RUBBER TUBE	1
18-6-2		I5002-50000	CLIP, TUBE	1
18-6-3		I5002-41200-04	CLIP	1
18-7		A7520-5EA0-0000	MANUAL FUEL CUP	1
18-8		I8506-05016	SCREW PAN	2
18-9		A7622-5EA0-0000	RUBBER PAD	1
18-10		F6520-5EE0-0000	DAMPER	2
18-11		G5010-5EE0-0000	COLLAR	2
18-12		C1510-9FA0-0000	FOAM RUBBER STRIP	4

No picture.

ITEM	AVAIL	PART NO.	NAME	QTY
19			SUSPENSION	
19-1		E1105-9KA0-0700	SUSPENSION, FRONT (SILVER)	2
19-2		I0102-10040	BOLT, HEX	6
19-3		I5701-10500	FLANGE NUT, HEX.	4
19-4		E2400-9KA0-0000	SUSPENSION, REAR	1
19-5		I0468-12006	PIN	6

No picture.

ITEM	AVAIL	PART NO.	NAME	QTY
20			FRONT WHEEL	
20-1	N	D471A-9EE0-0000	WHEEL ASSY.,(18×7-8)	1
20-1-1		D4710-9EE0-0000	TIRE, FRONT	1
20-1-2	N	D4601-5EB0-0000	WHEEL RIM	1
20-2	N	D471B-9EE0-0000	WHEEL ASSY.,(18×7-8)	1
20-2-1	N	D4601-5EB0-0000	WHEEL RIM	1
20-2-2		D4710-9EE0-0000	TIRE, FRONT	1
20-3		D4609-5EA0-0001	RUBBER CAP	2
20-4		D4611-9EA0-0000	FLANGE NUT, HEX.	8

No picture.

ITEM	AVAIL	PART NO.	NAME	QTY
21			REAR WHEEL	
21-1		D472C-9EE0-0000	SHAFT CONNECTER WITH BOLTS+REAR WHEEL	1
21-1-1	N	D471C-9EE0-0000	REAR WHELL ASSY.,(18×9-8)	1
21-1-1-1		D4720-9EE0-0000	TIRE, REAR	1
21-1-1-2	N	D4601-5FA0-0000	WHEEL RIM	1
21-1-2		D2705-9EA0-1000	SHAFT CONNECTER WITH BOLTS	1
21-1-3		D4611-9EA0-0000	FLANGE NUT, HEX.	4
21-2		D472C-9EE0-0000	SHAFT CONNECTER WITH BOLTS+REAR WHEEL	1
21-2-1	N	D471C-9EE0-0000	REAR WHELL ASSY.,(18×9-8)	1
21-2-1-1		D4720-9EE0-0000	TIRE, REAR	1
21-2-1-2	N	D4601-5FA0-0000	WHEEL RIM	1
21-2-2		D2705-9EA0-1000	SHAFT CONNECTER WITH BOLTS	1
21-2-3		D4611-9EA0-0000	FLANGE NUT, HEX.	4
21-3		I5500-14100	CASTLE NUT	2
21-4		I9905-14200	WASHER	2
21-5		D4609-5EA0-0001	RUBBER CAP	2
21-6		I4201-46325	SPLIT PIN	2
21-7		D2309-5EA0-0000	WASHER	2

No picture.

ITEM	AVAIL	PART NO.	NAME	QTY
22			FRONT BRAKE	
22-1		E020B-9KA0-0000	STEERING KNUCKLE ASSY.(LEFT)	1
22-1-1		D4610-9KA0-0000	BRAKE DRUM, FRONT	1
22-1-2		D4612-9EA0-0000	BOLT, STUD	4
22-1-3		D4620-9KA0-0000	INNER HOUSING	1
22-1-4		D4621-9KA0-0000	OIL-SEALING HOUSING	1
22-1-5		D5120-9KA0-0000	FRONT BRAKE SHOE COMP	1
22-1-6		D5125-9KA0-0000	SPRING	1
22-1-7		D5141-9KA0-0000	FRONT BRAKE ARM CAM	1
22-1-8		I4608-06710	O-RING	1
22-1-9		D5351-9KA0-0000	FRONT BRAKE DISC, LEFT	1
22-1-10		D5410-9KA0-0000	FRONT BRAKE ARM ,LEFT	1
22-1-11		I0020-06030	BOLT	1
22-1-12		E0205-9KA0-0000	LEFT,KNUCKLE	1
22-1-13		E0204-9KA0-0000	STEERING(L)	1
22-1-14		I0020-08030	BOLT(M8x30)	1
22-1-15		I2020-80001	NUT	1
22-1-16		I4104-06710	WASHER	1
22-1-17		I2020-60001	NUT	1
22-1-18		I6100-6004RZ	BEARING(INNER)	1
22-1-19		I6100-6003RZ	BEARING(OUTER)	1
22-1-20		I1225-42007	OIL SEAL(INNER)	1
22-1-21		I1225-35007	OIL SEAL(OUTER)	1
22-1-22		D4608-9KA0-0000	WASHER	1
22-1-23		I4012-140H0A	NUT	1
22-1-24		I4201-60320	PIN	1
22-1-25		I4012-100H0	NUT	2
22-2		E021B-9KA0-0000	STEERING KNUCKLE ASSY.(RIGHT)	1
22-2-1		D4610-9KA0-0000	BRAKE DRUM, FRONT	1
22-2-2		D4612-9EA0-0000	BOLT, STUD	4
22-2-3		D4620-9KA0-0000	INNER HOUSING	1
22-2-4		D4621-9KA0-0000	OIL-SEALING HOUSING	1
22-2-5		D5120-9KA0-0000	FRONT BRAKE SHOE COMP	1
22-2-6		D5125-9KA0-0000	SPRING	1
22-2-7		D5141-9KA0-0000	FRONT BRAKE ARM CAM	1
22-2-8		I4608-06710	O-RING	1
22-2-9		D5352-9KA0-0000	FRONT BRAKE DISC, RIGHT	1

22-2-10		D5411-9KA0-0000	FRONT BRAKE ARM ,LEFT	1
22-2-11		I0020-06030	BOLT	1
22-2-12		E0215-9KA0-0000	LEFT,KNUCKLE	1
22-2-13		E0214-9KA0-0000	STEERING(R)	1
22-2-14		I0020-08030	BOLT(M8x30)	1
22-2-15		I2020-80001	NUT	1
22-2-16		I4104-06710	WASHER	1
22-2-17		I2020-60001	NUT	1
22-2-18		I6100-6004RZ	BEARING(INNER)	1
22-2-19		I6100-6003RZ	BEARING(OUTER)	1
22-2-20		I1225-42007	OIL SEAL(INNER)	1
22-2-21		I1225-35007	OIL SEAL(OUTER)	1
22-2-22		D4608-9KA0-0000	WASHER	1
22-2-23		I4012-140H0A	NUT	1
22-2-24		I4201-60320	PIN	1
22-2-25		I4012-100H0	NUT	2
22-3		D5419-5EA0-0000	FRONT RETURN SPRING	2
22-4		E5450-9KA0-0000	CABLE, FRONT BRAKE ASSY	2


No picture.

ITEM	AVAIL	PART NO.	NAME	QTY
23			REAR BRAKE	
23-1		D2310-5EE0-0000	REAR WHEEL BEARING SEAT ASSY	1
23-2		D2311-5EA0-0000	SPACER	1
23-3		I6100-6006ZZ	BEARING, BALL RADIAL	2
23-4		D2313-9EA0-0000	OIL SEAL	2
23-5		I0141-12025-01	FLANGE BOLT, HEX.	1
23-6		G7130-5EE0-0000	BRAKE CALLIPER	1
23-6-1		G7131-5EE0-0000	BRAKE SHOE COMP	1
23-6-1		G7131-5EE0-0000	BRAKE SHOE COMP	1
23-6-2		G7132-5EE0-0000	BOLT LEAKAGE	1
23-6-2		G7132-5EE0-0000	BOLT LEAKAGE	1
23-6-3		G7133-BCA0-0000	CAP LEAKAGE	1
23-6-3		G7133-BCA0-0000	CAP LEAKAGE	1
23-6-4		G7139-5EE0-0000	SPRING,PAO	1
23-6-5		G7134-5EE0-0000	RING,SEAL	1
23-6-6		G7136-5EE0-0000	PISTON, BRAKE CALIPER	1
23-6-7		G7135-5EE0-0000	RING,DUST RESISTANT	1
23-6-8		G71C1-5EE0-0000	BOOT	1
23-6-9		G71C2-5EE0-0000	BOOT	1
23-6-10		G71C3-5EE0-0000	BRACKET, CALLIPER	1
23-7		D0114-9EA0-0000	SPACER	1
23-8		D3520-FIA0-0000	BRAKE DISK	1
23-9		D3251-5EE0-0000	BRAKE DISK MOUNTING SEAT	1
23-10		D3210-5EE0-0000	BRAKE OIL TUBE	1
23-11		I0105-08035	BOLT FLANGE	2
23-12		I0110-10811	BOLT, SOCKET	3
23-13		I0401-10034	FLANGE BOLT, HEX.	1
23-14		I0201-10118	WASHER	2
23-15		G7111-BCA0-0000	BRAKE FUEL TUBE, CLIP	1
23-16		I0149-06012	FLANGE BOLT, HEX.	1
23-17		I0141-12028-01	BOLT FLANGE	3
23-18		I9901-08100	WASHER, SPRING	2
23-19		D3211-9KA0-0000	CLIP	1

No picture.


ITEM	AVAIL	PART NO.	NAME	QTY
24			HANDLE BAR	
24-1		E3100-9EF0-0000	HANDLE BAR ASSY.	1
24-2		E3166-5EA0-0000	GRIP	2
24-3		E3112-5EA0-0000	BOTTOM,HANDLE BAR CLAMP	2
24-4		E3110-5EA0-0000	CAP,HANDEL BAR CLAMP(L)	1
24-5		E3111-5EA0-0000	CAP,HANDEL BAR CLAMP(R)	1
24-6		I0050-06025	BOLT, SOCKET	4
24-7		D3200-5EG0-0000	BRAKE MASTER CYLINDER,LEFT	1
24-7-1		D6110-9KB0-0000	BRAKE LEVER, LEFT	1
24-7-2		D3202-FIA0-0000	BRAKE SWITCH ASSY.	1
24-7-3		D3208-5EG0-0000	FIXED SUPPORT COMP	1
24-8		E3180-FIA0-0000	LEVEL ASSY., RIGHT	1
24-8-1		E3181-5FA0-0000	LEVEL SET,RIGHT	1
24-8-2		E319A-5FA0-0000	LEVEL ACCELERATE	1
24-8-3		E3183-FIA0-0000	COVER LEVER	1
24-8-4		E3188-FIA0-0000	GASKET	1
24-8-5		I8506-04016	SCREW,PAN HEAD	2
24-9		I5611-10200	HEX. FLANGE NUT, SAFETY	2
24-10		E3101-5EE0-1000	HANDLE BAR PROTECT (W150×222L)	1
24-11		E3102-5EE0-1000	HANDLE BAR PROTECT FOAM(20×42×220L)	1
24-12		I0401-10034	FLANGE BOLT, HEX.	1
24-13		I0201-10118	WASHER	2

25.REAR WHEEL AXLE




ITEM	AVAIL	PART NO.	NAME	QTY
25			REAR WHEEL AXLE	
25-1		D2301-9EA0-0000	REAR AXLE	1
25-2		D0110-9EA0-0000	DRIVE CHAIN ASSY.(28T)	1
25-2-1		D0111-9EA0-0000	SPROCKET HOLDER, REAR	1
25-2-2		D1111-9EA0-0000	GEAR(28T)	1
25-2-3		D2706-9EA0-0000	BOLT	4
25-2-4		I5611-10200	HEX. FLANGE NUT, SAFETY	4
25-3		D2302-9EA0-0000	NUT, HEX.	2
25-4		D0100-9EA0-0000	DRIVE CHAIN COMP	1
25-4-1		D0104-9EA0-0000	DRIVE CHAIN LINK(#520)	1
25-4-2		D0105-9EA0-0000	DRIVE CHAIN	1
25-5		D0510-5EE9-0000	DRIVE CHAIN COVER	1
25-6		I0149-08016	FLANGE BOLT, HEX.	2

26.SWING ARM SUB · PROTECT COVER



ITEM	AVAIL	PART NO.	NAME	QTY
26			SWING ARM SUB,PROTECT COVER	
26-1		E220A-9KB0-0000	SWING ARM COMP	1
26-1-1		E2208-5EA0-0000	SWING ARM OIL LINER	2
26-1-2		E2200-9KB0-0000	SWING ARM	1
26-2		E2209-5EA0-0000	SWING ARM SPACER	1
26-3		E2205-5EA0-0000	OIL SEAL	2
26-4		E2201-5EA0-0000	FLANGE BOLT, HEX.	1
26-5		I5611-14200	HEX. FLANGE NUT, SAFETY	1
26-6		D3617-5EE0-0000	REAR BRAKE PROTECTIVE COVER	1
26-7		I0149-08012	FLANGE BOLT, HEX.	1
26-8		D0140-9KB0-0000	PROTECTIVE COVER	1
26-9		I9901-08100	WASHER, SPRING	2
26-10		D0120-9KB0-0000	CHAIN ADJUSTER COMP.	1
26-10-1		D0121-9KB0-0000	CHAIN ADJUSTER	1
26-10-2		I4051-061T1	FLANGE NUT, HEX	2
26-11		I0149-08016	FLANGE BOLT, HEX.	2
26-12		E221A-FID0-0000	CHAIN TENSIONER	1
26-12-1		E2210-FID0-0000	IDLER BRACKET	1
26-12-2		E2213-FID0-0000	TENSION IDLER	1
26-12-3		E2215-FID0-0000	CIRCLIP	1
26-12-4		E2214-FID0-0000	WASHER	1
26-12-5		E2216-FID0-0000	BEARING	2
26-12-6		E2212-FID0-0000	STUD	1
26-12-7		E2211-FID0-0000	RETURN SPRING	1
26-13		I4104-08010	WASHER	1
26-14		E2202-5EA0-0000	CHAIN TENSIONER ROLLER	1

27. STEERING




ITEM	AVAIL	PART NO.	NAME	QTY
27			STEERING	
27-1		E3200-5EA0-9000	SHAFT ASSY., STEERING	1
27-2		E3201-5EA0-0000	OIL SEAL	1
27-3		I3102-5AC0-0000	OIL SEAL	1
27-4		D4620-5EA0-0000	COLLAR	1
27-5		I5611-14200	HEX. FLANGE NUT, SAFETY	1
27-6		I0020-08060	BOLT, HEX.	2
27-7		E3225-5EA0-0000	PU LINER	1
27-8		E3202-9FA0-0000	HOLDER, STEERING COLUMN	2
27-9		I9900-25019	PIN, SPLIT	1
27-10		I5611-10200	HEX. FLANGE NUT, SAFETY	4
27-11		E0258-9KA0-0000	STEERING TIE-ROD ASSY., LEFT	1
27-11-1		E0251-9KA0-0000	BOLT,STUD	1
27-11-1		E0251-9KA0-0000	BOLT,STUD	1
27-11-2		E0255-FIA0-0000	UNIVERSAL JOINT(L)	1
27-11-2		E0255-FIA0-0000	UNIVERSAL JOINT(L)	1
27-11-3		E0256-FIA0-0000	UNIVERSAL JOINT(R)	1
27-11-3		E0256-FIA0-0000	UNIVERSAL JOINT(R)	1
27-11-4		E0252-5EA0-0000	NUT (R)	1
27-11-4		E0252-5EA0-0000	NUT (R)	1
27-11-5		E0253-5EA0-0000	NUT (L)	1
27-11-5		E0253-5EA0-0000	NUT (L)	1
27-12		E0259-9KA0-0000	STEERING TIE-ROD ASSY., RIGHT	1
27-12-1		E0251-9KA0-0000	BOLT,STUD	1
27-12-1		E0251-9KA0-0000	BOLT,STUD	1
27-12-2		E0255-FIA0-0000	UNIVERSAL JOINT(L)	1
27-12-2		E0255-FIA0-0000	UNIVERSAL JOINT(L)	1
27-12-3		E0256-FIA0-0000	UNIVERSAL JOINT(R)	1
27-12-3		E0256-FIA0-0000	UNIVERSAL JOINT(R)	1
27-12-4		E0252-5EA0-0000	NUT (R)	1
27-12-4		E0252-5EA0-0000	NUT (R)	1
27-12-5		E0253-5EA0-0000	NUT (L)	1
27-12-5		E0253-5EA0-0000	NUT (L)	1
27-13		I0468-12006	PIN	4

No picture.

ITEM	AVAIL	PART NO.	NAME	QTY
28			ELECTRICAL EQUIPMENT	
28-1		C2100-9KA0-0000	MAIN WIRE ASSY.	1
28-1-1		C2010-5EA0-0000	FUSE(7A)	1
28-2		C1500-9FA0-0000	BATTERY	1
28-3		C5200-5EG0-0000	LEVER HOLDER ASSY., LEFT	1
28-3-1		C5201-5EG0-0000	LEVER HOLDER , LEFT	1
28-3-2		C5202-5EE0-0000	AIR CUT, LEVER	1
28-4		C2102-9KA0-0000	EARTH CABLE	1
28-5		I8506-05016	SCREW PAN	2
28-6		I2140-50001	WASHER	4
28-7		I3401-05020-07	BOLT, HEX.	1
28-8		C0510-V30-0000	COIL COMP IGN	1
28-9		C0410-A26-9000	C.D.I. UNIT ASSY	1
28-10		C1600-B00-0000	RECTIFIER COMP REGULATE	1
28-11		I0153-06012	SCREW	1
28-12		C585A-LRA0-0000	REALY ASSY, START	1
28-12-1		C5850-LRA0-0000	START RELAY	1
28-12-2		C2101-LRA0-0000	POSITIVE CABTE	1
28-13		I8556-06012	SCREW PAN	1
28-14		C1501-9FA0-0000	FOAM STICK, BATTERY	2
28-15		C1502-9ED0-0000	FIX STRIP(175L)	1
28-16		C8110-5EE0-0000	HORN	1
28-17		C5031-5EE0-0000	TAIL LIGHT	2
28-17-1		C5004-5EE0-0000	BULB (12v 21/5w)	2
28-17-2		C5005-5EE0-0000	REVERSING LIGHT LENS	2
28-18		C5035-5EE0-0000	TAIL LIGHT RUBBER	2
28-19		I4111-05100	SPRING WASHER	4
28-20		C505A-5EE0-0000	LED COMP	1
28-21		I2804-04013-5C	TAPPING SCREW, TRUSS	2
28-22		C503A-5EE0-1000	HEAD LIGHT ASSY.	1
28-22-1		C5070-5EE0-0000	HEAD LIGHT COVER (L)	1
28-22-2		C5080-5EE0-0000	HEAD LIGHT COVER (R)	1
28-22-3		C5020-5EE0-0000	HEAD LIGHT (L)	1
28-22-3-1		C5003-5EE0-0000	BLUB ASSY.(12v 10w)	1
28-22-4		C5030-5EE0-0000	HEAD LIGHT (R)	1
28-22-4-1		C5003-5EE0-0000	BLUB ASSY.(12v 10w)	1
28-22-5		C5021-5EE0-0000	HEAD LIGHT RUBBER	2
28-22-6		I2804-04013-5C	TAPPING SCREW, TRUSS	6
28-22-7		H7111-5EE0-0000	STICKER,HAD LIGHT (L)	1

28-22-8		H7112-5EE0-0000	STICKER,HAD LIGHT (R)	1
28-23		I7707-04016	TAPPING SCREW, TRUSS	2
28-24		I8310-FIA0-0000	PLASTIC SCREW	2
28-25		C5300-9EF0-0000	SHIFT SWITCH	1
28-26		C8400-EMA0-0000	BUZZER	1
28-27		I2600-03015	SCREW PAN	2
28-28		I2020-30001	NUT, NYLON	2

29.PACKING CACE,EXTERNAL




ITEM	AVAIL	PART NO.	NAME	QTY
29			PACKING CASEEXTERNAL	
29-1		H9500-9KA0-0000	PACKING CASE,EXTERNAL	1
29-2		H9020-FIA0-0000	TOOL PACK	1
29-3		H9021-9FA0-0000	WIRE CLAMP	1
29-4		H990A-9KA0-0000	OWNER'S MANUAL ASSY	1
29-4-1	N	H9900-9KA0-0000	OWNER'S MANUAL	1
29-5		H9022-5EA0-0000	PRESSURE METER	1
29-6		H840A-9EF0-0000	FLAG HOLDER ASSY	1
29-6-1		H8401-9EF0-0000	FLAG HOLDER	1
29-6-1		H8401-9EF0-0000	FLAG HOLDER	1
29-6-2		H8402-9EF0-0000	FLAG HOLDER SEAT	1
29-6-2		H8402-9EF0-0000	FLAG HOLDER SEAT	1
29-6-3		I3415-08016-0C	BOLT HEXAGON HEAD WITH WASHER	1
29-6-3		I3415-08016-0C	BOLT HEXAGON HEAD WITH WASHER	1
29-7		H9910-9KA0-0000	CONSUMER HANG TAP	1

No picture.

ITEM	AVAIL	PART NO.	NAME	QTY
30			MANUAL CHOKE KIT	
30-1		A611A-9KA0-0000	MANUAL CHOKE KIT	1
30-1-1		A0001-A26-9000	MANUAL CHOKE COMP 1	1
30-1-2		A7920-A26-9000	CABLE, AIR CUT	1
30-1-3		C5200-5EG0-0000	LEVER HOLDER ASSY., LEFT	1
30-1-3-1		C5201-5EG0-0000	LEVER HOLDER , LEFT	1
30-1-3-2		C5202-5EE0-0000	AIR CUT, LEVER	1

31.ACCESSORIES



ITEM	AVAIL	PART NO.	NAME	QTY
31			ACCESSORIES	
31-1		C2104-9EF0-0000	REMOTE CONTROL SWITCH ASSY.	1
31-1-1		C2105-9EF0-0000	ROMOTE CONTROL SAFETY SWITCH ASSY.	1
31-1-1-1		C2106-9EF0-0000	RECEIVE(BLACK)	1
31-1-1-2		C2107-9EF0-0000	ROMOTE CONTROL(433MHZ)(YELLOW)	1
31-1-2		H7133-9EF0-0000	STICKER,SAFETY ROMOTE CONTROLLER	1
31-2		C1802-FIB0-0000	POWER SUPPLY	1

ITEM	AVAIL	PART NO.	NAME	QTY
32			SERVICE KITS,BRAKE CALLIPER	
32-1		G7137-5EE0-0000	SERVICE KITS, BRAKE CALIPER	1
32-1-1		G7134-5EE0-0000	RING,SEAL	1
32-1-2		G7135-5EE0-0000	RING,DUST RESISTANT	1
32-1-3		G7136-5EE0-0000	PISTON, BRAKE CALIPER	1
32-1-4		G7138-5EE0-0000	BRAKE SHOE ASSY	1
32-1-4-1		G7131-5EE0-0000	BRAKE SHOE COMP	1
32-1-4-2		G7139-5EE0-0000	SPRING,PAO	1
32-2		G7138-5EE0-0000	BRAKE SHOE ASSY	1
32-2-1		G7131-5EE0-0000	BRAKE SHOE COMP	1
32-2-2		G7139-5EE0-0000	SPRING,PAO	1

No picture.

ITEM	AVAIL	PART NO.	NAME	QTY
33			TOOL	
33-1		C1110-B00-FT1	TACKING ACG FLY WHEEL TOOL	1